


# COOKTOP PARTS

For Models: RF263LXTW2, RF263LXTQ2, RF263LXTT2, RF263LXTB2, RF263LXTS2

(White) (White on White) (Biscuit) (Black) (S.Steel)



30" ELECTRIC FREESTANDING  
SELF CLEAN RANGE



Illus. No.	Part No.	DESCRIPTION
1	W10141166	Literature Instructions Installations Template, Anti-Tip
	9757142	English/Spanish
	9757143	English/French
	W10162204	Owners Manual
	W10115599	Tech Sheet
	9762761	Safer Cooking Tips


Illus. No.	Part No.	DESCRIPTION
2	3195208	Bowl, Drip 6" Chrome (2)
	3195209	8" Chrome (2)
3	3186231	Cooktop White
	8272527	Biscuit
	3186233	Black

Illus. No.	Part No.	DESCRIPTION
4	3195060	Hinge, Cooktop (2)
5	3196178	Screw (2)
6	308605	Relief, Strain
7	3195812	Rod, Support (2)
8	3196154	Screw
9		Element, Surface
	9761347	6" (2)
	9761345	8" (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: RF263LXTW2, RF263LXTQ2, RF263LXTT2, RF263LXTB2, RF263LXTS2  
 (White) (White on White) (Biscuit) (Black) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009040	White Left Hand
	W10009050	White Right Hand
	W10009060	Biscuit Left Hand
	W10009070	Biscuit Right Hand
	W10009080	Black Left Hand
	W10009090	Black Right Hand
2	9757609	Nameplate
3		Panel, Control
	9762015	White
	9762016	Biscuit
	9762017	Black
	W10117592	S.Steel


Illus. No.	Part No.	DESCRIPTION
4		Switch, Infinite
	3148954	LF/RR
	3148952	LR/RF
5		Light, Indicator
	8523265	Surface Unit (2)
6	3196068	Lens, Light (3)
7		Knob, Infinite (4)
	9761962	White
	9761963	Biscuit
	9761964	Black
8	8053912	Shield, Heat
9		Screw
	3196166	White
	8281194	Biscuit
	3196168	Black

Illus. No.	Part No.	DESCRIPTION
10	8272473	Cover, Upper
11	8273564	Clip
12		Control, Range
	W10108090	White
	W10108110	Biscuit
	W10108100	Black
	W10108100	S.Steel
13	3196178	Screw
14	9762078	Brkt-Mntg, EOC
15	9762095	Brkt-Mntg, Console
16	3400882	Screw
17	3196200	Clip, Spring (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: RF263LXTW2, RF263LXTQ2, RF263LXTT2, RF263LXTB2, RF263LXTS2  
 (White) (White on White) (Biscuit) (Black) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: RF263LXTW2, RF263LXTQ2, RF263LXTT2, RF263LXTB2, RF263LXTS2


(White) (White on White) (Biscuit) (Black) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9760407	Brkt – Mounting	15	9760314	Rail, Base (2)	33	9761517	Clip,Door Mntg (2)
2	3186144	Box, Burner	16	W10058460	Foot, Rear (2)	34	W10031780	Screw
3		Panel, Side (2)	17	3196548	Thermal, Fuse	35	3196567	Screw
		Incl Side Foil #45	18	3196172	Screw	36	3196168	Screw
	8053830	White	19	3186116	Support, Oven (2)	37	3196174	Screw
	8272519	Biscuit	20	3186034	Bracket, Service	38	9758238	Retainer, Insul(2)
	8053832	Black	21	9761958	Block, Terminal	39	3196560	Screw (2)
4	W10067840	Screw (6)	22	8274034	Back, Main	40	9755804	Tube, Vent
5	8522416	Seal, Oven Door	23	9757262	Switch, Door	41	9761013	Latch, Door
6	9757340	Element, Broil	24	3196701	Light Socket Assy	42	W10078380	Rod, Latch
7	9758541	Element, Bake	25	311255	Bulb, Oven Light	43	W10107820	Latch Asy, Rear
8	3195809	Bumper (2)	26	9758701	Spacer – Door	44	112432	Nut
9	9757239	Rod – Dr Switch	27	8273902	Sensor, Oven	45	9761490	Insulation, Side
10	W10114344	Glide, Drawer Frnt	28	3196169	Screw	<b><u>INSULATION</u></b>		
11	3196037	Foot, Front (2)	29	3196179	Screw		8272616	Insulation, Wrap
12	9761512	Clip, Mounting	30	3196178	Screw		8272612	Insulation, Back
13	8054068	Tray, Insulation	31	3400016	Screw			
14	3196576	Clip, Panel (6)	32	9758283	Cover, Box			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER & BROILER PARTS

For Models: RF263LXTW2, RF263LXTQ2, RF263LXTT2, RF263LXTB2, RF263LXTS2  
 (White) (White on White) (Biscuit) (Black) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	W10138079	Rack, Oven (2)
2	9761031	Drawer, Storage
3	9758200	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
	3196813	Black
5		Panel, Drawer Frnt
	8053339	White
	8272501	Biscuit
	8053341	Black
6	8053334	Glide, Drawer (2)
7	3196168	Screw
8	W10031790	Screw(Stls. Model)
9	9755798	Panel(Stls. Model)
10	9757219	Handle(Stls. Modl)
11	9781235	Clip(Stls. Model)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: RF263LXTW2, RF263LXTQ2, RF263LXTT2, RF263LXTB2, RF263LXTS2  
 (White) (White on White) (Biscuit) (Black) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	9761975	Trim, Top
	9761976	White
	9762391	Biscuit
	9762394	Black
	9762394	S.Steel
2	3196164	Screw
3	9761982	Handle, Door
	9761984	White
	9761984	Biscuit
	9761983	Black
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Window, Inner
7	9761357	Retainer, Insul.

Illus. No.	Part No.	DESCRIPTION
8	9761493	Hinge, Door (2)
	9761493	WH,BT,BL Models
	9761496	S.Steel Model
9	W10075980	Glass, Outer
	W10075980	White
	W10076000	Biscuit
	W10075990	Black
	W10154806	SS Model
10	8523172	Trim, Side
	8523166	White Left Hand
	8523166	White Right Hand
	8523173	Biscuit Left Hand
	8523167	Biscuit Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand

Illus. No.	Part No.	DESCRIPTION
11	3196160	Screw
12	8523175	Trim, Lower
	8523175	White
	8523178	Biscuit
	8523177	Black
	8523180	Black (Used on S.Steel Model)
13	8272618	Insulation
14	3186289	Frame, Window
15	W10031780	Screw
16	8522414	Seal, Window
17	W10113759	Strap, Door
18	3196794	Bracket, Window
19	3196165	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Models: RF263LXTW2, RF263LXTQ2, RF263LXTT2, RF263LXTB2, RF263LXTS2  
(White) (White on White) (Biscuit) (Black) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

**SPLICING WIRES--25FT.**

**LENGTH**

- 242828 Wire, Black  
12 Ga. 150° c
- 242821 Wire, Blue  
14 Ga. 150°c
- 242822 Wire, Brown  
14 Ga. 150°c
- 242830 Wire, Brown  
14 Ga. 200°c
- 242823 Wire, Green  
14 Ga. 150°c
- 242824 Wire, Orange  
14 Ga. 150°c
- 242825 Wire, Red  
14 Ga. 150°c
- 242831 Wire, Red  
14 Ga. 200°c
- 242827 Wire, Yellow  
14 Ga. 150°c

**REFINISHING MATERIAL**

- 799832 Kit, Porcelain  
Repair (White)
- 242756 Touch-Up  
Self-Clean(1/2 Pt)
- 261582 Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**INSULATION**

- 261514 Insulation,  
Fiberglass (1-1/2"  
x 24" x 120")
- 240132 Insulation,  
Fiberglass (2-1/2"  
x 22" x 120")

**PAINT, TOUCH-UP (1/2oz.)**

- 72017 White
- 4392899 Biscuit
- 511873 White Porcelain  
(2 Oz.)

**PAINT, PRESSURIZED SPRAY  
(12 oz.)**

- 350930 White
- 4392901 Biscuit
- 285006 Superior Black
- 206922 Primer (White)

**PAINT, BULK (1 qt.)**

- 799344 White (Uncut)
- 4392900 Biscuit(Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**ACCESSORY PARTS**

- 241430 Foil, Aluminum  
Oven (18" x 25')
- 3191048 Cleaner, Glass
- 4396923 Pan, Broiler

**ANTI-TIP KIT**

- W10017440 Anti-Tip Kit

**WIRING HARNESS PARTS**

- W10084660 Harness, Wire  
(Sensor/Dr Switch)
- 9761476 Harness, Surface  
Unit
- 311227 Wire, Ground
- 3196154 Screw
- W10114335 Harness, Wire  
(Main)
- 313660 Clip, Wire Ground
- 3196173 Screw
- 308605 Relief, Strain
- 3196174 Screw  
(Grnd Wire / Back)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST