

Getting Started

IPH301 is a cordless phone that enable user to place and receive both traditional phone calls and Skype internet calls without using a computer.


Package Contents: The IPH301 box includes the following items:

1. Base unit
2. Handset
3. Power adaptor for base
4. NiMH AAA Rechargeable Battery x 2
5. Telephone line cord
6. Ethernet Cable
7. User Manual
8. Quick Start Guide

If there are missing items, contact your dealer


Installation

Connecting Base unit



1. Connect one end of power adaptor to the base unit (9V DC), the other end to a standard wall outlet.
2. Connect the telephone line cord to the base unit (☎) and the telephone socket for landline calling
3. Connect the LAN port of base unit (🌐) to your ADSL or cable modem using the ethernet cable


Charging the Battery



1. Place the two rechargeable batteries into the battery compartment of the handset
2. Slide the battery door to close it.
3. Put the handset into the base unit for charging for 15 hours before initial use.

Setting up Your Phone

Once the handset is turned on, it is required to configure for the first time as follows:



Language - Select Language


Agreement - Read the Skype agreement and accept it.

Country code - Enter international calling code for your country , e.g 39 for Italy, 1 for US


Area code - It indicates geographical area within one country that is covered by hundreds of telephone exchanges. Enter the area code if necessary

Signing in to Skype


After setup is completed, you can start with sign-in process by clicking sign-in option on the Right soft key.



If you already have Skype account , sign in with your username and password.



You can save your Skype name and password for future automatic log-in.






If you don't have Skype account, you can choose to create the new account. Enter your Skype name and password , read the Skype agreement and accept it.

Once signed in successfully, your Skype contacts are downloaded to your phone. This could take several minutes depending on the internet traffic and number of contacts. You can make and receive calls.

Making a Skype call

To make Skype to Skype calls:




- Press Contacts
- Use Up/Down key to scroll down and select the contacts you want to call
- Press Send button  make the call
- When finished the call, press the end button 

Making a SkypeOut call

There are two ways that you can make SkypeOut call.


Direct Dialling



1. Press and hold key until '+' appears and then input the country code/area code/telephone number
2. Press Left soft key to select SkypeOut

*SkypeOut number should be in the following format:
 "+* + * country code" + * area code" + * number"

Dial through contact list




1. Choose the SkypeOut Contact that you want to call through the list.
2. Press Left soft key to select SkypeOut

Making a landline call


There are two ways that you can make landline call.

Direct Dialling




1. Input the landline number
2. Press the send key directly or press Left soft key to select landline to make the landline call

Dial through contact list



1. Choose the SkypeOut Contact that you want to call through the list.
2. Press Left soft key to select landline in order to make the landline call

Main Display



Skype Status – Display the Skype current Status

	Online	Online and ready to talk or chat.
	Offline	Not signed in to Skype
	SkypeMe™	Ready and willing to receive calls and chats from anyone.
	Away	Away from your computer a few minutes.
	Not available	Have been away from your computer for a long time.
	Do not disturb	Busy and will not be notified of incoming calls or chats

Main Menu

The user can access to all Skype and phone settings under the Main Menu. It include Contact, History, Status, Add contact, Search, Services and Settings.

	Contact	Your contact list, where you can see if they're online, offline, busy or away from their computer
	History	Show missed, incoming and outgoing calls
	Status	Set Skype status, edit your profile
	Add Contact	Add Skype/SkyeOut Contacts to your list
	Search	Search for Skype Contact
	Services	Skype Credit, Skypeln, and VoiceMail
	Settings	Other Phone setting

Handset Icons

The below icon appeared on the handset will indicate what the handset status.

	New Missed calls
	New voicemail
	Exchange contact details request
	Silent mode is active
	Headset connected
	Keypad locked
	Skype credit is nearly expired
	The speakerphone is on

Signal Strength / Battery status icon

	Signal Strength level
	Handset lost link
	Battery low level indicator
	Partially charged
	Fully charged
	Charging