





# Mains Plug Travel Adapter


1. Slide the plug-insert all the way into the master unit (**Figure 1**)
2. Move the sliding lock button into the LOCK position (**Figure 2**)



**Figure 1**



**Figure 2**













**NEVER** separately plug a plug-insert into a mains socket!

Always check that the plug-insert is correctly locked into the master unit.

**IMPORTANT:** This adapter is designed to change the shape of the plug only. It **DOES NOT** change the voltage! Before use, please ensure your electrical equipment complies with the voltage of the country you are in.

For temporary travel use only; not for permanent use!

**Keep out of reach of children!**



No. 73013

April 2006

[www.lindy.com](http://www.lindy.com)