



## Feature operation

### Call Forward

Activate	Fwd		
Deactivate			
Reinstate	Fwd		

### Call Pickup

		Pickup
--	--	--------

### Conference

	Conf		
--	------	--	--

### Hold

Place a call on hold		(Hold)
Return to a held call		(Line)

### Last Number Redial

			(Line)
--	--	--	--------

### Message

			(Msg/Inbox)
--	--	--	-------------

### Ring Again

Activate	RngAgn	
When notified		
Deactivate		

### Transfer

	Trans		
--	-------	--	--

### Adjust volume

		or		(Volume +)	(Volume -)
--	--	----	--	------------	------------

## Legend

Icon	Action
( )	Indicates the key cap text label. For example, (Message).
	Lift the handset.
	Replace the handset.
	Press the goodbye key.
(Goodbye)	
	Dial a number.

## Legend (continued)

Icon	Action
	Press the line key.
	An icon flashes when a feature is being programmed. An icon lights steadily when a feature is active.
	Press the <b>Services</b> key once for server-based features, or press the <b>Services</b> key twice for local phone features.
	Press the <b>Message/Inbox</b> key.
	Press the <b>Up/Down Navigation</b> keys
	Press the <b>Enter</b> key
	Press the <b>Expand</b> key

## Services and Telephone Options menus

### Services menu



**Note:** The **Services** menu contains the **Telephone Options**, **Password Admin**, **Virtual Office**, and **MG 1000B** menus. These options are not available on all Nortel IP Phone 1110 phones. Consult your system administrator.

### Telephone Options menu

The following are the most commonly used options:

#### Volume adjustment

Choose one of:


- . Ringer
- . Handset Listen
- . Listen-only speaker
- . Buzzer



#### Contrast adjustment



#### Language



**Note:** This language setting controls the language used by features on your phone only. To set the language used elsewhere on your phone, press **Services** twice, select 1. Preferences, and select 2. Language.

#### Date/Time format



#### Local DialPad Tone



#### Ring type



#### Call Timer



## Nortel IP Phone 1110



\*Note: If supported by your server, the Feature Status Lamp provides a user-defined alert. Contact your system administrator to find out if this feature is available for you.

# NORTEL

## IP Phone 1110

For Nortel Communication Server 1000

## Quick Reference Card



To provide feedback or report a problem in this document, go to [www.nortel.com/documentfeedback](http://www.nortel.com/documentfeedback).

Date: March 2007

Document Release: Standard 01.01

Document Number: NN43110-100

Copyright © 2007, Nortel Networks.

All rights reserved.

\* Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.