



myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for MOTOROLA DIGITAL CORDLESS PHONE-MD451. You'll find the answers to all your questions on the MOTOROLA DIGITAL CORDLESS PHONE-MD451 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

[User manual MOTOROLA DIGITAL CORDLESS PHONE-MD451](#)
[User guide MOTOROLA DIGITAL CORDLESS PHONE-MD451](#)
[Operating instructions MOTOROLA DIGITAL CORDLESS PHONE-MD451](#)
[Instructions for use MOTOROLA DIGITAL CORDLESS PHONE-MD451](#)
[Instruction manual MOTOROLA DIGITAL CORDLESS PHONE-MD451](#)



MD450 Series

Digital 2.4 GHz
Expandable Cordless Telephone System
Système téléphonique
sans fil évolutif numérique 2,4 GHz

User's Guide >
Guide de l'utilisateur >



[Your user manual](#)
[MOTOROLA DIGITAL CORDLESS PHONE-MD451](#)

Manual abstract:

Note: If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this cordless phone does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer. Repairs Repairs to this equipment should be made by an authorized Canadian maintenance facility designated by Motorola. Any repairs or alterations made by the consumer, or any malfunctions of this equipment, may give the telecommunications company cause to request that you disconnect the equipment, and may void the limited warranty. Privacy Privacy of communications may not be ensured when using this telephone. Other devices, including other cordless telephones, may interfere with the operation of this cordless phone or cause noise during operation. Units without code access may be accessed by other radio communications devices. Hearing Aid Compatibility This telephone system meets Industry Canada standards for hearing aid compatibility. Interference Information This device complies with Industry Canada's RSS-210. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

4 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Industry Canada's ICES-003. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference with one or more of the following measures: · Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).

· Reorient or relocate and increase the separation between the telecommunications equipment and the receiving antenna. · Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected. If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Industry Canada publishes several publications to assist consumers with solving interference problems, which are available from its offices or from its web site (strategis.gc.ca).

ITC02-173s IC Information 5 Important Safety Instructions Follow these safety precautions when using your cordless phone to reduce the risk of fire, electric shock, and injury to persons or property: 1. Keep all slits and openings of the phone unblocked. Do not set the phone on a heating register or over a radiator. Ensure that proper ventilation is provided at the installation site. 2. Do not use while wet or while standing in water. 3. Do not use this product near water (for example, near a bath tub, kitchen sink, or swimming pool). 4.

Do not allow anything to rest on the power cord. Place the power cord so that it will not be walked on. 5. Never insert objects of any kind into the product slits as that may result in fire or shock. 6. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning. 7. Do not disassemble this product.

If service or repair work is required, contact the Motorola address found in the back of this user's guide. 8. Do not overload wall outlets and extension cords. 9. Avoid using during an electrical storm.

Use a surge protector to protect the equipment. 10. Do not use this cordless phone to report a gas leak, especially if you are in the vicinity of the gas line. Caution: To reduce the risk of fire, use only No. 26 AWG or larger UL Listed or CSA Certified Telecommunication Line Cord.



[Your user manual](#)

[MOTOROLA DIGITAL CORDLESS PHONE-MD451](#)