2.0m

3.0m

2.0m

3.0m



HP Parts Reference Guide™ www.hp.com/go/hpparts

Electronic Accessories

Power Module

C6409-60014

25

C	able (Interface)	
	5063-1256	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 2 (6.6ft) long
	5063-1257	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 3 (9.8ft) long
	C2950A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 2 (6.6ft) long
	5063-1256	New Part for C2950A
	C2951A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 3 (9.8ft) long
	C2990A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) (type A) to 36 pin (M) Centronics (type B) - 1.8m (6ft) long NO LONGER SUPPLIED
	C2991A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) (type A) to 36 pin (M) Centronics (type B) - 3.0m (10ft) long NO LONGER SUPPLIED
	8120-8485	Universal Serial Bus (USB) interface cable - Type 'A' connector to type 'B' connector, 1.8m (6.0 ft) long
	C6518A	Universal serial bus (USB) interface cable - Type 'A' connector to type 'B' connector - 2.0m (6.6ft) long

		NO LONGER SOLL FILED
	8120-8485	Universal Serial Bus (USB) interface cable - Type 'A' connector to type 'B' connector, 1.8m (6.0 ft) long
	C6518A	Universal serial bus (USB) interface cable - Type 'A' connector to type 'B' connector - 2.0m (6.6ft) long
Ele	ectronics/Power	Supply
	Cable	
9	C4557-60022	Cable assembly - An 11 pin (F) connector to two 3 pin (F) connectors and a 7 pin (F) connector - 36.8cm (14.5 inches) long
10	C4557-80075	Carriage assembly flex cable - 40.3cm (15.9 inches) long
11	C5870-60140	Cable assembly - 12 pin (F) connector, 5 pin (F) connector, and 7 pin (F) connector - 43.9cm (17.3 inches) long
	Keypad	
12	C4557-60009	Keypad assembly
	PC Board	
13	C4557-60062	Banner PCA and cable assembly
14	C6409-60200	Paper encoder PCA - Controls operation of paper motor
15	C6419-69118	Main logic PCA - Configured for English font - Not for Europe NO LONGER SUPPLIED
16	C6419-69119	Main logic PCA - Not for purchase in Europe - Can be configured for Arabic, Cyrillic, Greek, Hebrew, Lithuanian, Latvian, or Thai fonts
	Power Cord	
17	5185-7509	Power cord (For 120V in the USA, Canada, Mexico, and Latin America) - Note: This power cord has been recalled
18	8120-8336	Power cord (Quartz Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 100V in Japan)
19	8120-8337	Power cord (Quartz Gray) - Two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 240V in Australia and New Zealand)
20	8120-8341	Power cord (Quartz Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 240V in the UK)
21	8120-8345	Power cord (Quartz Gray) - Two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 240V in South Africa and India)
22	8120-8346	Power cord (Quartz Gray) - Two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 220V in China)
23	8120-8900	Power cord (Flint Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 120V in the USA, Canada, Brazil, Latin America and Saudi Arabia)
24	8121-0023	Power cord (Flint Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 220V in Europe, Asia Pacific, Germany, Spain, France, Netherlands, Switzerland, Italy, and Portugal)

© 2004 Hewlett-Packard

Power Supply Module - 100V-240V, 50/60Hz - Requires separate AC power cord - For worldwide use



www.hp.com/go/hpparts

External Case Parts

(Cover	
26	C4557-60020	Left side case
27	C6409-60162	Right side case
28	C6411-40008	Main logic PCA cover - Has cut outs for the USB interface socket, parallel interface socket, and power module socket
	Door	
29	C5870-40045	Top/front access door - Print cartridge access door - Solid door without a window opening
30	C6458-60001	Top/front access door assembly - Print cartridge access door with strawberry colored window - Includes installation instructions
31	C6458-60002	Top/front access door assembly - Print cartridge access door with strawberry colored window - Includes installation instructions
32	C6459-60001	Top/front access door assembly - Print cartridge access door with lime window - With installation instructions
33	C6459-60002	Top/front access door assembly - Print cartridge access door with lime colored window - Without installation instructions
34	C6460-60001	Top/front access door assembly - Print cartridge access door with tangerine colored window - With installation instructions
35	C6460-60002	Top/front access door assembly - Print cartridge access door with tangerine window - Without installation instructions
36	C6461-60001	Top/front access door assembly - Print cartridge access door with grape colored window - With installation instructions
37	C6461-60002	Top/front access door assembly - Print cartridge access door with grape colored window - Without installation instructions
38	C6462-60001	Top/front access door assembly - Print cartridge access door with blueberry colored window - With installation instructions
39	C6462-60002	Top/front access door assembly - Print cartridge access door with blueberry colored window - Without installation instructions NO LONGER SUPPLIED
40	C6409-40014	I/O and power input cable covering door
41	C4557-60076	Rear cleanout door assembly - Paper jam cleanout door
	Foot	
42	C4557-40118	Rubber foot
	Knob	
43	C4557-40090	Rear cleanout door knob
	Namenlate/Logo	

Nameplate/Logo

C6411-40002 Nameplate - DeskJet 812C

Plate

44

47

48

49

50

65 C4557-40014 Back Plate - Holds Latch Spring, Knob and Latch Components of Rear Cleanout Assembly

Other Accessories

CD-ROM (Support)

C6450-60020	Deskjet and Deskyvriter service manual on CD-ROW - Version 4.1
C6450-60021	DeskJet and DeskWriter service manual on CD-ROM - Version 4.1

Cartridge

46	C1823A	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8
		inch by 10 inch print area (for USA)

C1823D New Part for C1823A

C1823AA	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8

inch by 10 inch print area (for Asia/Pacific)

C1823AC Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8

inch by 10 inch print area (for Canada)

C1823AE Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8

inch by 10 inch print area (for Europe)

C1823AL Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8

inch by 10 inch print area (for Latin America)



Other Accessories

C6462A

door

	Cartridge	
51	C1823D	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for USA)
52	C1823DA	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Asia/Pacific)
53	C1823DC	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Canada)
54	C1823DE	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Europe)
55	C1823DL	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Latin America)
56	C1823G	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for USA)
57	C1823GA	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Asia/Pacific)
58	C1823GE	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Europe)
59	C1823GL	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Latin America)
60	C1823T	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for USA)
61	C1823TA	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Asia/Pacific)
62	C1823TE	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Europe)
63	C1823TL	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Latin America)
64	C6618AN	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch (20.3cm) by 10 inch (25.4cm) print area (for USA) NO LONGER SUPPLIED
65	C6615AA	No.15 black ink print cartridge - 21 ml ink (for Asia/Pacific)
66	C6615AC	No.15 black ink print cartridge - 21ml ink (for Canada) NO LONGER SUPPLIED
67	C6615AE	No.15 black ink print cartridge - 21 ml ink (for Europe)
68	C6615AL	No.15 black ink print cartridge - 21 ml ink (for Latin America)
69	C6615AN	No.15 black ink print cartridge - 21ml ink (for USA) NO LONGER SUPPLIED
7 0	C6615DA	No.15 black ink print cartridge - 25 ml ink (Asia Pacific)
71	C6615DC	No.15 black ink print cartridge - 25 ml ink (Canada)
72	C6615DE	No.15 black ink print cartridge - 25 ml ink (Europe)
73	C6615DL	No.15 black ink print cartridge - 25 ml ink (Latin America)
74	C6615DN	No.15 black ink print cartridge - 25 ml ink (for USA)
	Door (Product)	
77	C6458A	Top/front access door assembly - Print cartridge access door with Strawberry colored window - Replaces the existing door
78	C6459A	Top/front access door assembly - Print cartridge access door with Lime colored window - Replaces the existing door
79	C6460A	Top/front access door assembly - Print cartridge access door with Tangerine colored window - Replaces the existing door
80	C6461A	Top/front access door assembly - Print cartridge access door with grape colored window - Replaces the existing door

© 2004 Hewlett-Packard 3

Top/front access door assembly - Print cartridge access door with blueberry colored window - Replaces the existing



www.hp.com/go/hpparts

Other Accessories

Lubricant

6040-0800 Special lubricating oil - For carriage slider rod surface - 1 quart bottle (.95 liter)

NO LONGER SUPPLIED

6040-0911 Special lubricating oil - For carriage slider rod surface - (syringe with 35cc oil)

Manual

C6413-90023 DeskJet user's guide for Apple/Macintosh (English)

Restraint

C6409-80031 Right carriage restraint - Used to protect the carriage assembly from damage during shipment

Retainer

C6409-80030 Left carriage retainer - Protects the carriage assembly from damage during shipment

Return Kit

5183-5268 Return kit with box and instructions - For returning defective Thermal InkJet (TIJ) 2.5 InkJet cartridges covered under the

CREW program - For USA

5184-2833 Return kit with box and instructions - For returning defective Thermal InkJet (TIJ) 2.5 InkJet cartridges covered under the

CREW program - For use outside of the USA

Tool

9301-1717 35cc syringe - For use with carriage slider rod lubricant

Other Internal Parts

Brace

90

91

92

93

94

95

96

C4557-40128 Left backBone brace - Provides support for backBone

C4557-40130 Left wall brace - Provides support for left wall

C5870-40020 Right backbone brace - Installed on right side of printer base to provide support for backbone

Ferrite Assembly

9170-1655 Ferrite core

Frame

C5870-40039 Wing frame - Chassis for in/out tray components

Shield

C4557-00038 Paper motor ESD shield
C6409-00007 Main logic PCA EMI shield
NO LONGER SUPPLIED

Paper Tray Parts

Cam

133 C4557-40034 Drawer cam - Short, spring loaded lever attached to the base of the wing frame - Used to draw input tray into position

Channel

134 C5870-00006 Width adjust channel

Door

135

137

138

139

C4557-40026 Output door - Separates output media from input media

Guide

136 C5870-40037 Length adjuster - Media input length adjuster

NO LONGER SUPPLIED

C6409-40034 Left wall pusher - Pushes against left side of media to maintain correct edge alignment

C6411-40004 Width adjust (Gray) - Holds media against right wall of input tray

NO LONGER SUPPLIED

Lever

C6411-40006 Banner lever - Used to choose either single sheet paper or continuous feed (Banner) paper

NO LONGER SUPPLIED



www.hp.com/go/hpparts

Paper Tray Parts

Pad	
-----	--

140

143

144

145

147

150

155

C4557-80027 Length adjust pad (Poron) - Mounted under the fine length adjuster

Panel

141 C4557-40098 Paper tray left inner panel (Left cheek cap)
 142 C4557-40099 Paper tray right inner panel (Right cheek cap)

NO LONGER SUPPLIED

C4557-40116 Paper tray left outer panel (Left cheek)
C5870-40019 Paper tray right outer panel (Right cheek)

Spring

C4557-00029 Left wall spring (Front) - Holds left wall assembly in position
C4557-00030 Left wall spring (Rear) - Provides pressure against media

C4557-00031 Paper length adjuster spring - Provides tension for paper input length adjuster

C6455-00011 New Part for C4557-00031

C4557-00035 Paper pusher spring - Maintains alignment in paper tray
 C4557-20020 Envelope spring - Holds envelopes in position for picking

C6409-00017 Wing torsion spring - Provides pressure on the wing during paper output

NO LONGER SUPPLIED

Stop

151 C6411-40005 Fine paper length adjuster (Gray) - Holds paper firmly against the back of the paper input tray

Tray

152 C4557-60049 Paper input tray pressure plate

153 C5870-40028 Paper input tray base - Does not include the pressure plate assembly

Tray Assembly

154 C5870-60081 Paper input tray assembly (partial) - Includes only base of tray and pressure plate assembly

C6411-60004 Paper tray left side assembly (Left cheek assembly) - Includes left cheek, banner PCA and cable assembly, banner

switch lever

NO LONGER SUPPLIED

Wing

C4557-40024 Left wing - Holds printed paper after being ejected
 C4557-40025 Right wing - Holds printed paper after being ejected

Paper and Other Media

Film (Transparency)

C3832A Premium InkJet transparency film - A4 size (21.0cm x 29.7cm) - 20 sheets per package
C3835A Premium InkJet transparency film - A4 size (21.0cm x 29.7cm) - 50 sheets per package
C6053A Premium InkJet rapid-dry transparencies - A4 size (21.0cm x 29.7cm) - 50 sheets per package

NO LONGER SUPPLIED

C3828A Premium InkJet transparency film - A size (8.5 x 11-inches) - 20 sheets per package
C3834A Premium InkJet transparency film - A size (8.5 x 11-inches) - 50 sheets per package
C6051A Premium InkJet rapid-dry transparencies - A size (8.5 x 11-inches) - 50 sheets per package

NO LONGER SUPPLIED

Greeting Card Kit

C6587AN Printable Expressions all occasions card kit - Includes 20 greeting cards and envelopes, and a CD-ROM with 24 original

pieces of art

NO LONGER SUPPLIED



www.hp.com/go/hpparts

Paper and Other Media

Iron-On Transfers

C6050A Iron-on T-shirt transfers - A4 size (21.0cm x 29.7cm) - 10 sheets per package

C6065A Iron-on T-shirt transfers - A4 size (21.0cm x 29.7cm) - 10 sheets per package (Asia)

C6049A Iron-on T-shirt transfers - A size (8.5 x 11-inches) - 10 sheets per package

Paper

C6828A Greeting card paper pack (White) - A size (8.5 x 11-inches) - Felt textured - Includes 20 sheets and 20 envelopes

C6042A Greeting card paper pack (White) - A4 size (21.0cm x 29.7cm) - Includes 20 sheets and 20 envelopes
C1812A Greeting card paper pack (White) - A size (8.5 x 11-inches) - Includes 20 sheets and 20 envelopes

Paper (Banner)

C1821A Banner paper - A4 size (21.0cm x 29.7cm) - Perforated for easy separation - 100 sheets per pack
C1820A Banner paper - A size (8.5 x 11-inches) - 24 lb - Perforated for easy separation - 100 sheets per pack

Paper (Glossy)

C6817A Professional glossy InkJet brochure and flyer paper - Glossy on both sides - A size (8.5 x 11-inches) - 50 sheets per box

Paper (InkJet Photo)

C6983A Photo quality InkJet paper - With two sided semi-gloss finish - A size (8.5 x 11-inches) - 25 sheets per package

C7007A Photo quality InkJet paper - With two sided matte finish - A size (8.5 x 11-inches) - 100 sheets per package

Paper (InkJet)

51634Z InkJet non-glossy LX paper - A4 size (21.0cm x 29.7cm) - 200 sheets per package C1825A Bright white InkJet paper - A4 size (21.0cm x 29.7cm) - 500 sheets per package

C1853A Premium InkJet heavyweight paper - A4 size (21.0cm x 29.7cm) - Coated on both sides - 100 sheets per package

C5977A Bright white InkJet paper - A4 size (21.0cm x 29.7cm) - 200 sheets per package
C5977B Bright white InkJet paper - A4 size (21.0cm x 29.7cm) - 250 sheets per package
InkJet non-glossy LX paper - A size (8.5 x 11-inches) - 200 sheets per package
C1824A Bright white InkJet paper - A size (8.5 x 11-inches) - 500 sheets per package
C5976A Bright white InkJet paper - A size (8.5 x 11-inches) - 200 sheets per package
C5976B Bright white InkJet paper - A size (8.5 x 11-inches) - 250 sheets per package

Paper (Matte)

C7018A Matte greeting cards (White) - Half fold - A size (8.5 x 11-inches)

C6955A Professional and flyer paper (Matte) - A size (8.5 x 11-inches) - 50 sheets

Paper (Photo)

C1846A Photo paper - A size (8.5 x 11-inches) - 20 sheets per package

C6979A Premium glossy photo paper (fast dry time) - A size (8.5 x 11-inches) - 50 sheets per package

C6040A Premium glossy photo paper - A4 size (21.0cm x 29.7cm) - 15 sheets per package (Europe, Brazil, and Argentina)

C6043A Premium glossy photo paper - A4 size (21.0cm x 29.7cm) - 15 sheets per package (Japan)

C6039A Premium glossy photo paper (Fast dry time) - A size (8.5 x 11-inches) - 15 sheets per package

C6055A Deluxe glossy photo paper - A size (8.5 x 11-inches) - 20 sheets per pack - For use with DeskJet KIE-logo printers

C6039A New Part for C6055A

Paper (Textured)

C7019A Textured greeting card - White half fold - A size (8.5 inches x 11 inches)

Print Mechanism Parts

Adjuster

158

C6409-40021 Carriage rod adjuster - Used to support and align the carriage rod (2 used) - This item should be replaced only by

trained, experienced service personnel

NO LONGER SUPPLIED



www.hp.com/go/hpparts

Print Mechanism Parts

Bac	kb	or	1e
-----	----	----	----

C6409-00013 BacKBone - Large metal item where the main logic PCA and the carriage drive motor are mounted - This item should be

replaced only by trained, experienced service personnel

Belt

159

160

161

162

163

165

167

169

170

173

174

177

178

180

182

C4557-40049 Carriage drive belt - Moves printhead side to side

NO LONGER SUPPLIED

Blade

C2145-00037 ESD blade - Installed between cartridge and carriage PCA ESD blade - Installed between cartridge and carriage PCA

Bracket

C5870-00010 Paper motor mounting bracket

Cam

C6409-40040 Pick cam - Controls pressure plate and lever

NO LONGER SUPPLIED

Carriage

164 C6409-40031 Ink cartridge carriage

C6409-60003 Ink cartridge carriage assembly - This item should be replaced only by trained, experienced service personnel

Encoder

166 C4557-80019 Paper motor encoder disk

Flag

C5870-40024 OOPS flag - Media sensor - Mounts on the top right edge of the upper paper guide

Gear

168 C4557-40007 Pick gear

C4557-40021 Feed roller idler gear

C4557-40095 Encoder gear

171 C4557-40102 Feed roller cluster gear

Guide

172 C4557-40013 Rear paper guide - Guides media through rear of printer

C4557-40121 Paper encoder disk guide

C6409-40022 Upper paper guide - Guides media through paper path

NO LONGER SUPPLIED

C6409-40030 Spring guide

C6428-40002 Rear paper guide - Platform for rear rollers - Part of rear cleanout assembly

Latch

C4557-40042 Plastic latch (Y-shaped) - Used in conjuction with the knob to hold the rear paper cleanout door assy in place

C4557-60045 Cartridge latch (Black) - Holds black ink cartridge in place

NO LONGER SUPPLIED

179 C4557-60046 Cartridge latch (Color) - Holds color ink cartridge in place

Lever

C4557-00037 Pressure plate lever - Transfers upward pressure from the separator lifter to the kicker

181 C5870-40022 Paper pusher - Small, spring loaded lever attached to pivot - Pushes against left side of paper to maintain right edge

alignment

Lifter

C4557-40063 Separator lifter - Used to lift the separator peg

Link

183 C6429-60025 Kicker bar cam link (Spring loaded)



www.hp.com/go/hpparts

Print Mechanism Parts

C4557-00033

C4557-20003

210

211

Prir	nt Mechanism P	arts
N	Motor	
184	C4557-60003	Carriage motor assembly (Includes pulley)
185	C6409-60004	Paper advance motor
F	PC Board	
187	C6409-60237	Ink cartridge carriage PC board
F	Paper Stacker	
186	C4557-40016	Kicker - Restacks paper in stack after top sheet is picked
F	Pin	
188	C5870-40029	Separator peg
F	Plate	
189	C6409-40028	Belt Attachment Plate - Mounted to back of Ink Cartridge Carriage Assembly - Used to attach the Carriage Drive Belt
F	Retainer	
190	C4557-00024	Ferrite retainer - Holds head drive flex cable ferrite
191	C4557-20026	Felt retainer - Holds the lubricating felt to the side of the carriage
F	Rod	
192	C6409-20004	Carriage rod - Shaft that the carriage assembly rides on - This item should be replaced only by trained, experienced service personnel
F	Roller	
193	C4557-20002	Pinch roller - Provides downward pressure on media as it passes by upper paper guide
194	C4557-40015	Rear roller (Black) - Between paper and rear paper guide NO LONGER SUPPLIED
195	C4557-60025	Pivot feed roller - Shaft with 4 hard rollers - Does not include other items such as gear or encoder
196	C5870-40030	Postscan roller - Shaft with 2 rollers - Mounts on underside of the lower ADF chassis
197	C5870-60092	Pickup roller assembly - Shaft with large rollers, gear, and 2 bearings - Picks paper from paper input tray - Available for trade sales in Europe and Asia/Pacific - Available for authorized service centers only in USA
198	C6409-60037	Pivot feed roller assembly - Shaft with small rollers and paper encoder - This item should be replaced only by trained, experienced service personnel
199	C6426-60049	Pickup roller - Shaft with large rollers - Does not include other items such as gear or bearings
S	Separator	
200	C4557-60011	Separator pad
S	Shaft	
201	C4557-20027	Cartridge latch shaft near top of carriage - Used to hold cartridge latches in place
S	Shift Plate	
	C6455-60057	Shift plate assembly - Five plastic gears held in a two piece plastic frame - Attaches to feedroller assembly
S	Slide	
203	C5870-40036	Integrated slider for carriage assembly
S	Snap	
204	C4557-40150	Pivot snap - Used to hold pivot to pick feed roller shaft
S	Spring	
205	C2145-00033	ESD spring between ESD blade and carriage PCA
206	C4557-00009	Separator spring - Provides pressure between separator assembly and the center drive roller
207	C4557-00011	Drawer spring - Holds input drawer in place
208	C4557-00017	Belt tension spring - Provides tension for carriage belt
209	C4557-00018	Encoder spring - Provides tension for encoder strip

© 2004 Hewlett-Packard 8

Rear roller spring - Flexible axle for rear roller

Link spring - Provides tension to shaft of pick cam gear



www.hp.com/go/hpparts

Print Mechanism Parts

_				
· ·	-	2	n	~
•	u			u
_	г			-

C4557-20007 Pinch spring - Provides tension on upper paper guide
 C4557-20009 Latch spring - Provides friction for rear access door knob

214 C4557-20024 Shifter spring - Provides tension on the pivot

C4557-20028 EOR tension spring - Maintains tension on wear strip

C5870-20002 Paper stacker (kicker) spring

Strip

215

216

217

219

221

C4557-80001 Encoder strip - Clear strip with position marks - Used by the sensor in the carriage assembly to determine position

218 C5870-00004 Wear strip - Long, spring loaded strip mounted in top of backbone - Used to ensure smooth ink cartridge carriage motion

Support

C6409-00008 Upper paper guide support - Base for upper paper guide

NO LONGER SUPPLIED

Turnaround Assembly

220 C4557-60109 Turnaround assembly - Provides carriage belt tension - Does not include spring

Washer

C4557-80002 Felt washer - Used to lubricate the carriage rod

Replacement Printer

Printer

C6411-69003 Replacement DeskJet 812C - Without power cord

NO LONGER SUPPLIED

Service Station Parts

Absorber

C5870-80007 Spittoon sponge - Absorbs excess ink from cartridges

Bonnet

C5870-40016 Service station bonnet - Top cover of the spittoon - Has cutout for pallet/link assembly

Clip

224

228

229

232

225 C5870-00002 Service station ESD grounding clip

Gear

C4557-40079 Transfer gear (Double gear)C5870-40017 Cluster gear (Large gear)

Motor

C5870-60004 Service station motor assembly - Includes PC board and gear

Pallet

C6426-60054 Pallet/link assembly - Installed between spittoon and sled cap assembly - Mounting platform for the wiper and capping

systems parts

Shaft

230 C4557-40066 Drive shaft with molded gears on each end - Inside the service station spittoon assembly

231 C4557-60013

C4557-60013 Sled cap assembly - Top cover of the service station assembly - Includes print cartridge caps (gaskets which keep the

cartridges from drying out when not printing)

Snap

Sled

C4557-40069 Cap snap - Installed between pallet/link assembly and sled cap assembly - Used to hold the cap spring

Spittoon

233 C5870-40014 Spittoon base - The bottom of the service station assembly



Service Station Parts

Spring

C4557-00026 Cap spring - Provides pressure to cap parked print cartridges

Vent

C4557-40068 Cap vent - For equalizing the print cartridge capping pressure

Wiper


236 C4557-60014 Wiper assembly - Metal base with plastic wipers

11




HP Parts Reference Guide™ www.hp.com/go/hpparts

Main Assembly Locator






Carriage Assembly






Paper Drive Motor Assembly




Paper Tray Assembly (1 of 2)






Paper Tray Assembly (2 of 2)






Printer Mechanism (1 of 2)

2 of 2 >






Printer Mechanism (2 of 2)






Rear Access Cleanout Assembly

Rear Access Cleanout Assembly-41






Service Station





Upper Paper Guide Assembly





HP Parts Reference Guide

http://www.hp.com/go/parts

HP PartSurfer

http://partsurfer.hp.com

HP Parts Ordering Information

http://www.hp.com/go/hpparts

HP Parts Questions/Comments

http://partsurfer.hp.com/contactus.htm