


# KitchenAid® DOOR AND PANEL PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
 (Black) (White) (Almond)

UNDERCOUNTER  
 DISHWASHER

**Illus. Part**  
**No. No. DESCRIPTION**


1	9743028	Door Frame
2	302868	Screw
3	9742964	Stiffener, Door
4		Panel Front
	3379375	Black Model
	3379376	White Model
	3379377	Almond Model
5		Access Panel & Clip Assembly (Includes Items 11 & 12)
	3379917	Black Model
	3379918	White Model
	3379919	Almond Model
6	3379643	Spring, Door (2)
7	3373234	Bushing, Spring Door (2)
8		Toe Panel (Includes Item 11)
	3368942	Black Model
	9742861	White Model
	9742862	Almond Model
11	9743825	Insulation
12	3378123	Clip, Grounding
13	3367670	Screw (2)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)




Illus. No.	Part No.	DESCRIPTION
1		Console (Also Order Item 2)
	9743753	Black Model
	9743754	White Model
	9743755	Almond Model
2		Insert
	9743375	Black Model
	9743376	White Model
	9743377	Almond Model
3	9743241	Switch, Panel (User Interface)
4	9743573	Spring, Handle
5	9743572	Link, Handle
6	9743412	Sponge, Vent
7	304231	Screw (3)
8	3369051	Screw (4)
9		Handle, Latch
	9743903	Black Model
	9743904	White Model
	9743905	Almond Model

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR AND LATCH PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR AND LATCH PARTS


For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	9743399	Cap, Dispenser
2	3369325	Switch
3	3369051	Screw, Door
4	9743978	Latch, Bolt Assy. (Includes Item 2)
5	4159424	Screw
6	9742353	Inner Door Mastic Assembly (Also Includes Items 7, 9 & 10)
7	9743542	Seal, Door Lower
8	9742770	Vent Assembly (Also Order Item 9)
9	9742782	Gasket, Vent
10	9742780	Deflector, Vent (Also Order Item 9)
11	9742629	Dispenser, Assembly
12	9743450	Shield, Dispenser
13	9742623	Bracket, Controls
15	9743487	Guide, Door
16	9743486	Bracket, Dispenser (2)
19	3380945	Control, Electronic
20	246132	Screw (2)
22	9743451	Fuse Thermal Electronic
24	9743154	Dispenser, Wiring Harness
25	9742397	Sound Absorber
26	9742852	Sensor, Rinse Aid
27	3376405	Elbow, Harness
30	9743820	Wiring Harness Main
33	3400700	Screw (6)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LOWER WASHARM AND STRAINER PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
 (Black) (White) (Almond)




Illus. No.	Part No.	DESCRIPTION
1	9742947	Wash Arm Assembly
2	9742945	Nut, Washarm
3	9742646	Strainer (Coarse)
4	9742946	Bearing, Radial
5	3376846	Seal, Sprayarm

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# HEATER PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	9743495	Heater Element Assembly (Also Includes Item 2)
2	717273	Washer, Heater Element
3	9743039	Nut, Heater Element
4	9743166	Pod, Terminal Heater


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FILL AND OVERFILL PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


- |    |         |   |
|----|---------|---|
| 1  | 9741999 | Control, Overfill Assembly (Also Order Item 14) |
| 2  | 9742727 | Hose, Inlet                                     |
| 3  | 9742783 | Water Inlet Assembly (Includes Items 4 & 5)     |
| 4  | 9742787 | Gasket  |
| 5  | 9742786 | Bezel, Inlet                                    |
| 6  | 301958  | Clamp, Hose                                     |
| 7  | 9743559 | Fill Valve Assembly                             |
| 8  | 304392  | Screw   |
| 10 | 4159424 | Screw   |
| 11 | 9743413 | Switch, Overfill Control                        |
| 12 | 9741997 | Standpipe, Overfill                             |
| 13 | 4161670 | Gasket, Flat                                    |
| 14 | 9741998 | Nut, Standpipe                                  |
| 15 | 9743070 | Float & Retainer Assembly                       |
| 16 | 4171116 | Lever, Overflow Switch                          |



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UPPER WASH AND RINSE PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)




Illus. No.	Part No.	DESCRIPTION
1	3376846	Seal, Sprayarm
2	3400031	Screw
3	9742989	Sprayarm, Upper (Also Order Item 1)
4	9742992	Manifold, Sprayarm
5	9742994	Mount, Tiered
6	3379644	Tube, Connector
7	9742997	Holder, Water Inlet Funnel
8	9743210	Funnel
9	9743473	Connector (Includes Items 13, 14 & 15)
10	9742950	Feed Tube Assembly
13	9743475	Washer
14	9740848	Screw
15	9743474	Gasket, Connector
16	9742953	Seal, Tube
17	9743194	Mount, Top Upper Sprayarm

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# TUB AND FRAME PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TUB AND FRAME PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
 (Black) (White) (Almond)


<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	9743798	Tub Assembly
3	9743590	Door Seal
4	9742788	Plug Tub (2)
5	9743468	Wheel & Mount Assembly (Also Order Item 6)
6	9743002	Gasket, Bracket Mounting
7	3378056	Tub Stiffener
8	3400003	Screw (8)
9	9743149	Rear Support Assembly
10	343641	Screw
11	9742610	Connector Tub To Brace
12	90767	Screw (2)
13	304392	Screw
14	3370389	Screw (2)
15	302819	Wheel Leg
16	3376439	Leveler, Leg
17	9743488	Spacer, Tank – RH
18	9743489	Spacer, Tank – LH
19	3378131	Terminal Box
20	3369138	Screw
21	300068	Cover, Terminal Box
22	3400014	Screw
23	3378128	Washer
24	3370307	Strain, Relief
25	9743460	Trim Strip, Tub
26	304666	Retainer, Push (2)
27	9742789	Corner Trim, Tub
28	9742661	Shield, Sound Tub
29	9742648	Bracket, Thermostat
30	3371618	Thermostat
31	9742722	Strike, Latch
32	9743406	Pad, Friction
33	3370225	Screw, Ground

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# PUMP AND MOTOR PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)

Note: The Pump Gasket Must Be Replaced Anytime The Pump Assembly Is Removed And Reinstalled In The Dishwasher.



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# PUMP AND MOTOR PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9740982	Plate, Perforated (Also Order Item 30) See Note A.	17	9743202	Pump & Motor Assembly (Includes Item 16)	27	3368270	Slinger (Also Order Item 30) (See Note A.)
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.	18	302707	Bushing, Grind	28	3379364	Motor & Fan (Assembly) (Includes Item 27) (Also Order Item 30) See Note A.
3	9741232	Screw	19	302718	Chopper Kit (Also Order Item 30) See Note A.	29	3369331	Screw (4)
4	302710	Seal, Inlet Base	20	3378139	Sleeve, Drain Impeller	30	675703	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
5	302709	Ball, Check	22	302704	Seal, Drain Cover	31	303918	Tool, Pump Centering
6	95080	"O" Ring	23	3378207	Cover, Drain (Also Order Item 30 & 40) See Note A.	32	356138	Clamp, Hose
7	719929	Ball, Check (2)	24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.	33	3374077	Hose, Drain
9	9742968	Filter Assembly	25	3376157	Base, Pump (Also Order Item 30) See Note A.	34	3371748	Cap, Drain
10	3400001	Screw	26	3367197	Support, Pump Mounting (4)	35	3374757	Shaft, Absorber
11	303510	Impeller, Wash (Includes Items 12 & 13)	36			36	3378202	Weight, Absorber
12	3371152	Screw & Seal,	37			37	3378083	Thermostat
13	302711	Seal, Pump Outlet	38			38	3376723	Seal, O-Ring
14	9742973	Outlet, Pump (Includes Item 13)	39			39	3376358	Retainer, Thermostat
15	3369482	Check Valve (Includes Item 6)	40			40	9740674	Gasket, Drain Cover
16	717000	Gasket, Pump						

**NOTE A:**

Pump Centering Tool Required  
For Pump Re-Assembling—  
Order Item 31.

# UPPER RACK AND TRACK PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)





Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3380949	Dishrack, Upper (Also Order Item 3)	7	9743017	Clip, Tine Row (5)	14	3377604	Holder, Stemware (2)
3	9742983	Wheel & Bearing Assembly (4)	8	3377429	Tine Row	15	9743018	Positioner
4	9743016	Pivot, Upper Tine Row (2)	9	3377419	Cupshelf	16	3377464	Clip, No Flip (4)
6	9742998	Track, Rack (2)	10	9743019	Clip, Cupshelf	17	9742999	Protector, Sprayarm Guard
			11	3377443	Tine Row, Upper (Multi Position)	18	9743010	Handle, Dishrack Front
			12	3377439	Tine Row, Upper Mini	19	9743011	Handle, Dishrack Rear
			13	3379941	Track Stop (4)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LOWER RACK PARTS

For Models: KUDS24SEBL3, KUDS24SEWH3, KUDS24SEAL3  
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	9743501	Lower Rack Assembly (Includes Item 3)
2	9743048	Cover Basket Silverware
3	9743007	Wheel Assembly (2) Lower Rack (8)
4	9743574	Basket Half, Silverware
5	9743536	Extension, Side Wall
6	9743548	Flexrow (2)
7	9743534	Clip, Flexrow (6)
8	3377419	Cupshelf
10	9743019	Clip, Cupshelf (3)
11	3368629	Retainer, Flexrow (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

