



FRAME AND CONSOLE PARTS


For Models: MDB4621AWB0, MDB4621AWW0, MDB4621AWS0

(Black)

(White)

(Stainless)

UNDERCOUNTER
DISHWASHER



Illus. No.	Part No.	DESCRIPTION
1	8535436	Literature Parts Instructions, Installation
	3367007	Instructions, Installation (Supplement) (Locating Your Water Supply)
	W10102584	Guide, Use & Care
	8535431	Tech Sheet English/French
	W10102582	Guide, Energy
3	W10039780	Control, Electronic
4	3376359	Fuse, Thermal

Illus. No.	Part No.	DESCRIPTION
6		Console (Includes Insert & Active Overlay)
	W10102617	Black
	W10102618	White
	W10102619	Stainless
8	9743028	Door Frame
	3380854	Black
9	3380854	Bolt, Latch
10	3380778	Lever, Latch
	3380779	Black
	3380779	White
11	3369325	Switch, (2)
12	3368955	Pin, Switch (2)

Illus. No.	Part No.	DESCRIPTION
13	8573190	Harness and Protector
14	3376405	Elbow, Harness
15	3400892	Screw
16	8051304	Cover, Timer
17	3374501	Motor, Dual
19		Panel, Front
	3379375	Black
	3379376	White
22	3379358	Spring, Door Catch
23	3379357	Catch, Door
26	3373234	Bearing, Spring (2)

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.


INNER DOOR PARTS

For Models: MDB4621AWB0, MDB4621AWW0, MDB4621AWS0

(Black)

(White)

(Stainless)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3371435	Door, Inner (Includes Items 2 & 3)	4	3369505	Actuator Assembly	10	8066018	Spring, Lid
2	3376066	Latch, Detergent Dispenser (Includes Item 3)	5	8052028	Wet Agent, Dispenser	11	3372028	Pin (Lid Hinge)
3	3369061	Snap, Detergent Dispenser (Includes Item 2)	6	3379673	Seal, Door Vent	12	3371710	Screen, Vent
			7	3369448	Draw Bar, Electronic	13	3378134	Cap, Wet Agent
			8	3368999	Spring (Draw Bar)	15	3400815	Screw (8)
			9	3378138	Lid Assembly	16	3371569	Cover, Drip
						19	3379674	Vent Assembly (Includes Item 6)
						20	8271325	Absorber, Sound

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.


TUB ASSEMBLY PARTS

For Models: MDB4621AWB0, MDB4621AWW0, MDB4621AWS0

(Black)

(White)

(Stainless)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

TUB ASSEMBLY PARTS

For Models: MDB4621AWB0, MDB4621AWW0, MDB4621AWS0

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10082658	Tub Assembly	18	661566	Thermostat, Hi-Limit	36	302868	Screw, 8-18 x 1/2 (4)
2	8528831	Tub, Wheel Assembly (8)	20	301958	Clamp	37	3369414	Hose, Inlet
3	3368933	Runner (2)	23	3400935	Clip	40	8573243	Sound Shield, Tub
4	3374849	Leveler (2)	25	304231	Screw, 8-18 x 1/2	41	8573951	Terminal Box
5	3370389	Screw, Shoulder (2)	28	3379383	Spring, Door (2)	42	300068	Cover Assembly, Terminal Box
6	302819	Wheel (2)	29	8318218	Housing, Float Switch	50	3378595	Bracket, Thermostat
7	343641	Screw, 10-16 x 1/2 (4)	30	3369067	Switch, Float	53	3379740	Support, Heater
8	3378149	Plate, Latch	31	8318219	Cover, Switch Housing	54	3400014	Screw
9	3374720	Screw	32	8519587	Float & Washer Assembly	55	3378128	Washer
10	3376927	Gasket	33	717488	Nut	57	3369138	Screw, 8-18
11	8573061	Strain Relief	34		Panel, Toe (Includes Item 26)	61	8052018	Friction Pad
12	8528862	Deflector (2)		3368942	Black	62	3369816	Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)
13	8519830	Heater (Includes Item 14)		9742861	White			
14	717273	Washer, Rubber (2)		8054181	Biscuit			
15	8268548	Nut (2) (Heater Terminal)	35		Panel, Access			
16	8283345	Water Valve		3379387	Black			
17	304392	Screw, 8-18 x 1/2		3379388	White			
				9743560	Stainless			

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

PUMP AND MOTOR PARTS


For Models: MDB4621AWB0, MDB4621AWW0, MDB4621AWS0

(Black)

(White)

(Stainless)

Note: The Pump Gasket Must Be Replaced Anytime The Pump Assembly Is Removed And Reinstalled In The Dishwasher.



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

PUMP AND MOTOR PARTS

For Models: MDB4621AWB0, MDB4621AWW0, MDB4621AWS0

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9740982	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.	16	661633	Gasket, Pump	28	8534971	Motor & Fan Assembly (Includes Item 27) (Also Order Item 30) See Note A.
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.	17	8283498	Pump & Motor Assembly (Includes Item 16)	29	8281183	Screw (4)
3	9741232	Screw, 8-18 x 5/8	19	3378175	Chopper Kit (Also Order Item 30) See Note A.	30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
4	302710	Seal, Inlet Base	22	302704	Seal, Drain Cover	31	303918	Tool, Pump Centering
5	302709	Ball, Check	23	3376845	Cover, Drain (Also Order Item 30) See Note A.	32	356138	Clamp, Hose
6	95080	"O" Ring	24	8274950	Impeller, Drain Kit (Also Order Item 30) See Note A.	33	3374077	Hose, Drain
7	719929	Ball, Check	25	3376157	Base, Pump (Also Order ITEM 30) See Note A.	34	3371748	Cap, Drain
9	3384593	Filter Assembly (Includes Items 12, 13 & 22) See Note A.	26	3367197	Support, Pump Mounting (4)	37	3378083	Thermister
10	3400001	Screw	27	3368270	Slinger (See Note A.)	38	3376723	Seal, O-Ring
11	3378176	Impeller, Wash (Includes Items 12 & 13)				39	3376358	Retainer, Thermostat
12	3371152	Screw & Seal 10-32 x 3/4				40	9740674	Gasket, Drain Cover
13	302711	Seal, Pump Outlet						
14	3376844	Outlet, Pump (Includes Item 13)						
15	3369482	Check Valve (Includes Item 6)						

NOTE A:
Pump Centering Tool Required
For Pump Re-Assembling
Order Item 31.

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.


UPPER DISHRACK AND WATER FEED PARTS

For Models: MDB4621AWB0, MDB4621AWW0, MDB4621AWS0

(Black)

(White)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8268838	Support, Arm (Also Order Items 2 & 8)
2	303722	Clip
3	8268829	Spray Arm, Upper (Also Order Item 8)
4	3385142	Bumper (2)
5	8268862	Tower, Pressure
6	8268645	Wheel & Transport Assembly (4)
7	8539208	Dishrack, Lower
8	8268871	Support Lock, Spray Arm
9	8539107	Basket, Silverware
10	8539093	Lid, Basket
11	3376846	Seal, Lower Sprayarm
12	3385089	Track
13	8565920	Stop, Track (4)
14	8562003	Basket, Small Item
17	8268848	Wheel Assembly
18	8539222	Dishrack, Upper
22	8268874	Sprayarm, Lower
23	3367910	Cap, Nozzle
24	719576	Bearing, Nozzle

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

OPTIONAL PARTS (NOT INCLUDED)

For Models: MDB4621AWB0, MDB4621AWW0, MDB4621AWS0

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
<u>ACCESSORIES</u>		
		Side Panel Kits
	4378867	White
	4378868	Black
	675788	Biscuit
	4378869	Almond
		Custom Trim & Panel Kits
	675775	Black
	675776	White
	675809	Biscuit
		Moisture Barrier Kit
	4396277	Kit
		Drain Hose
	3385556	12 Ft.
		Heavy Duty Spring Kit
	4318050	Spring
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	72032	Black
	4392899	Biscuit

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		
	350930	White
	285006	Superior Black
	4392901	Biscuit
<u>PAINT, TOUCH-UP (1 qt.)</u>		
	799344	White (Uncut)
	4392900	Biscuit
<u>POWER CORD KIT</u>		
	4317824	Power Cord Kit (Includes Power Cord & Misc. Hardware)

Illus. No.	Part No.	DESCRIPTION
<u>ANTI-TIP KIT</u>		
	4378968	Floor Mounting Kit
<u>DISHRACK REPAIR</u>		
		Tip Tine Repair Kit (Enough for Two Complete Dishracks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		Vinyl Touch-Up (4 oz.)
	676453	White
	676455	Grey
	4396853	Silver Atlantis

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.