

## **DOOR AND PANEL PARTS**

Whirlpool For Models: DU1100XTPB3, DU1100XTPQ3, DU1100XTPT3, DU1100XTPS3 (Black) (White) (Biscuit) (Stainless)


UNDERCOUNTER DISHWASHER



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
ı	8535437	Instructions.
	0000 101	Installation
	8535642	
	8535541	Guide, Use & Care
		Tech Sheet
_	8535451	English/French
2	0504050	Arm, Hinge
	8534858 8534857	
3	8268983	
3	0200303	Door
4		Panel Front
	8269841	Black
	8269842	White
	8269844	
_	8269845	Stainless
5	8543834	Access Panel
	8543835	
	8543836	
6	8268580	
8		Toe Panel
	8268999	
	8269000	
0	8269001	
9 12	8269740	Clip, Grounding Screw
12	302868	
	3400836	
	3400865	
13	343641	
15	3369181	Screw




## **CONTROL PANEL PARTS**





Illus. No.	Part No.	DESCRIPTION
1		Console Asm. (Includes Active Overlay & Insert)
	8535523 8535524	Black White
4	8535525 8283512	Cover Control
5 6	8524471 8269213	Shield Assembly Actuator, Latch Fuse, Thermal
7	3400412	Electronic
8 9	3369051	Handle, Latch
	8534984 8534985	White
10	8534986 8524476	Bolt, Latch
11	8564544	Control, Electronic
12	8269209	Switch, Door

## **DOOR AND LATCH PARTS**



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 3	3369051 8269311	Screw, Door Inner Door	7	8542566	Deflector, Vent (Also Order	12	8537823	Wiring Harness Main
Ū	0200011	(Also Order Item 6)	8	0521025	Item 6) Dispenser,	13 14	8281154 8269296	Screw
5	8542603	Vent Assembly (Also Order			Assembly			Console/door
		ltem 6)	9	8269258	Seal, Front	15 16		Bracket, Dispenser Shield, Dispenser
6	8269259	Gasket, Vent				17		Cap, Rinse Aid






Illus. No.	Part No.	DESCRIPTION
		_
1	8268333	Wash Arm Assembly
2	8268317	Cap, Internal
		Rear Feed
		(Also Order
		Ìtem 3)
3	8268340	Seal, Śprayarm
4		Hub, Lower
		Sprayarm
		(Also Order
		Ìtem 3)

## **HEATER PARTS**


For Models: DU1100XTPB3, DU1100XTPQ3, DU1100XTPT3, DU1100XTPS3 (Black) (White) (Biscuit) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	8572861	Heater Element Assembly (Also Includes Item 2)
2	717273	Washer, Heater Element
3	8268548	Nut, Heater Element
4	8269262	


**NOTE:** If heater element is removed, it must be replaced.

### FILL AND OVERFILL PARTS






Illus. No.	Part No.	DESCRIPTION
1	8268607	Tub Assembly
3	8268888	,
5	8531022	Drain Loop
		With Check Valve
8	8533836	Screw (8)
10	3367670	Screw `
11	8269145	Bracket,
		Undercounter
15	8269831	Wheel Leg
16	8524584	
18	8524473	
		Balance
19	8270016	Wheel & Mount
00	0.400000	Assembly
20 21	3400892	Screw
۷۱	8268991	Cover, Terminal Box
23	8268961	Pad, Friction
26 26	304231	Screw
27	8269016	Clip, Grounding
28	8531032	Shield, Sound
20	0001002	Tub
29	3378595	Bracket.
		Thermostat
30	661566	Thermostat
31	8269111	Strike, Latch
32	9741232	Screw
33	8268990	Bushing, Door
		Spring
34	3378128	
35	3400014	
46	8542575	
48	356138	, ( )
50	8269297	Miscellaneous
		Parts Bag
		(Includes 2 Screws
		& 2 Hose Clamps)




## **PUMP AND MOTOR PARTS**

Illus. No.	Part No.	DESCRIPTION	
1	8534952	Accumulator Assy	
	8283527	Shield, Motor	
2 3 4	3400069	Screw	
1	8534882	Sump With Seal	
5	8268375	Check Valve, Sump	
6	8268383	Chopper Assembly	
7	9741232	Screw	
8	8531857	Protector, Inlet	
10	8534942	Motor Assembly	
11	3400217	Screw	
12	8268391	Screen, Separation	
14	8535150	Sump & Motor	
17	0000100	Assembly	
15	8269524	Tab, Sump	
16	8533949	Nut	
17	661658	Pump, Drain	
18	8531019	Volute, Back	
10	0001013	(Also Order	
		Items 23 & 30)	
19	8269144	Hose, Drain	
20	8534941	Motor	
21	8268397	Seal, Volute	
22	8531017	Impeller Kit	
	0001017	(Also Order	
		Item 30)	
23	8268403	Face Seal Assembly	
	0200.00	(Also Order	
		Item 30)	
24	356138	Clamp, Hose	
25	8269208	Thermister	
26	8269507	Capacitor	
27	8534946	Shield,	
		Capacitor	
30	8531018	Washer	

### **UPPER RACK AND TRACK PARTS**







UPPER RACK AND TRACK PARTS
For Models: DU1100XTPB3, DU1100XTPQ3, DU1100XTPT3, DU1100XTPS3
(Black) (White) (Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION
1	8539214	Dishrack, Upper
2	8268655	Mount, Wheel
3	3385089	Track, Rack
4	8524581	Stop Track

### **UPPER WASH AND RINSE PARTS**



### LOWER RACK PARTS



### **OPTIONAL PARTS (NOT INCLUDED)**

For Models: DU1100XTPB3, DU1100XTPQ3, DU1100XTPT3, DU1100XTPS3 (Black) (White) (Biscuit) (Stainless)

Illus. Part

No. No. DESCRIPTION

### **ACCESSORIES**

SIDE PANEL KITS
8171656 White
8171657 Black
8171658 Biscuit
8171659 Stainless Steel
Custom Panel Kits
4396199 Black
4396200 White
4396201 Biscuit
Cabinet Seal Kit
8269110 Seal, Kit

### PAINT, TOUCH-UP (1/2oz.)

72017 White 72032 Black 4392899 Biscuit

# PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White 285006 Superior Black 4392901 Biscuit

### PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit

### **POWER CORD KIT**

4317824 Power Cord Kit (Includes Power Cord & Misc. Hardware)

### **ANTI-TIP KIT**

4396194 Floor Mount Kit