


Upgrade instructions

Step 1.

If you are just taking the DVD-HD841 out of the box, please connect the unit to your TV using the Composite video connection, see Figure 1. If you have already connected the unit to your TV and have successfully configured the DVI output prior to this upgrade, skip to Step 2.

DVD-HD841 Upgrade Instructions

Reason for upgrade: Samsung has issued this upgrade to simplify the DVI output setup procedure. After this upgrade is performed, the DVD-HD841's DVI output will be enabled automatically when a DVI cable is connected between the DVD-HD841 and a TV.



Step 2.

Open the Disc Tray by pressing the open/close button, then insert the software Upgrade disc.
Close the Disc Tray.




Figure 2

After the disc loads, you will then see the upgrade screen shown in Figure 3. The word "Total" will be highlighted.



Figure 3

Step 3.

Using the DVD-HD841 remote control, press the "Enter" button located in the center of the remote.




Figure 4

"Now Loading" will be displayed on the screen, see Figure 5.

Step 4.

The Disc tray will eject automatically after approximately 15 seconds. Remove the disc from tray. Do not turn off unit until Disc tray closes, as the unit is still upgrading the software. The Disc tray will close automatically in 1-2 minutes. Power off the unit using the front power button and then power on the unit, this completes the upgrade.



Figure 5

The new software will automatically switch to DVI output when a DVI cable is connected to the rear panel of the DVD player.

Congratulations!

Your Samsung DVD-HD841 is now loaded with the latest upgrade available. The new software will automatically switch to DVI output when a DVI cable is connected between your DVD-HD841 and your TV.

If you are having difficulty with this upgrade please feel free to contact our Customer Support Center at **1-800-SAMSUNG** and a Samsung Support Specialist will be happy to assist you.