



SNH-1011N English

Quick Start Guide

Thank you for purchasing the Samsung SmartCam Wifi Home Security Camera. Follow the simple steps in this guide to set up and start using your new SmartCam.



HELP If you have any questions or need help installing your new product please contact our free technical support.

Telephone : 1-877-349-3149


9am - 9pm EST, Monday - Friday

Internet : <http://www.samsungsv.com/Support/Index>

Related manual can be downloaded from https://www.samsungsmartcam.com/web/pages/main_support.jsp.

UNPACKING

Make sure all following items are in the packaging:



1 Save the packaging for later use. You will need the serial number found on the side of the packaging.



CONNECTING THE CAMERA TO YOUR ROUTER


1. Connect the power adapter to the camera.
2. Connect the network cable to the camera and your network router.
3. The camera bootup will take about 1 minute then the camera status LED will change from red to green.
 - 1** For proper networking to a Wi-Fi router with using the router's WPS function, refer to the router's manual and the product's user manual available on the web page.



SETTING UP YOUR ACCOUNT

1 The subscription and camera registration explained below can be made on your smartphone too. Refer to the "iPhone" or "Android" section of <Support> on the product web site.

1. From your PC, go to <http://www.samsungsmartcam.com>.
2. Select <Sign Up> to register. After reading the terms of use, check "I Agree...", and click <Next>.
3. Enter requested information, and click <Sign Up>.



ADDING YOUR CAMERA

1. From your PC, go to <http://www.samsungsmartcam.com>.
2. Enter your SmartCam account username and password and <Login>.



3. Enter your camera Serial Number and click <Check>.
4. Create a private key (Password) for the camera. Use 1 to 8 alphanumeric characters.
5. Create a name for the camera. I.e., Home And click <Add>.
6. Click camera icon in the camera list.




7. Enter the Private Key for the camera and click <OK>.
 - 1** If you forget your Private Key, you must reset the camera. Refer to the full manual for details.
8. View your camera. You will be asked to install the web viewer plug-in to view the video for the first time. After installation, please restart the browser and login again.



CONNECTING TO YOUR WIFI NETWORK

1. Click <Setup>.
2. Click <Network Setting>.



3. Click <Wireless Network>.
4. Select <Wireless On> then select your wifi network. If your network is hidden, select <Other Wifi Networks>.
5. Enter the password for your wifi network and click <Apply> then in the popup, click <OK>.
6. Disconnect the network cable from the camera and the wireless router.





1 The camera status LED will flash blue then turn steady green after about 20 seconds. You can now unplug the camera and place anywhere around the home within the WiFi range. If it continues to flash blue, a wifi connection has not been established. Please contact our tech support at 1-877-349-3149

SETTING UP NOTIFICATIONS

YouTube

Automatically uploads 30 second clip to your private YouTube account.

1. Click the <Video> tab.
2. Click the <Youtube> tab.
3. Select <Enable>.



4. Enter your YouTube User ID and Password.

5. Click <Apply>.

1 If you do not have a YouTube account, please go to YouTube.com and register an account.
The recorded videos are 30sec clips.

Picasa

Automatically uploads a image to your private Picasa account.

1. Click the <Picasa> tab.

2. Select <Enable>.

3. Enter your Picasa User ID and Password.
Your Picasa account info is the same as your YouTube account info.

4. Click <Apply>.

MyFriends

1. Click the <MyFriends> tab.

2. A list of users that will receive the notifications is listed. Select <Enable>.

3. Click <Apply>.

Twitter

Get message notification to your Twitter account when event is detected.

1. Click the <Twitter> tab.

2. Select <Enable>.

3. Click <Request URL>.

4. Click <Move>.

5. Enter your Twitter User ID and Password.

6. Click <Authorize app>.

7. Write down the Access Token then click <Go to the SAMSUNG SmartCam homepage>.

8. Return to the <Twitter> tab and enter the Access Token.

9. Click <Apply>.

1 If you do not have a Twitter account, please go to Twitter.com and register an account.

E-mail

1. Click the <E-mail> tab.

2. Enter your outgoing server address.

1 Refer to the full manual for the E-mail server information.

3. Enter your email server ID, Password and Sender information.

1 Many people use their name or the camera name as sender information.

4. Enter an email address where you want the notification to go and click <Add>.

5. Click <Apply>.

ENABLING NOTIFICATION

1. Click <Setup>.

2. Select <General Setting>.

3. For motion detection, under Motion select <On>.

4. Adjust Sensitivity.

For audio detection, under Audio select <On>.

5. Under Activation time, select <Scheduled>.

6. Select the times that you would like detection to be on.


7. Click <Apply>.

8. Select <Time Setting>.

9. Select your time zone under <Time Zone> then click <Apply>.

MONITORING FROM A SMARTPHONE

1. On an Android phone, visit Google Play Store and search Samsung SmartCam. On an iPhone, visit App Store and search Samsung SmartCam.



2. Click <FREE> to download the SmartCam app to your phone.



3. Click the SmartCam app on your phone.



4. Enter your SmartCam account User ID and Password, check <Remember me> and click <Login>.

5. Click your camera's name in the camera list.

6. Click <Live> to view your camera.

7. Enter the camera private key, check <SAVE> and click <OK>.

8. View your camera.



9. Click <HQ> for high quality streaming.
1 HQ mode is best viewed with a wifi or 4G connection.

PT01-001379A

