

THE SHARPER IMAGE®

Professional Series™
Ionic Breeze®
Quadra®

Silent Air Purifier
with
OzoneGuard™
SI857 Instructions

Ionic Breeze® cleans with
OzoneGuard™

ENGELHARD
PremAir® catalyst converts
ozone to oxygen.

SHARPER IMAGE DESIGN®

Read and save these instructions.



Table of Contents

| | |
|--|----|
| Warnings | 5 |
| Important Information - Please Read | 7 |
| Frequently Asked Questions about OzoneGuard™ | 8 |
| Setup and Operation | 9 |
| Cleaning the Collection Grid | 11 |
| Thorough Cleaning | 12 |
| Additional Information | 13 |
| Statement of FCC Compliance | 14 |

Warnings

Warning: To reduce the risk of fire, electric shock, or injury when using any electrical appliance, basic precautions should always be observed, including the following:

- This appliance operates at 110V AC and 50Hz or 60Hz only.
- Connect to a properly grounded outlet only.
- Use indoors only.
- Before unplugging the unit from the outlet, turn off all the controls.
- Do not unplug by pulling the cord. Grasp the plug itself, not the cord, when unplugging from an outlet.
- Do not handle the plug or appliance with wet hands.
- Unplug from outlet when not in use and before servicing.
- Do not allow the appliance to be used as a toy. Close attention is necessary when the appliance is operated near children.
- Use only as described in this user manual.
- Do not use if cord or plug appears to be damaged. If the appliance is not working properly, or has been dropped, damaged, left outdoors or dropped into water, return it to a service center or to the original place of purchase.

Warnings

- Do not pull, lift or carry by the power cord. Do not use the cord as a handle, close a door on the cord, or pull the cord around or against sharp edges or corners.
- Keep the cord away from heated surfaces.
- A damaged power cord must be replaced by qualified service personnel only. There are no user-serviceable parts inside the unit. Any attempt to open the unit will void the warranty and could lead to serious damage to the unit and/or personal injury to the user.
- Do not put any object into openings. Do not continue to use with any opening blocked. Keep all openings free of dust, lint, hair or anything that may reduce airflow.
- Keep hair, loose clothing, fingers and all parts of the body away from openings.
- Do not operate the unit in areas where flammable or combustible products or vapors may be present.

READ AND SAVE THESE INSTRUCTIONS

Important Information – Please Read

The collection grid has many edges and areas that can trap water. Ensure the grid is completely dry before re-inserting it into the unit. If it is not completely dry, the unit could be damaged. If water is used to clean the grid, please allow at least 24 hours for the collection grid to dry.

This unit should not be located near a fireplace, whether or not the fireplace is actually in operation. Dust and soot from the chimney could be rapidly drawn through the Ionic Breeze and deposited on or around the unit.

In rooms where candles or oil lamps are frequently burned, the smoke from these products will tend to stick to the outside of the Ionic Breeze. Avoid placing the Ionic Breeze in a location where it will be subjected to smoke from oil lamps or candles.

In any area where this product will be subjected to heavy pollution or smoke, it will be necessary to clean the collection grid more frequently.

If the unit begins to arc or make a “static-like” sound, turn the unit off, slide the collection grid out and slowly invert the unit several times. Replace the grid.

Frequently Asked Questions about OzoneGuard™

What does OzoneGuard™ do?

With the OzoneGuard in place, a significant portion of ground-level ozone inside the air purifier — including any trace levels of ozone by-product — is converted into oxygen before the cleaned air circulates back into the room.

Why is the OzoneGuard™ smaller than the grill itself?

The majority of the air output is directed toward the center of the grill and therefore a larger OzoneGuard isn't necessary.

Does the Ionic Breeze still have the Negative-Ion Feature™ option?

Yes it does. The new OzoneGuard front grill does not affect the popular Negative-Ion Feature of the *Professional Series*™ Ionic Breeze® air purifiers. An emitter at the bottom of the new grill has replaced the ionizing wires inside the original grill. The feature itself works the same way as before.

Please read this product instruction manual for important safety information and operating instructions.

Setup and Operation

To reduce the risk of electric shock, this equipment has a grounding-type plug that has a third (grounding) pin. This plug will only fit into a grounding-type power outlet. If the plug does not fit into the outlet, contact qualified personnel to install the proper outlet. Do not alter the plug in any way.

Place Ionic Breeze on a level surface, at least twelve inches from the wall and furniture. Plug into a grounded 110V outlet. (Read warnings for details.)



Switch the **MODE CONTROL** to the desired setting:

SMALL: For small rooms or rooms where the door is usually closed.

MEDIUM: For average sized rooms.

LARGE: For large rooms and higher traffic areas.

These are recommended settings. Adjust to your own comfort level.



Setup and Operation



Normal operation at all power levels involves a programmed cycle of altering high and low air movement.

To override the power control setting and let the unit run at maximum power for five minutes, press **BOOST/IONS** until the button turns blue.

Your previously selected power level resumes after the five minutes has elapsed.

To activate the Negative-Ion Feature, press **BOOST/IONS** until the button turns green. This feature adds millions of negative ions to the airflow to freshen your indoor environment. To cancel, press the button again.

Note: Use of this feature increases negative-ion output and may increase soot buildup near the product.



Cleaning the Collection Grid

Clean the grid every one or two weeks. As a reminder, the cleaning indicator light will turn green after two weeks. If the cleaning indicator light turns red, the unit has shut down because of excessive dirt or circuitry problems. In many cases, a thorough cleaning will return the unit to normal operation.




Before cleaning, unplug the unit.

Remove the collection grid by releasing the latch and pulling the grid from the top of the unit.

Use a dry or slightly damp towel or sponge to quickly wipe the dust from each of the three collection bars.

Before replacing the grid, invert the entire unit two or three times.

Collection Grid
Release Latch



Thorough Cleaning

If the unit makes noise during operation, a thorough cleaning of the grid, grills and internal ionizing wires may be required.

Unplug the unit before cleaning.

Release the OzoneGuard front grill and back grill by lifting the blue release tabs on the bottom of the grills.

To remove, slide the grill up.

Note: The OzoneGuard cannot be detached from the front grill.

The OzoneGuard has sharp edges; use caution when cleaning.

Use a hair dryer to blow dust from the interior, or a vacuum to remove the dust.

The grills can be cleaned under a spray of warm water. Rinse and **allow to dry** before returning to unit.

CAUTION: Do not use the product if wires are broken or either grill appears damaged.

Call 1-800-344-5555 to order a replacement grill.



Release-Tab

Additional Information

The exterior of the unit can be cleaned using a cloth or sponge and a solution of one part household bleach to five parts water or any bleach-based spray cleaner.

Before plugging the unit back into an outlet, allow the surface to dry completely.

The unit will not function while the collection grid is removed or either of the grills are removed.

The majority of collected particles will gather on the removable stainless steel grid. Over time, debris will accumulate inside the unit. Remove the front and rear grills to access the inside. (See section titled “Thorough Cleaning.”)

The Ionic Breeze[®] complies with U.S. safety standards for low ozone emission (less than 50 parts per billion). We recommend that individuals with a history of respiratory disease consult with their doctor about possible heightened sensitivity to very low ozone.

Statement of FCC Compliance — Model SI857

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Statement of FCC Compliance — Model SI857

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for assistance.

Full Five-Year Warranty

What Is Covered

This warranty covers any defects in materials or workmanship, with the exceptions stated below.

How Long Coverage Lasts

This warranty runs for five years from the date of original purchase.

What Is Not Covered

This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, or loss or damage to batteries or removable parts.

What The Sharper Image Will Do

The Sharper Image will repair any defects in materials or workmanship. In the event repair is not possible, The Sharper Image will either replace this product with one of similar features and price, or refund the full purchase price of the product, whichever you prefer.

How to Obtain Service

Return the product and receipt, along with a brief explanation of the problem, to:

T.S.I. - Returns Department
2901-A West 60th Street
Little Rock, AR 72209

If you have questions please feel free to contact our customer service representatives at 1-800-344-5555 or by email at care@web.sharperimage.com.

This warranty gives you specific legal rights, and you may have other legal rights that vary from state to state.

© 2005 Sharper Image Corporation

Sharper Image Corporation
650 Davis St., San Francisco, CA 94111
(415) 445-6000

Shop online: **www.sharperimage.com**

Due to continuing improvements, actual product may differ slightly from the product described herein.

V1 09/05