

### A Easy Set Up Components

DVR4-1300 Unit

BNC to RCA Cable

Power Adapter Cable

DVR Power Adapter

Remote Control

Cameras and Accessories Optional

### C Connecting the DVR to TV

- 1 Connect the RCA end of the BNC to RCA cable to the back of the TV INPUT socket
- 2 Connect the BNC end of the cable to the top VIDEO INPUT socket on the back of the DVR
- 3 Tune your TV to the correct INPUT - this is sometimes labelled A/V, input, source, L1, L2, etc. - consult TV manual for details

### B Camera Connections

- 1 Connect the camera cable's BNC socket & DC socket to the BNC plug & DC plug on the extension cable.
- 2 Connect the other end of the BNC plug of the extension cable to the camera connections on the back of the DVR.
- 3 Connect the DC power sockets on the extension cables to the power splitter's DC plugs.
- 4 Connect the power splitter's DC socket to the DC plug on the power supply.
- 5 Plug in the DVR and camera power adapter to power outlets.