



MODEL# SVMR, SVMB

Stinger voltmeter, 3-digit display w/ turn-on circuit

Wiring Schematic

- Red (power)** - wire to +12V constant source at location of desired reading
- Black (ground)** - wire to chassis ground
- Blue (trigger)** - wire to a +12V switched source (ignition) or to radio remote turn-on

Cover Removal

depress both tabs located on either side to remove cover

Mounting Options



- Option 1** - can be secured by (2) mounting holes located under cover with supplied screws
- Option 2** - can be fastened by a piece of double sided tape
- Option 3** - can be custom mounted by two thin strips of double side tape on front cover then back mounted for a more custom look

Voltage Adjustment

test voltage at red and black wires on **SVMR /SVMB** with a small phillips or slotted screwdriver adjust meter to match reading from previous test.

counterclockwise - voltage increase

clockwise - voltage decreased



Stinger® 13160 56th Court Clearwater, FL 33760
Technical Support 800.477.2267 ext. 230
stingerelectronics.com