
FILTER REPLACEMENT INSTRUCTIONS - 4000,5000,6000 & 8000 SERIES

AllerAir Industries Inc. Toll Free: 1888-852-8247 Fax: 1-877-688-2193 www.allerair.com


REPLACE THE PRE-FILTER



STEP 1


Make sure the unit is set to "off" and the unit is **unplugged**. Lay the unit on its side.

REPLACE CARBON & HEPA FILTERS



STEP 2

Slowly remove the dirty filter to avoid dispersing its contents. Gently insert it into a plastic bag before discarding.



STEP 3

Insert the new filter by pressing it gently against the sides of the carbon filter inside the unit These replacement filters will extend the life of your AllerAir unit. Please be sure to follow the instructions for changing the filters in your unit.

We recommend changing prefilters every two months, HEPA filters every three to five years, and carbon filters every two years.



STEP 1

Make sure the unit is set to "off" and the unit is **unplugged**. Lay the unit upside down, so that the wheels face up.




STEP 5

First, **remove the carbon filter**. (pull up gently by placing thumbs on the inner side of the filter)



Step 9 Put back the felt pad removed in **STEP 4.**




STEP 2

Using a #2 Philips screwdriver, remove the four screws that hold the base onto the unit.



STEP 6 Then, **remove the HEPA filter** with the same technique.



Step 10 Replace the base, making sure the arrow on the gold sticker lines up with unit's rear seam.




STEP 3

Grasp the wheels. Remove the base by pulling gently on the wheels



STEP 7 Now, gently insert the new HEPA filter.



Step 11 Replace the four screws.



STEP 4

Reach inside the unit, and remove the felt pad.



STEP 8

Then, **insert the new** carbon filter into the unit.



Step 12 Turn the unit back onto its wheels. It is now ready for use.