# **About This Manual**

The user manual provides information for configuring the features of the NETGEAR® 5 GHz Wireless-N HD Access Point/Bridge WNHDE111 beyond initial configuration settings. Initial configuration instructions can be found in the . You should have basic to intermediate computer and Internet skills.

## **Conventions, Formats, and Scope**

The conventions, formats, and scope of this manual are described in the following paragraphs:

• Typographical conventions. This manual uses the following typographical conventions:

Italic	Emphasis, books, CDs	
Bold	User input, GUI screen text	
Fixed	Command prompt, CLI text, code	
Italic	URL links	

• Formats. This manual uses the following formats to highlight special messages:





**Tip:** This format is used to highlight a procedure that will save time or resources.



**Warning:** Ignoring this type of note might result in a malfunction or damage to the equipment, a breach of security, or a loss of data.



**Danger:** This is a safety warning. Failure to take heed of this notice might result in personal injury or death.

• **Scope**. This manual is written for the Wireless-N AccessPoint/Bridge according to these specifications:

Product Version	5 GHz Wireless-N HD Access Point/Bridge WNHDE111
Manual Publication Date	May 2008

For more information about network, Internet, firewall, and VPN technologies, click the links to the NETGEAR website in Appendix B, "Related Documents."



**Note:** Product updates are available on the NETGEAR, Inc. website at *http://www.netgear.com/support*.

#### How to Use This Manual

The HTML version of this manual includes the following:

- Buttons, > and < , for browsing forward or backward through the manual one page at a time.
- A <u>set</u> button that displays the table of contents and an <u>button</u> button that displays an index. Double-click a link in the table of contents or index to navigate directly to where the topic is described in the manual.
- A *intersection* button to access the full NETGEAR, Inc. online knowledge base for the product model.
- Links to PDF versions of the full manual and individual chapters.

## How to Print This Manual

To print this manual, you can choose one of the following options, according to your needs.

• **Printing a page from HTML**. Each page in the HTML version of the manual is dedicated to a major topic. Select File > Print from the browser menu to print the page contents.

- **Printing from PDF**. Your computer must have the free Adobe Acrobat Reader installed for you to view and print PDF files. The Acrobat Reader is available on the Adobe website at *http://www.adobe.com*.
  - **Printing a PDF chapter**. Use the **PDF of This Chapter** link at the top left of any page.
    - Click the **PDF of This Chapter** link at the top left of any page in the chapter you want to print. The PDF version of the chapter you were viewing opens in a browser window.
    - Click the print icon in the upper left of your browser window.
  - Printing a PDF version of the complete manual. Use the Complete PDF Manual link at the top left of any page.
    - Click the **Complete PDF Manual** link at the top left of any page in the manual. The PDF version of the complete manual opens in a browser window.
    - Click the print icon in the upper left of your browser window.



**Tip:** If your printer supports printing two pages on a single sheet of paper, you can save paper and printer ink by selecting this feature.

### **Revision History**

NETGEAR, Inc. is constantly searching for ways to improve its products and documentation. The following table indicates any changes that might have been made since the Wireless-N AccessPoint/Bridge was introduced.

 Table 2-1.
 Publication Revision History

Part Number	Version Number	Date	Description
202-10300-01	v1.0	January 2008	First publication.
	v1.1	May 2008	Revised to reflect full product feature set.