



You can wear your Deluxe Carry Case anywhere! Put it on over your left or right shoulder as illustrated:


RIGHT SHOULDER



LEFT SHOULDER



Use the adjustable strap to loosen or tighten the Deluxe Carry Case to your body. Snap the clip together and get movin'!



NOTE: Store only your **VIDEONOW** Color Player and accessories in the appropriate locations in the Deluxe Carry Case in order to minimize the risk of scratching the LCD screen.



TIGER
ELECTRONICS
Where Technology Comes to Play!™



Questions? Call 1-800-327-8264

© 2004 Hasbro. All Rights Reserved.
® denotes Reg. U.S. Pat. & TM Office.
73987 P/N 6352350200

73987

AGES 6+

VIDEONOW™

COLOR

Deluxe Carry Case

Thank you for purchasing the **VIDEONOW** COLOR Deluxe Carry Case. Be sure to read and follow all instructions carefully before using this product.

The **VIDEONOW** Color Deluxe Carry Case is a stylish way to store and carry all of your favorite **VIDEONOW** accessories with your player!

Each accessory (sold separately) has its own storage place inside the case!

