

VENOM™ MASK & WRIST BLASTER
Be just like the spider-stalking VENOM!

CAUTION:
Do not aim at eyes or face.


WARNING:
Pressurized container. Read all instructions before use.

Thank you for purchasing the VENOM Mask & Wrist Blaster.
Please read and retain these instructions.

IMPORTANT! Please read all instructions before wearing this toy!

Includes:

- Web Blaster
- One 5 oz. (142 grams) Web Fluid canister
- VENOM Mask




VENOM MASK:

Adjust mask using hook and loop fastener on rear strap. Mask should fit snugly over top and back of head so that it does not move around too much during use.



Tongue/lower jaw should be tucked under chin.




WEB BLASTER ASSEMBLY & USE:

- 1 Rotate back part of nozzle (not the gear) until the D shaped opening in the nozzle shows red dot on can.




- 2 Slide can into Blaster Housing with red dot facing up. Can will snap into place.




3

Place Web Blaster on forearm and fasten touch fastener straps.




Use middle fingers to press down on trigger to shoot web.



4

To remove can, press Lock Button and pull out can.




For Best Performance:

- Keep Web Fluid at room Temperature
- Shake Can very well before each use
- Make sure the red mark on the top ring of the can is facing up
- Aim can slightly up from horizontal for best performance

If Web Fluid is not shooting very far, shake can again.

If Web Fluid is not coming out, make sure the nozzle is clean. To clean the nozzle, pull the gear assembly off of the can. Clear Web Fluid away from plastic nozzle, and inside of gear. Snap gear assembly back onto can.



WARNING: Contents Under Pressure.

Do Not Puncture Or Incinerate.

Do Not Expose to Heat or Store at Temperatures above 120° Degrees F / 48 Degrees C.

- Do Not Spray on Open Flame or Any Hot Stoves or Light Bulbs.
- Do Not Leave in Direct Sunlight or Store in a Hot Vehicle.
- Heat Can Cause Can to Burst Violently.
- Do Not Spray in Eyes or Face.
- Do Not Ingest String.

Shake well before using.

Can should be used in a horizontal position.

Adult Supervision Required.

Non-Toxic.

Non-Flammable.

Not Recommended for Indoor Use.



CAUTION: Do not spray on walls, floors, clothing, furniture or vinyl as string may stain certain types of surfaces and fabrics. USE ONLY AS DIRECTED.

Ingredients: Water HFC 134a (propellant), Acrylic Resin, Hydrocarbon solvents, Light oil, Pigment.



Not suitable for children under 3 years because of small parts — choking hazard.



Spider-Man and all related characters: TM & © 2007 Marvel Characters, Inc. Spider-Man movie elements: © 2002-2007 Columbia Pictures Industries, Inc. All rights reserved. Licensed by Spider-Man Merchandising L.P. ®* and/or TM* & © 2007 Hasbro. All Rights Reserved. TM & © denote U.S. Trademarks.

P/N: 6670540000