

MCE Remote Control with Netflix Function

RHRC-12001

User Manual

Thank you for purchasing a quality Rosewill Product.

Please register your product at: www.rosewill.com for complete warranty information and future support for your product.

INDEX

1. Introduction.	2
2. Appearance	2
3. Features.	3
4. Package Contents	3
5. System Requirements	3
6. Installation and Operation.	3
7. Specifications	5
8. Key Definition.	6
9. Use Media Center Remote Control with Netflix	9
10. Troubleshooting	10

Caution!

No part of manual may be reproduced or modified without our express written permission; otherwise the right of using the device will be cancelled.

Trademarks

Microsoft®, Windows®, Windows 8, Windows 7® and Windows Vista® are U.S. registered trademarks of Microsoft Corporation. IBM, DOS, and PC are registered trademarks of IBM Corporation. All brands, products and companies are trademarks of registered trademarks of their respective companies.

Notice

The information contained in this document is subject to change without notice. All rights are reserved. No part of document maybe photocopied, reproduced, or translated to another language, for any purpose, without our express written permission.

Introduction:

RHRC-12001 Media Center Remote Control with IR605/Q Receiver is your best solution to control the MCE on your Desktop or Laptop. It is compatible with Microsoft® Windows® MCE certification and Green Button regulation. The easy connection between RHRC-12001 and IR605/Q makes your entertainment more joyful.

Appearance:

Media Center Remote Control: RHRC-12001





Receiver: IR605/Q

Features:

RHRC-12001 Remote Control

- Microsoft® Windows® MCE certification and Green Button support
- With all of the buttons and functions necessary for Microsoft® certification, including official Green 2. Button.
- Small USB dongle style receiver 3.
- 4. Use standard Microsoft® drivers, no need to install drivers.
- 5. It could wake the system from S1 or S3
- 6. Infrared Rays Frequency: 38KHz; Infrared Rays transmission distance: 21 ft-33 ft

IR605/Q Receiver

- 1. Small USB dongle type Receiver and easy to connect with your computer.
- 2. Support one indication LED for the system level interaction: blink during working mode and turned off during sleep mode.
- 3. Use in-box Windows® drivers.
- 4. RC6, QP and MCIR key board protocols are supported
- 5. Receive the signal from MCE remote control or MCE key board using a normal IR receiver.
- 6. It can wake the system from sleep mode.
- 7. It consumes around 1.5mAin sleep mode.

Package Contents:


- Media Center Remote Controller (RHRC-12001) x 1 Intel® Pentium® 1GHz CPU or faster
- Receiver IR605/Q (USB Port) x 1
- User Manual
- AAA battery x 2
- USB extension cable x 1
- Installation CD (for one click to access Netflix feature)

System Requirements:

- 512MB RAM or above (1G recommended)
- Desktop or laptop computer running Windows 8 PRO, Windows®7 Home Premium, Professional or Ultimate or Windows® Vista Home Premium or Ultimate
- USB Port; PC platform
- Graphics card capable of DirectX9


Installation and Operation:

- 1. Battery Installation -- Open the battery cover of the Remote Control and install 2 AAA batteries correctly.
- 2. Receiver Installation -- Plugging IR605/Q Receiver (with USB Port on it) into the USB port of your computer.
 - If your package comes with a USB cable, you can use the USB cable to bridge between your USB port and the IR605/Q Receiver and then put the IR605/Q Receiver in front of you to get a better signal transmission.
- 3. Software Installation -- Insert the Installation CD into your CD-ROM or DVD-ROM drive. Click next and follow the installation program.




Installation will install PowerConfig in your system. If the autorun is disable. Double click the CD-ROM driver ID, and then double-click the PowerConfig.exe. PowerConfig.exe is green program and it will not waste any system resource. Click exit to close program, there is no uninstall procedure.

- 4. <u>Hardware Operation</u> -- Before you start use, please make sure the distance between RHRC-12001 Remote Control and IR605/Q Receiver is within the effective range and the Remote Control is aimed at the IR Receiver. You can start using your Remote Control by pressing anykey you want.
- 5. <u>Software Operation</u> After you execute PowerConfig, there is an icon show in task bar. Click right mouse key on the icon to get the menu.



This setup will re-configure the green button function. When you choose "Start Netflix", it means the system will start Media Center and go to Netflix program directly. Or you can choose "Start Media" to go back to default setting.

6. You can choose TV mode or PC mode from Setup.



* TV mode will change the power configuration of Notebook, let display keep ON when close the panel. Change to PC Mode when you use battery power.

and start to Media Center or Netflix once your press the green button.

Choose Autorun on startup can execute PowerConfig when windows boot up. Finally, press Exit to quit PowerConfig.

Specifications:

RHRC-12001 Remote Control:

- Operation Voltage: 2.4V~3.2V; Battery: AAA battery x 2
- Power Consumption with input signal: 350mA
- Infrared Rays Frequency: 38KHz; Infrared Rays transmission distance: 21 ft~33 ft
- Remote Control size: 8.66" x 2.16" x 0.87" (max)
- Remote Controller Button Number: 49 buttons

IR605/Q Receiver:

Receiver size: 1.69"x 0.87"x 0.64"

Receiver Interface: USB Port

Operation Voltage: 4.75V~5.25V

Key Definition:

	eminion :		
No.	ICON	Function	Function Description
1		Start	Start the MCE or Start the Netflix after install the enclosed CD.
2	0	Power	Turn on/off the power
3	•	Rec	Record the TV program you are watching
4		Stop	Stop all the on going function
5		Rew	Move backward
6	(E)	Play	Run the function you want
7		Fwd	Move forward
8	14	Skip Back	Jump back to the previous one
9		Pause	Stop all the on going function temporary
10	(I)	Skip Fwd	Jump to the next one
11	0	Back	Go back to the upper function group
12	田	Guide	Start the Guide function
13		Left	Move to the left side

No.	ICON	Function	Function Description
14		Right	Move to the right side
15	Ď	Live TV	Start the TV
16	OK	OK	Run the current pointed function
17		Up	Move to the up side
18		Down	Move to the downside
19		Videos	Start Videos Function
20	5	Music	Start Music Function
21	6	Radio	Start Radio Function
22		Pictures	Start Picture Function
23	+	Vol up/down	Tune the volume up/down
24	+	Ch/Pg up/down	Change the channel
25	0	DVD Menu	Open the DVD menu
26	clear	Clear	Clear what you just input/choose
27	enter	Enter	Confirm what you just input

No.	ICON	Function	Function Description
28	L	Recorded TV	Start the Recorded TV function
29		Mute	Turn off the vol immediately
30	(1)	More	Provide information of the current status
31		1	Number 1
32	2	2	Number 2
33	3	3	Number 3
34	4	4	Number 4
35	5	5	Number 5
36	6	6	Number 6
37	7	7	Number 7
38	8	8	Number 8
39	9	9	Number9
40	0	0	Number 0
41	*/.	*/.	*/.
42	(#)	#	#
43		Red	Go to Teletext
44		Green	Go to Teletext
45		Yellow	Go to Teletext
46		Blue	Go to Teletext
47	(T)	Teletext	Open the Teletext


Use Media Center Remote Control with Netflix:

1. <u>Navigation</u> – You can use up, down, left, right and OK key to do navigation for Netflix service.



Moreover, you can use fast forward, back forward, skip, play, stop and pause etc., multimedia control keys for Netflix.

2. <u>Search</u> – You can use Media Center Control input method to search your preference movie titles. Use Navigation key move to Search, press OK. When system appear below dialog, use number key to input the text.



Trouble shooting:

Question	Possible Reason	Solution
RHRC-12001 Remote Control doesn't work	 No battery installed, battery dead, or the batteries are not installed properly Un-correct MCE installation Un-properly connection between the receiver and the computer 	 Check the battery installation and correct it Check the installed MCE program Check the connection between the receiver (USB port) and computer (USB port) and correct it
Cannot find out Netflix in Media Center	 Auto update feature has not enabled in Media Center System location and time zone is incorrect Computer system outside US and Canada. 	 Enable auto update from General Setting of Media Center Follow system guide to change the setting. Users can refer to Netflix or Microsoft website to get more detail support. Refer URL is http://blog.netflix.com/ or http://support.microsoft.com/kb/972496