


3.5 INCH TOUCH SCREEN NAVIGATION SYSTEM

M3-MX

NAVTEQ

ON BOARD















KEYPAD OPERATION AND SCREEN ICONS



Peel the protective sticker off the GPS



Press the "ON" button located on top of the GPS






UNIT VIEW DESCRIPTION



- 1. POWER button Press the power button to enter or exit the standby mode.
- 2. LCD Screen



1. RESET button (if unit freezes press button)



- 1. USB Port
- SD Memory Card slot
 Headphone Jack Used to connect headphones for private listening. When the headphones are connected to this jack, the speaker will be turned off automatically.

 4. DC 5V Input Jack - Used to connect
- to the supplied power adaptor.



Travel Distance



Time to Destination





When using the unit in vehicle, you can use the supplied mounting assemblies (mounting bracket, mounting cradle and dashboard mount disk) to mount the unit in the vehicle. Take the following steps to operate:



- Slide the mounting cradle onto the end of the mounting bracket.
 Lift the suction cup lever.
 To mount to windshield, press the suction cup to the windshield and press down on the suction cup lever. To mount to dashboard, use the included adhesive disk. Choose a clean, dry spot on your dashboard, peel off protection liner from the back of the disk, and then attach the disk to your dashboard.



Nextar's liability or damages to you or any other person ever exceed the amount paid by you for the device, regardless of the form of the claim. Some countries/states do not allow the limitations or exclusion of liability for incidental or consequential damages, so the above limitation or