

Nextar #MN2607

Please review the instructions in order to update your GPS.

First you must download the file (GPS Firmware 1.1 upgrade.dat) and save this to your computer.

1. Connect the GPS to the PC using the USB cable provided.
2. Drag the file (GPS Firmware 1.1 upgrade.dat) into the GPS (this is where all your MP3's are stored.)
3. Unplug cable
4. Restart GPS
5. Upon startup a UI will pop up asking if you want to update the firmware. press yes on the screen and the firmware will begin updating.
6. Once the update has completed turn off GPS and restart again.

The upgrade is complete.