

# DENON

In-Ear Headphones

## AH-C710

Owner's Manual

Bedienungsanleitung

Manuel de l'Utilisateur

Manuale delle istruzioni

Manual del usuario

Gebruiksaanwijzing






Bruksanvisning

Инструкция по эксплуатации

Instrukcja Obsługi

操作說明書

操作说明书



### Accessories

Check that the following parts are supplied with the product.

- ① Owner's Manual ..... 1
- ② Service station list ..... 1
- ③ Ear pieces (S/L size) (☞ A) ..... 2 pcs. / 1 size  
(M size ear pieces are pre-fitted on the headphones.)
- ④ Foam ear pieces (☞ B) ..... 2
- ⑤ Extension cable (Cable length 0.8m) (☞ C) ..... 1
- ⑥ Clip (☞ D) ..... 1
- ⑦ Carrying Case (☞ G) ..... 1

### Declaration of conformity

We declare under our sole responsibility that this product, to which this declaration relates, is in conformity with the following standards: EN55013.

Following the provisions of 2004/108/EC Directive. (For Europe model)

### A note about recycling

This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with the local recycling regulations.

When discarding the unit, comply with local rules or regulations.

This product and the supplied accessories conform to the WEEE directive. (For Europe model)

### Safety precautions

- Listening at high volumes that irritate your ears can have a negative influence on your hearing.
- Do not use headphones while driving a bicycle, motorcycle or automobile. Doing so could lead to accidents.
- When using headphones, for safety keep the volume to a level at which surrounding sounds can be heard.
- Do not put in water or dampen.
- Do not place heavy objects on, heat, or pull on the headphones. Doing so could damage or deform them.
- Store the ear pieces out of the reach of children to prevent small children from accidentally swallowing them.

### Caution on handling

- Be sure to hold the plug when unplugging the cable.
- **Do not place undue stress on the cable, as this can result in wire disconnection or damage.** Observe the following for correct usage.
  - **Do not pull the cable unduly.**
  - Do not pull too hard on the cord when attaching it to or removing it from the included clip.
  - Do not fold the cable.
  - When connected to a portable device, do not leave the portable device hanging.
  - Do not wrap the cable around the portable device.
- If you leave a connected portable device hanging, it may become disconnected and fall. Take care as DENON does not guarantee portable devices.
- Metal parts will touch your skin. People with allergies to metal should not use these headphones. If you feel that the headphones irritate your skin, stop using them and contact a physician or your store of purchase for advice.
- Do not use benzene, thinners, or other organic solvents or insecticides on the main unit since they may cause a change in quality or color.
- The headphones have a structure by which the sound tends to leak out if the volume is too high. Be considerate of others.

### Using the headphones

#### About the ear pieces

Foam type:

Material offering a good fit in the ear and little affected by surrounding noise (☞ B).

Regular type:

Material little affected by sweat or fat. Select the ear pieces providing the best fit from among three sizes: S, M and L (☞ A).

#### NOTE

- Fit the ear pieces securely on the nozzle of the headphones.
- The ear pieces may deteriorate after long term of use or storage.
- Do not let Foam type ear pieces get wet. Moisture will accelerate their deterioration.

### Using the headphones

Check the left/right markings on the headphones, then insert them so that they fit snugly inside your ear, the one marked "R" in your right ear, the one marked "L" in your left ear (☞ E).

- Adjust the position of the slider to take up any slack in the right and left cables (☞ F).
- The cord can be fixed to a clothing pocket, etc., using the included clip (☞ D).

### Specifications

- Type:** Dynamic type
- Drive units:** Ø 11.5 mm
- Input impedance:** 16 Ω/ohms
- Sensitivity:** 110 dB/mW
- Maximum input:** 250 mW
- Playback frequencies:** 5 - 25,000 Hz
- Weight:** 5.6 g (not including cable)
- Cable length:** 0.7 m OFC cable
- Plug:** Ø 3.5 mm gold-plated stereo mini plug

\* For improvement purposes, specifications and design are subject to change without notice.