




**ACTIVE NOISE**  
Cancelling Technology



Wireless Headset


Model: EM266

**In the box**



**About noise cancellation technology**

This headset uses a dual microphone design to filter out wind and unwanted external noise. Using Noise Cancellation Technology, the headset compares the sound from the twin built-in microphones, and is able to recognize the difference between voice and unwanted background noise.



**Noise Cancellation Technology**  
Enables the other end of your conversation to hear you clearly!

**Drive Safe**



**CAUTION:** Although this device enables drivers to conduct handsfree conversations, it is still safer to pull over before using a mobile phone.


- Do not use the stereo earphone while driving.
- Always keep your full attention on your driving.

Driving while talking on your mobile phone is dangerous, and illegal in many states.

Check local laws regarding the use of a mobile handset and wireless headset while driving. If you use the **Bluetooth Headset** while driving, ensure your attention and focus remains on your driving.

**Please use your mobile phone, and our product responsibly while driving!**


**Location of controls**



**Charging the Bluetooth Headset**

1. Connect the USB cable to the charging socket of the headset.
2. Connect the other end of the USB cable to either the:
  - AC Charger, and plug into a wall (A/C) outlet
  - Computer's USB port
3. The **BLUE LED** indicator light turns on.
4. The **BLUE LED** indicator light shuts off when the headset is fully charged (approximately 2-3 hours).


**NOTE:** When the battery is running low, the **BLUE LED** indicator light starts to flash.



**NOTE:** Charge your headset for at least **8 hours** before using it for the first time.


**Pairing the headset with a Bluetooth enabled device**

1. Make sure the **Bluetooth Headset** is turned off.
2. Keep your **Bluetooth Headset** and mobile phone within **3 feet** of each other during the pairing process.
3. Press and **HOLD** the **[POWER]** button until the **BLUE** indicator light turns on, flashes several times, and becomes a steady blue. The headset is now in **Pairing Mode**, and is ready to connect to your mobile phone.
4. The headset is now in **Pairing Mode** and is ready to connect to your mobile phone.




**NOTE:** To enter the **Pairing Mode**, you must press and **HOLD** the **[POWER]** button for approximately 10 seconds.


5. Set your mobile phone to search for Bluetooth devices.




6. When the phone finds the headset, confirm by selecting EM266 from the list.



7. Enter passcode "0000" when prompted by the phone.




**OR** depending on which model mobile phone you are trying to connect the headset to, it may not be necessary to enter a passcode and the following message (or similar) may appear on your phone's display.




Select "Pair" to complete the pairing process.

8. Your mobile phone will confirm that the pairing was completed, and prompt you to accept the connection. Please select **"YES"** to connect the headset to your mobile phone. If the pairing was successful, the headset's indicator light flashes a steady blue.



9. When attempting to reconnect the headset to your mobile phone, you may see the message below, and your mobile phone will prompt you to accept the connection request to the EM266 headset, and an option not to ask this again. Please accept the connection, and if you select "Don't ask this again", your phone will automatically accept future connection requests from your **Bluetooth Headset**.



**NOTE:** The screenshots above are typical of many Bluetooth enabled phones in the market today, and are used to assist in the explanation of the pairing process. Your mobile phone's interface and interaction with the **Bluetooth Headset** may slightly differ from the illustrations above.

**Pairing with the SONY PlayStation®3 (PS3™)**

**Pairing the Bluetooth Headset with a Sony PlayStation 3**

**<SET ACCESSORY to BLUETOOTH on PS3>**

1. Go to the PS3 main menu, scroll to and select **"Settings"**.
2. Scroll to and select **"Accessory Settings"**.
3. Scroll to and select **"Manage Bluetooth Devices"**.
4. The menu will ask: **"The Bluetooth device has not been registered. Do you want to register it?"**, then select **"YES"**.

**<REGISTER EM266 to PS3>**

Put your Bluetooth Headset into pairing mode.  
(See **"Pairing the headset with a Bluetooth enabled device"**)

1. Select **"Start Scanning"** from the PS3 menu.
2. Once the PS3 has discovered the Headset, the screen will read **"Select the Bluetooth device to register"**, then select **"EM266"**.
3. The PS3 will ask for a passkey. Enter **[0000]** then select **"OK"**. Now press [O] (the PS3 circle button) to get back to the previous menu.
4. Scroll to and select **"Audio Device Settings"** to change the **"Input Device"** to **"EM266"**.

**NOTE:** **"Input Device"** is the microphone, and determines the method of how others will hear you speak. By default, the **"Output Device"** will now switch to **"EM266"**. **"Output Device"** is the audio, and determines how you will hear the PS3 audio and others speaking.


To test the connection, speak into the headset and you will see the bars above the "Microphone Level" moving, if not, repeat the pairing process.

Press **"OK"** to confirm the new settings. You are now ready to use the Bluetooth Headset with your PS3 Entertainment System. If you would like to hear the PS3 audio through your TV or Audio System, scroll to "Output Device" and switch to "System Default Device".

For further assistance with Bluetooth settings on your PS3 please refer to your PS3 instruction manual.


## Wearing your Bluetooth Headset

For added comfort and noise suppression, 3 silicone cushions are included with your **Bluetooth Headset**. Choose the silicone cushion (S) (M) (L), which fits most comfortably in your ear, and insert it on the **Bluetooth Headset** as shown in the diagram below.



Silicone cushions

You may wear your headset with or without the provided earhook. If you choose to wear your headset with the earhook, connect it to the headset as shown in the diagrams below.



Fits either ear comfortably

Right ear

Left ear

**NOTE:** For the best audio quality, always wear your **Bluetooth Headset** on the same side of the body as your mobile phone

## Using your Bluetooth Headset

### Powering ON/OFF

To turn **ON**, press and hold the **[POWER]** button until the **BLUE LED** indicator light turns on.

To turn **OFF**, press and hold the **[POWER]** button until the **BLUE LED** indicator light flashes quickly several times, and then shuts off.

### Answering/Ending a call


- To answer a call, press and release the **[POWER]** button.
- To end a call, press and release the **[POWER]** button.

### Rejecting an incoming call

During an incoming call, press and **HOLD** the **[POWER]** button until you hear the confirmation tone.

### To make a call

Dial the number and press the send button on your mobile phone, the call is automatically transferred to the headset.




### Redialing the last number called (Dependent on your phone supporting this feature)

Double press the **[POWER]** button and release. The headset will emit a confirmation tone, and the last number called will be redialed.

### Adjusting the volume


Press the **[VOLUME UP]** or **[VOLUME DOWN]** button to adjust the volume to the desired level.

**NOTE:** You may also adjust the volume from your mobile phone's volume control.




## Stereo Bluetooth

Connect the Stereo Earphone to the Bluetooth Headset's charging socket as shown below.



Insert the Bluetooth Headset in one ear, and wrap the Stereo Earphone behind your neck and insert it into your other ear.



This headset allows you to listen (in full stereo) and control\* the music on your Bluetooth enabled mobile phone, gaming console, computer or mp3 player and supports the following Bluetooth profiles:

- **A2DP - Advanced Audio Distribution Profile**
- **AVRCP - Audio/Video Remote Control Profile**
- **HSP - Headset Profile**
- **HFP - Handsfree Profile**

To use the headset to listen/control music, your Bluetooth enabled device must support the A2DP and AVRCP profiles. Please refer to the user guide of your Bluetooth enabled device for more information.

## Playing music

To enjoy wireless music on your **Bluetooth Headset**, press the **[PLAY]** button of your Bluetooth enabled device to begin music playback. Once playback has begun, you can control the music or answer phone calls from the control buttons of the headset (Not all mobile phones support the control of music using Bluetooth).

### Adjusting the volume

Press the **[VOLUME UP]** or **[VOLUME DOWN]** button to adjust the volume to the desired level.

**NOTE:** You may also adjust the volume from your mobile phone's volume control.

### Play/Pause\* (music)


While the music is playing, press the **[POWER]** button to pause the music. To resume music playback, press the **[POWER]** button again.

### Skipping or searching songs\* (Dependent on your phone supporting this feature)

While the music is playing, press the **[◀ VOLUME UP]** button to go to the previous song, or press the **[▶ VOLUME DOWN]** button to go to the next song.

### Answering a call while listening to music

During an incoming call, press the **[POWER]** button to answer. Press the **[POWER]** button again to end the call and return to the music.



\*Certain Bluetooth features including those listed may not be supported by all compatible Bluetooth-enabled devices, and/or the functionality of such features may be limited in certain devices.

## Troubleshooting tips

❓ I Can pair the Bluetooth Headset with my Bluetooth device, but I cannot hear any music?

- Make sure your Bluetooth device supports A2DP profile.
- When playing music on some mobile phones, the music will be transmitted to the phone's speaker instead of the headset. Select "Transmit sound via Bluetooth" in the phone's Bluetooth settings, then select "EM266" as the speaker device.

❓ My iPhone is paired correctly and I hear music but I cannot control (play, pause, next song, previous song) the music using the controls on the Bluetooth Headset.

- At the time of this User's Guide publication, the iPhone only supports the playback of music using Bluetooth, and does not support the control of the music using Bluetooth.

❓ I cannot get the Bluetooth Headset into **Pairing Mode**.

- Make sure the Bluetooth Headset are turned off before beginning the pairing process.
- Press and **HOLD** the **[POWER]** button until the **BLUE** indicator light turns on, flashes several times, and becomes a steady blue. The headset is now in Pairing Mode, and is ready to connect to your mobile phone.

❓ My mobile phone is not able to pair with the Bluetooth Headset.

- Make sure that you fully charged the headset before pairing.
- Keep your headset and mobile phone within 3 feet of each other during the pairing process.
- Check that your phone's Bluetooth feature is turned **ON**.
- Try repeating the pairing process, see "Pairing the headset with a Bluetooth enabled device."

❓ After successfully pairing my mobile phone and Bluetooth Headset, when I shut my phone and turn it on again, my headset did not automatically connect.

- Try turning the headset **OFF**, and then turning them **ON** again.
- Many mobile phones have an auto reconnect option when first attempting to reconnect to a newly paired Bluetooth device. Make sure you accept this option, so that the headset automatically reconnects to your mobile phone; check the user guide of your mobile phone for more information regarding this option.
- Try unpairing the headset from your phone, and repeat the pairing procedure.

❓ The sound is very low.

- Try adjusting the volume by using the **[Volume]** button on your headset; make sure the volume on your mobile phone is turned up as well.

## FCC and telephone company information

### FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Do not attempt to repair or modify this equipment.

**Warning:** Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Warranty information

### Limited Warranty


In the unlikely event that this product is defective, or does not perform properly, you may within one (1) year from your original date of purchase return it to the authorized service center for repair or exchange.

### TO OBTAIN WARRANTY SERVICE:

- **Provide proof of the date of purchase within the package (Dated bill of sale).**
- **Prepay all shipping costs to the authorized service center, and remember to insure your return.**
- **Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.**
- **Describe the defect or reason you are returning the product.**

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

 **Southern Telecom, Inc.**  
**ATTN: Returns Department**  
**14-C 53rd Street**  
**Brooklyn, NY 11232**

Should you have any questions or problems concerning this product, please contact our customer service department at:

 **1-877-768-8483 (Toll Free)**

**Monday - Thursday: 9AM - 5PM (EST)**

**Friday: 9AM - 3PM (EST)**

or

via e-mail at

 **cs@southern telecom.com**

### Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

### Limitation of Warranty:

• THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY SOUTHERN TELECOM INC. IT'S AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

• REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SOUTHERN TELECOM INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

 **Emerson™**

[www.emersonphones.com](http://www.emersonphones.com)

Distributed by Southern Telecom Inc. Brooklyn, NY 11232

© 2010 Southern Telecom Inc. All rights reserved.

Emerson and the G-Clef logo are registered trademarks of Emerson Radio Corp. Parsippany, New Jersey USA.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. SONY PlayStation® and PS3™ are either trademarks or registered trademarks of SONY.

All other trademarks are trademarks of their respective owners.