

PROLETARIAT NC

Skullcandy

ACTIVE NOISE CANCELLING STEREO HEADPHONES

## User's Manual

### INTRODUCTION


CONGRATULATIONS! This innovative Noise Cancelling headphone frees you from any unwanted noise and provides you with private listening enjoyment even in noisy places. To ensure the best performance of your headphones, please read this manual carefully.

### FEATURES


- Travel-fold design for compact portability
- Large driver units for rich and powerful sound
- Detachable, single-sided connection cable for easy movement
- Adjustable headband fits a wide variety of head sizes
- Full size leatherette earcups provide long-lasting comfort
- Operates as passive headphones when noise cancelling circuit is not activated

### HEADPHONES COMPONENTS

You can find the following parts and accessories together with the headphones




### INSTALLING BATTERIES




### FOLDING THE HEADPHONES FOR STORAGE

This headphones feature rotating earcups that fold flat (they rotate in one direction only) or fold up for easy, convenient storage.




### Using the headphones



1. Connect the headphones to the AV equipment. First connects cable (with 3.5mm I-plug) into the jack on the left (L) earcup and then connects the other end of cable (with 3.5mm plug L-plug) to your audio source.

2. Wear the headphones with the cable always on your left.




3. Adjust the headband by pulling up or down on each end so it rests gently on top of your head and the earcup cushions fit comfortably around your ears.

4. Turn on the power of headphones and the power switch is located on the left (L) earcup. The power indicator lights in green. When the power is turned on, you can feel that ambient noise is reduced.



5. Turn on the power of AV equipment and you are ready to enjoy listening to music or on board movies under a quiet environment.

6. Adjust the volume control on the left (L) earcup as desired.



7. You can use the headphones with a variety of AV equipment: airline audio, CD, DVD or MP3 players, personal or laptop computer or home stereo.

8. Turn OFF the power of headphones when not in use to preserve battery life.

### Notes:

- You can use the headphones to enjoy audio performance even without turning on the power.
- You can use the headphones for noise reduction only even without cable connection to earcup or audio source. Cable can be detached from the earcup for cordless convenience.

### TROUBLESHOOTING

#### No Sound

- Check the connection of the headphones and the AV equipment
- Check the connected AV equipment is turned on
- Turn up the volume of headphones or the connected AV equipment

#### Noise Reduction Absent

- Check the power of headphones is turned on
- Replace the batteries

### SPECIFICATIONS

#### General

Driver units	40mm
Frequency Response	20Hz - 20kHz
Impedance	32 ohms
Sensitivity	121dB/ mW (when power is ON) 115dB/ mW (when power is OFF)
Noise Reduction Level	up to 18dB at 300Hz
Power Supply	2 x AAA batteries

For product improvement, design and specifications are subjected to change without prior notice.

#### Supplied accessories

- Dual plug adapter for in-flight use
- 2 x AAA batteries
- Carrying pouch
- 1.5m cable
- User's manual