



Connecting the Xbox

Use the included cable to connect the base unit, Xbox and sound system as shown. This will allow you to hear the Xbox with either the sound system or the X2 headphones.



Connecting the Microphone

The X2 microphone may be used to communicate with other players during Xbox Live multi-player gaming sessions. Use the included 2.5mm cable to connect the microphone to the Xbox controller. Insert the light gray plug into the headphones and the dark gray plug into the Xbox controller, as illustrated below. The switch integrated into the cable may be used to mute the microphone when you don't want other players to hear you talking.



Configuring Xbox Settings

IMPORTANT: In order to hear other players you must make sure that the following is set from the Xbox 360 dashboard.


1. From the Xbox 360 Dashboard, press the Xbox Guide button (the X button in the center of your controller) to access your Xbox Live Settings.
2. Navigate to the "Personal Settings" selection, and press the "A" button on your controller.
3. Select "Voice" from the following menu, and press "A".
4. On the Voice screen, make sure that "Play Through Both" is selected for Voice Output selection and that volume is set to 10 (see below).
5. You may need to lower the in-game effects and music volume and increase the headphone volume to balance the chat level to your preference.



Connecting Music Players

The X2 may be used for listening to other audio sources, such as the output of your TV, the output of your PC sound card, an Mp3 player, home theater system, etc. In each case, simply connect the output of the audio device to the audio input jack on the base unit and set the level control for optimum listening volume.

As an example, the illustration below shows how to connect the X2 base unit to the output of a home theater system. In this case, the base unit audio input would be connected to the stereo line output on the home theater receiver. In some systems, this would be the recording line output, typically used for a cassette recorder, while on other systems it would be a pre-amplifier line output. Refer to the instructions included with your unit for details.



EAR FORCE[®] X2 Wireless Xbox[®] Headphones


Operating Instructions



For more products, accessories, and our support knowledge base, visit www.turtlebeach.com

About the X2 Headphones

Ear Force X2 wireless headphones use infrared (IR) technology to transmit sound from the base unit to the headphones. The IR light beam is received by sensors in each earpiece, so the headphones must be within sight of the base unit in order to operate properly.




The X2 is perfect for listening to game audio on an Xbox or other game console, and may also be used as a high-fidelity wireless headphone for home theater sound, PC audio, MP3 players, etc. Please refer to the other side of this guide for instructions on how to connect the X2 to these systems.

Important Information

1. Be careful when turning on the master volume control on the headphones. Before placing the headphones over your ears, set the volume control to minimum, then slowly increase until you reach a comfortable level.
2. **CAUTION:** Use only the supplied power adapter. Failure to use the correct power adapter can result in fire and permanent damage to the base transmitter unit.
3. Like any speakers, overdriving headphones may cause damage to both the headphones and your ears. Please listen at moderate levels.
4. **WARNING:** Long term exposure to loud music or other sounds in headphones may cause hearing damage. It is best to avoid extreme volume levels when using headphones, especially for extended periods. Over time, your ears adapt to the volume level, so a level that may not cause initial discomfort might still damage your hearing.

Installing the Batteries

The X2 headphones are powered by 2 AAA batteries (included) located in the left ear cup. Typical battery life is 30 - 40 hours, depending upon usage. Lift the battery cover and insert both batteries before operating the headphones. Then turn the power switch on the right ear cup to the "on" position.




Push in to lift the battery cover

PLEASE NOTE: To conserve battery power, the X2 headphones automatically power off after 2 minutes without a signal. To use the headphones after they have auto-shut down, turn the power switch to the "off" position, then "on" again.

Connecting the Power Adapter

The X2 base unit is powered by a DC power adapter, (included). Insert the power adapter into the power jack on the back of the base unit.




When the adapter is inserted into the base unit and plugged into a wall socket, a red light on the front of the base unit will light up to indicate that power is active.

CAUTION: Use only the supplied power adapter. Failure to use the correct adapter can result in fire, damage to the unit or other hazards.

Connecting an Audio Source

Connect an external audio source to the base unit Audio Input jack using the adapter cable (included). Refer to the other side of this pamphlet for instructions on how to connect this cable to an Xbox or other devices.



Setting the Volume Level

The X2 headphones include a volume control on the right ear cup for controlling the headphone audio level.

The volume sensitivity may be set by a three-way switch on the base unit.

Center Position (Mute): Turns off the audio input to mute the sound to the headphones.

Top Position (High): Used with low level audio sources (**not recommended for Xbox or Xbox 360**). If the audio signal is boosted too loud the headphones may sound distorted or they may stop making sound for a brief time to protect the speaker from being damaged.

Bottom Position (Low): Used with high level audio sources (**recommended**).

When using the X2 with an Xbox, position the switch to the bottom (low) setting.

Package Contents

- X2 wireless headphones
- Transmitter base unit
- DC power adapter
- 2 AAA batteries
- Xbox controller connection cable
- Audio connection cables
- This user's guide

For warranty information please visit <http://support.turtlebeach.com>

Copyright © 2006, Voyetra Turtle Beach, Inc. (VTB). All rights reserved. No part of this document may be reproduced without permission. Turtle Beach, the Turtle Beach logo and Ear Force are trademarks of VTB. Xbox and Xbox Live are trademarks of Microsoft Corporation. All other trademarks are properties of their respective companies and are hereby acknowledged. Product features, visual design, package contents and specifications are subject to change without notice.

V6
Product# TBS-2060