




## **LCD 12.1 ENTERTAINMENT SYSTEM**

LCD-0101-02

LCD-0102-02

LCD-0201-02

LCD-0202-02



**Customer Support Services**  
**PARTS MANUAL** rev 14 Dec 2007

# LCD 12.1-02 ENTERTAINMENT SYSTEM


## Contents

---

|  |    |
|--|----|
| EXPLODED ASSEMBLY .....                        | 3  |
| LCD COMPONENTS.....                            | 4  |
| REMOTE CONTROL.....                            | 5  |
| CONSOLE SUPPORT MOUNTING HARDWARE .....        | 6  |
| STAIR CLIMBER MOUNTING HARDWARE .....          | 7  |
| CROSS-TRAINER (BLACK) MOUNTING HARDWARE.....   | 8  |
| CROSS-TRAINER (SILVER) MOUNTING HARDWARE ..... | 9  |
| TREADMILL (BLACK) MOUNTING HARDWARE .....      | 10 |
| TREADMILL (SILVER) MOUNTING HARDWARE .....     | 11 |

# LCD 12.1-02 ENTERTAINMENT SYSTEM

## *Exploded Assembly*




| Description                          | Part No.        |
|--------------------------------------|-----------------|
| LINE-CORD: 125V; 10A; DOMESTIC B     | 0017-00003-0963 |
| POWER-SUPPLY: AC-TO-DC; 12V 6' CORD  | 0017-00003-0967 |
| POWER-SUPPLY: AC-TO-DC; 12V 10' CORD | 0017-00003-0970 |
| LINE-CORD: 250V; 10A; EUROPEAN B     | 0017-00003-0964 |
| LINE-CORD: 250V; 10A; BRITISH B      | 0017-00003-0965 |
| LINE-CORD: 250V;10A; AUSTRALIAN B    | 0017-00003-0966 |
| COAX CBL-ASSY                        | AK32-00020-0002 |

# LCD 12.1-02 ENTERTAINMENT SYSTEM

## LCD Components


---



# LCD 12.1-02 ENTERTAINMENT SYSTEM

## Remote control


| Remote Assembly Stealth Gray |                   |                 |
|------------------------------|-------------------|-----------------|
| Type Of Cord                 | Complete Assembly | Remote Only     |
| Black Coiled Cord            | AK32-00162-0002   | AK32-00118-0000 |
| Gray Coiled Cord             | AK32-00162-0001   | AK32-00118-0001 |
| Gray Straight Cord           | AK32-00162-0000   | AK32-00118-0002 |



# LCD 12.1-02 ENTERTAINMENT SYSTEM

## *Upright and Recumbent Bikes* *Mounting Hardware*

---



# LCD 12.1-02 ENTERTAINMENT SYSTEM

## Stair Climber Mounting Hardware

Mounting Screws(4)  
 Black  
 0017-00101-1819  
 Gray  
 0017-00101-1820  
 Washer  
 0017-00104-0476

Models: SC95/91/85  
 Mounting Bracket  
 Black  
 AK32-00033-0005


Models: 95S & 93S  
 Mounting Bracket  
 Gray  
 AK32-00033-0011

Model: 90S  
 Mounting Bracket  
 Black  
 AK32-00033-0012

Console Mounting Screws(4)  
 Black  
 0017-00101-1821  
 Gray  
 0017-00101-1822

Support Screws (2)  
 0017-00101-1823


Adapter  
 Black  
 OK32-01035-0000  
 Gray  
 OK32-01035-0001



# LCD 12.1-02 ENTERTAINMENT SYSTEM

## Cross-Trainer (Black) Mounting Hardware

---






# LCD 12.1-02 ENTERTAINMENT SYSTEM

## *Cross-Trainer (Silver) Mounting Hardware*

---


OK62-01265-0000 BRKT: REMOTE; 93X/95Xi



# LCD 12.1-02 ENTERTAINMENT SYSTEM

## Treadmill (90T, 91T) Mounting Hardware

---



# LCD 12.1-02 ENTERTAINMENT SYSTEM

## Treadmill (Silver) Mounting Hardware

---

