

## Easy Setting Guide


Blu-ray Disc Home Theater Sound System

Model No. **SC-BT235**





The order of setting



### 1 Prepare the speakers




### 2 Place the speakers



Speakers	(A)
Front speakers	FRONT/AVANT
Center speaker	CENTER/CENTRE
Surround speakers	SURROUND/AMBIOPHONIE


Refer to the rear label of the speaker before connecting the corresponding cable. Verify the type of speaker with the label on the rear of the speaker. e.g.,



# 3 Connect the cables

For detailed information, refer to the operating instructions.


Connect the cables by color or by the numbers indicated in the illustration to the appropriate terminals on the rear panel of the unit.



# Other connection

## Broadband Network Connections (Optional)

By connecting this unit to the network, you can use the BD-Live and VIERA CAST features.



# 4 Turn on the main unit

**1 Connect the AC power supply cord**

Connect the AC power supply cord to the main unit before connecting to the household AC outlet.

**AC power supply cord (included)**

To a household AC outlet (AC 120 V, 60 Hz)

**2 Turn on the TV**

Turn on your TV and select the appropriate video input mode (e.g., VIDEO 1, AV 1, HDMI, etc.) to suit the connections to this unit.

**3 Turn on the main unit**

Press [ ] to turn on the main unit.

**Installing batteries in the remote control**

R6/LR6, AA

**4 The Easy setup starts**

The on screen display will guide you through the steps.\*2

Press [◀ ▶] to select [Yes/Oui/Si].

\*2 If you want to restart the Easy setup: Refer to "STEP 6: Smart setup / Easy setup" in the operating instructions.