### **Panasonic**

### **Easy Setting Guide**

The order of setting

**Blu-ray Disc Home Theater Sound System** 

Model No. SC-BT230

Prepare the speakers



Place the speakers



Connect the cables See over



Turn on the main unit See over



Easy setup See Easy setup


screen

Prepare the speakers

### Step 1

Label each speaker cable by attaching the numbered sticker at the position indicated in the illustration. Be sure to match the number on each sticker with the circled number in the illustration.

#### e.g., Front speaker Lch




Refer to the rear label of the speaker before connecting the corresponding


Verify the type of speaker with the label on the rear of the speaker.

Speakers	A
Front speakers	FRONT/AVANT
Center speaker	CENTER/CENTRE
Surround speakers	SURROUND/AMBIOPHONIE


e.g.,		_		
0	8			
0	8.8		—(A	0


Step	2





## Place the speakers






## 3 Connect the cables

For detailed information, refer to the operating instructions.


Connect the cables by color or by the numbers indicated in the illustration to the appropriate terminals on the rear panel of the unit.



### Other connection

#### **Broadband Network Connections (Optional)**

By connecting this unit to the network, you can use the BD-Live and VIERA CAST features.



# 4 Turn on the main unit

