

SA-VS700ED

SERVICE MANUAL



Ver 1.0 2003.07

US Model
Canadian Model
AEP Model
UK Model

- SA-VS700ED is composed of following models.
As for the service manual, it is issued for each component model, then, please refer to it.

COMPONENT MODEL NAME

		SA-VS700ED
FRONT SPEAKER/SUBWOOFER		SA-VF700ED
SS-CR700ED	CENTER SPEAKER	SS-CN700ED
	SURROUND SPEAKER	SS-SR700ED

SPECIFICATIONS

SA-VF700ED (Front speakers/Subwoofer)

General

Power requirements	120 V AC, 60 Hz
North American model:	220 - 230 V AC, 50/60 Hz
European model:	250 watts
Power consumptions	1 watt (standby mode)
Dimensions (w/h/d)	Approx. 300 x 1,200 x 300 mm (11 7/8 x 47 1/4 x 11 7/8 in.)
Mass	AMP SIDE: Approx. 16.7 kg (36 lb 13.07 oz) NON AMP SIDE: Approx. 15.0 kg (33 lb 1.11 oz)

SS-CN700ED (Center speaker)

Dimensions (w/h/d)	Approx. 270 x 97 x 120 mm (10 3/4 x 3 7/8 x 4 3/4 in.) When used supplied speaker stand: Approx. 270 x 108-118 x 120 mm (10 3/4 x 4 3/8 - 4 3/4 x 4 3/4 in.)
Mass	Approx. 2.5 kg (5 lb 8.19 oz) When used supplied speaker stand: Approx. 3.0 kg (6 lb 9.83 oz)

SS-SR700ED (Surround speakers)

Dimensions (w/h/d)	Approx. 97 x 270 x 120 mm (3 7/8 x 10 3/4 x 4 3/4 in.) When attached supplied speaker stand: Approx. 270 x 1,200 x 270 mm (10 3/4 x 47 1/4 x 10 3/4 in.)
Mass	Approx. 2.5 kg (5 lb 8.19 oz) When attached supplied speaker stand: Approx. 6.3 kg (13 lb 14.23 oz)

Supplied accessories

Center speaker stand (1)
Surround speaker pipes (2)
Surround speaker bases (2)
Screws (for the surround speaker stands) (2)
Audio connecting cord, 5 m (16 ft 1/2 in.) (1)
Subwoofer connecting cord, 5 m (16 ft 1/2 in.) (1)
Speaker connecting cords (for the front(L/R), center speakers), 5 m (16 ft 1/2 in.) (3)
Speaker connecting cords(for the surround speakers), 10 m (32 ft 9 3/4 in.) (2)

Design and specifications are subject to change without notice.

PARTS LIST

Part No.	Description	Remark
ACCESSORIES		

1-827-817-11	SPEAKER CORD (5m) (For CENTER SPEAKER)	
1-827-818-11	SPEAKER CORD (10m) (For SURROUND SPEAKER)	
1-827-595-11	CORD (WITH CONNECTION) (4P) (5m) (For SUBWOOFER)	
1-827-596-11	CORD (WITH CONNECTION) (PIN-PLUG) (5m)	
4-250-049-01	BASE (SURROUND)	
4-250-050-01	FOOT (CENTER)	
4-250-054-01	BASE (CENTER)	
4-250-055-01	CUSHION (BASE)	
4-249-491-11	MANUAL, INSTRUCTION (ENGLISH, FRENCH)	
4-249-491-21	MANUAL, INSTRUCTION (SPANISH,GERMAN) (AEP)	
4-249-491-31	MANUAL, INSTRUCTION (DUTCH, ITALIAN) (AEP)	
4-249-491-41	MANUAL, INSTRUCTION (SWEDISH, POLISH) (AEP)	
7-685-659-79	SCREW +BVTP 4X8 TYPE2 N-S	
7-685-660-19	SCREW +BVTP 4X10 TYPE2 N-S	

HOME THEATER SPEAKER SYSTEM

9-961-027-01

2003G02-1

© 2003.07

Sony Corporation

Home Audio Company

Published by Sony Engineering Corporation

SONY®

<http://getMANUAL.com>