

INSTALLATION INSTRUCTIONS V90224

ACT955 SQUARE ACCURUS REMODEL HOUSING



Avoid Fire or Electric Shock

This product MUST be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved. DO NOT install insulation within 3 inches of any part of the luminaire. Blinking light of this thermally-protected luminaire may indicate overheating.

- *Read Installation Instructions completely before installation.
- *Failure to follow Installation Instructions may void warranties.
- *Always turn off electricity at fuse box before proceeding to prevent electrical shock.



Installation

- 1. Cut an opening of 4-3/16 inch square in ceiling.
- 2. Get wire from ceiling.
- 3. Mark electrical connections:
- a. connect 1/2 inch trade size flexible metal conduit (supply wire) to junction box opening near can (housing) with suitable housing.
- b. connect black wire from transformer to black supply wire from conduit with wire connector provided inside the junction box.
 - c. connect red or white wire from transformer to white supply wire from conduit with wire connector.
- d. connect green grounding wire (or bare copper wire) in junction box to grounding wire from conduit (green wire) with wire connector.
- 4. Install housing above ceiling:
 - a. adjust suitable height of the weight supporter on transformer.
 - b. turn and insert junction box through the opening.
 - c. snap the housing can straight up against opening.
- d. push clip through housing slot and lock in place; fit clip on side of transformer first to assure proper holding on the weight.
- 5. Install lamp into lampholder.
- *IMPORTANT* Use 50W MR16 12V Lamp Only
- 6. Install lamp into trim then trim into housing.