

INSTRUCTIONS FOR INSTALLATION**READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE INSTALLING FIXTURE.**

This fixture is intended for installation in accordance with the National Electrical Code and local or federal code specifications. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for reference.

1. Thread NIPPLE into CROSSBAR. Thread (UPPER) CAP and LOCKNUT. Secure CROSSBAR to OUTLET BOX with screws provided in OUTLET BOX.
2. Drop (LOWER) CAP and CANOPY over CORD.
3. Pass CORD through NIPPLE and tie a SINGLE OVERHAND KNOT as shown. Adjust NIPPLE to CANOPY depth and lock with LOCKNUT.
4. Make connections: Black fixture lead or fixture lead without tracer mark to black supply lead; white fixture or fixture lead with tracer mark to white supply lead.

Grounding is accomplished by connecting the GREEN GROUND WIRE from the fixture, to the GROUND WIRE from the OUTLET BOX, and to the UNINSULATED GROUND JUMPER WIRE supplied with the fixture in the parts kit.

Use WIRE NUTS (local hardware item) to make connections. Place connections in OUTLET BOX.

5. Position CANOPY over OUTLET BOX and secure with (LOWER) CAP by threading onto NIPPLE.
6. Install recommended lamp.

CAUTION: MAXIMUM WATTAGE AS MARKED ON FIXTURE MUST NOT BE EXCEEDED.

