Flameless LED Scented Candle

Vanilla Scented

Item # B2510

INSTRUCTIONS


Use the On - Off switch on bottom of candle to turn LED to On Flicker position or OFF position. (see A)
 Switch to "off" when not in use.

 To replace the included button cell (CR2032) open bottom battery compartment cover, install one CR2032 battery, replace battery compartment cover, Make sure polarity (+) faces out as indicated, (see B).

Warning: This product is made of war. It is recommended to keep out of high heat environments. May cause candle to change shape or met.

This device complex with Part 15 of the FCC Rules, Operation in subject to the following two conditions 1) This device may not cause harmful interference, and 2) This device must accept any interference received, including interference that may cause undesired operation.

Remove batteries when spent or if product is unused for long periods of time.



m

Mark Feldstein & Associates, inc.

Maumee, Ohio 43537 - www.markfeldstein.com