



- 1.Carefully remove the fixture out of the carton, and check that all the parts are included referring to the above illustration .Make sure not to misplace any parts that are needed for the installation;
- 2.Install the fixture loop(1)onto nipple(2);
- 3.Thread nipple with hex nut(7)into coupling(6),then slide the space tube(8),tube cover(9),rubber washer(10),glass sahde(11)and steel washer(12)onto nipple with hex nut(7),and secure them with hex nut(13);
- 4.Slide the cap(14)onto nipple with hex nut(7), and secure it with finial(15);
- 5.Install the ball screw(3)through hole of the plastic washer(4)and glass panel(5)into steel panel;
- 6.Install the lamps on!