

# Ferrari one Series

## Quick Guide

Copyright © 2009. All Rights Reserved.

Ferrari one Series Quick Guide  
Original Issue: 08/2009

Ferrari one Series Notebook PC

Model number: \_\_\_\_\_

Serial number: \_\_\_\_\_

Date of purchase: \_\_\_\_\_

Place of purchase: \_\_\_\_\_

# First things first

We would like to thank you for making an Acer notebook your choice for meeting your mobile computing needs.


## Your guides

To help you use your Acer notebook, we have designed a set of guides:

First off, the **Just for Starters...** poster helps you get started with setting up your computer.

The **Ferrari Series Generic User Guide** contains useful information applying to all models in the Ferrari product series. It covers basic topics such as using the keyboard and audio, etc. Please understand that due to its nature, the **Generic User Guide** as well as the **AcerSystem User Guide** mentioned below will occasionally refer to functions or features which are only contained in certain models of the series, but not necessarily in the model you purchased. Such instances are marked in the text with language such as "only for certain models".

The **Quick Guide** introduces you to the basic features and functions of your new computer. For more on how your computer can help you to be more productive, please refer to the **AcerSystem User Guide**. This guide contains detailed information on such subjects as system utilities, data recovery, expansion options and troubleshooting. In addition it contains warranty information and the general regulations and safety notices for your notebook. It is available in Portable Document Format (PDF) and comes preloaded on your notebook. Follow these steps to access it:

- 1 Click on  **Start, All Programs, AcerSystem.**
- 2 Click on **AcerSystem User Guide.**




.....

**Note:** Viewing the file requires Adobe Reader. If Adobe Reader is not installed on your computer, clicking on **AcerSystem User Guide** will run the Adobe Reader setup program first. Follow the instructions on the screen to complete the installation. For instructions on how to use Adobe Reader, access the **Help and Support** menu.









# Your Acer notebook tour

After setting up your computer as illustrated in the **Just for Starters...** poster, let us show you around your new Acer notebook.

## Top view



#	Icon	Item	Description
1		Acer Crystal Eye webcam	Web camera for video communication.














#	Icon	Item	Description
2		Microphone	Internal microphone for sound recording.
3		Display screen	Also called Liquid-Crystal Display (LCD), displays computer output (Configuration may vary by models).
4		HDD	Indicates when the hard disk drive is active.
		Num Lock	Lights up when Num Lock is activated.
		Caps Lock	Lights up when Caps Lock is activated.
5		Keyboard	For entering data into your computer.
6		Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
7		Click buttons (left and right)	The left and right buttons function like the left and right mouse buttons.
8		Communication indicator	Indicates the status of WLAN / 3G communication. (only for certain models)
		Power <sup>1</sup>	Indicates the computer's power status.
		Battery <sup>1</sup>	Indicates the computer's battery status. <b>1. Charging:</b> The light shows amber when the battery is charging. <b>2. Fully charged:</b> The light shows blue when in AC mode.
		Bluetooth communication indicator	Indicates the status of Bluetooth communication. (only for certain models)
9		Palmrest	Comfortable support area for your hands when you use the computer.
10		Power button / indicator	Turns the computer on and off. / Indicates the computer's power status.

1. The front panel indicators are visible even when the computer cover is closed up.


## Hotkeys

The computer employs hotkeys or key combinations to access most of the computer's controls like screen brightness and volume output.

To activate hotkeys, press and hold the **<Fn>** key before pressing the other key in the hotkey combination.

Hotkey	Icon	Function	Description
<b>&lt;Fn&gt; + &lt;F1&gt;</b>		Power management	Launch Windows power management.
<b>&lt;Fn&gt; + &lt;F2&gt;</b>		System property	Starts System Property for displaying system information.
<b>&lt;Fn&gt; + &lt;F3&gt;</b>		Bluetooth	Enables/disables the Bluetooth function. (only for certain models)
<b>&lt;Fn&gt; + &lt;F4&gt;</b>		Sleep	Puts the computer in Sleep mode.
<b>&lt;Fn&gt; + &lt;F5&gt;</b>		Display toggle	Switches display output between the display screen, external monitor (if connected) and both.
<b>&lt;Fn&gt; + &lt;F6&gt;</b>		Screen blank	Turns the display screen backlight off to save power. Press any key to return.
<b>&lt;Fn&gt; + &lt;F7&gt;</b>		Touchpad toggle	Turns the internal touchpad on and off.
<b>&lt;Fn&gt; + &lt;F8&gt;</b>		Speaker toggle	Turns the speakers on and off.
<b>&lt;Fn&gt; + &lt;F10&gt;</b>		Ferrari	Launches the Ferrari website.
<b>&lt;Fn&gt; + &lt;↑&gt;</b>		Brightness up	Increases the screen brightness.
<b>&lt;Fn&gt; + &lt;↓&gt;</b>		Brightness down	Decreases the screen brightness.
<b>&lt;Fn&gt; + &lt;↑&gt;</b>		Volume up	Increases the sound volume.
<b>&lt;Fn&gt; + &lt;↓&gt;</b>		Volume down	Decreases the sound volume.

## Closed front view




#	Icon	Item	Description
1		Speakers	Left and right speakers deliver stereo audio output.
2		Communication key	Enables / disables the WLAN / 3G function.
3		Bluetooth communication switch	Enables / disables the Bluetooth function. (only for certain models)




## Rear view



#	Icon	Item	Description
1		Battery bay	Houses the computer's battery pack.


## Left view



#	Icon	Item	Description
1		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).
2		Acer DynaVivid Graphics Dock connector	Connects to an Acer DynaVivid Graphics Dock device.
3		Ventilation slots	Enable the computer to stay cool, even after prolonged use.
4		USB 2.0 port	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).









## Right view



#	Icon	Item	Description
1		Multi-in-1 card reader	<p>Accepts Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick PRO (MS PRO), xD-Picture Card (xD).</p> <p><b>Note:</b> Push to remove/install the card. Only one card can operate at any given time.</p>
2		Headphones/speaker/line-out jack with S/PDIF support	Connects to audio line-out devices (e.g., speakers, headphones).
		Microphone-in jack	Accepts inputs from external microphones.
3		USB 2.0 port	Connects to USB 2.0 devices (e.g., USB mouse, USB camera).
4		DC-in jack	Connects to an AC adapter.
5		Kensington lock slot	<p>Connects to a Kensington-compatible computer security lock.</p> <p><b>Note:</b> Wrap the computer security lock cable around an immovable object such as a table or handle of a locked drawer. Insert the lock into the notch and turn the key to secure the lock. Some keyless models are also available.</p>
6		Ethernet (RJ-45) port	Connects to an Ethernet 10/100/1000-based network.

## Base view



#	Icon	Item	Description
1		Battery bay	Houses the computer's battery pack.
2		Battery lock	Locks the battery in position.
3		Hard disk bay	Houses the computer's hard disk (secured with screws).
4		Memory compartment	Houses the computer's main memory.
5		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. <b>Note:</b> Do not cover or obstruct the opening of the fan.
6		Battery release latch	Releases the battery for removal.

# Specifications

Operating system	<ul style="list-style-type: none"> <li>• Genuine Windows 7®</li> </ul>
Platform	<ul style="list-style-type: none"> <li>• AMD Athlon™ 64 X2 dual-core processor</li> <li>• AMD M780G Chipset</li> </ul>
System memory	<ul style="list-style-type: none"> <li>• Dual-Channel SDRAM support</li> <li>• Up to 2 GB of DDR2 667 MHz memory, upgradeable to 4 GB using two soDIMM modules*</li> <li>• Up to 2 GB of DDR2 800 MHz memory, upgradeable to 4 GB using two soDIMM modules*</li> </ul>
Display	<ul style="list-style-type: none"> <li>• 16:9 aspect ratio</li> <li>• 11.6" high-brightness Acer CrystalBrite™ LCD</li> </ul>
Graphics	<ul style="list-style-type: none"> <li>• ATI Radeon™ HD 3200 Graphics</li> </ul>
Communication	<ul style="list-style-type: none"> <li>• Integrated Acer Crystal Eye webcam</li> <li>• WWAN: UMTS/HSPA at 850/900/1900/2100 MHz and quad-band GSM/GPRS/EDGE (850/900/1800/1900 MHz)*</li> <li>• WLAN: <ul style="list-style-type: none"> <li>• Acer InviLink™ Nplify™ 802.11b/g/Draft-N*</li> <li>• Acer InviLink™ 802.11b/g*</li> </ul> </li> <li>• WPAN: Bluetooth® 2.1+Enhanced Data Rate (EDR)*</li> <li>• LAN: Gigabit Ethernet; Wake-on-LAN ready</li> </ul>
Audio	<ul style="list-style-type: none"> <li>• High-definition audio support</li> <li>• S/PDIF (Sony/Philips Digital Interface) support for digital speakers</li> <li>• MS-Sound compatible</li> <li>• Built-in microphone</li> </ul>
Storage subsystem	<ul style="list-style-type: none"> <li>• 2.5" hard disk drive</li> <li>• Multi-in-1 card reader</li> </ul>
Privacy control	<ul style="list-style-type: none"> <li>• BIOS user, supervisor, HDD passwords</li> <li>• Kensington lock slot</li> </ul>
Dimensions and weight	<ul style="list-style-type: none"> <li>• 285 (W) x 204 (D) x 24/30 (H) mm (11.22 x 8.03 x 0.9/1.2 inches)</li> <li>• 1.5 kg (3.31 lbs.) with 6-cell Li-ion battery pack</li> </ul>
Power subsystem	<ul style="list-style-type: none"> <li>• ACPI 3.0</li> <li>• 6-cell Li-ion battery pack</li> <li>• 3-pin 65 W AC adapter</li> <li>• ENERGY STAR®*</li> </ul>
Special keys and controls	<ul style="list-style-type: none"> <li>• 84-/85-/88-key keyboard</li> <li>• Touchpad pointing device</li> </ul>

I/O interface	<ul style="list-style-type: none"> <li>• Acer DynaVivid Graphics Dock™ connector</li> <li>• Multi-in-1 card reader (SD/MMC/MS/MS PRO/xD)</li> <li>• USB 2.0 port</li> <li>• External display (VGA) port</li> <li>• Headphones/speaker/line-out jack with S/PDIF support</li> <li>• Microphone-in jack</li> <li>• Ethernet (RJ-45) port</li> <li>• DC-in jack for AC adapter</li> </ul>
Environment	<ul style="list-style-type: none"> <li>• Temperature:             <ul style="list-style-type: none"> <li>• Operating: 5 °C to 35 °C</li> <li>• Non-operating: -20 °C to 65 °C</li> </ul> </li> <li>• Humidity (non-condensing):             <ul style="list-style-type: none"> <li>• Operating: 20% to 80%</li> <li>• Non-operating: 20% to 80%</li> </ul> </li> </ul>



-----

**Note:** \* Only for certain models



-----

**Note:** The specifications listed above are for reference only. The exact configuration of your PC depends on the model purchased.