

# Lenovo 3000 G430/G530 Setup Poster v1.0




Read the safety notices and important tips in the included manuals before using your computer.

**lenovo**


## Initial setup instructions

### 1 Install battery pack


Unlock both switches and insert the battery pack. After inserting the battery pack, make sure both switches are in the lock position.



### 2 Connect to the power




### 3 Turn on the Power



### 4 Configure the Operating System following on-screen instructions


Slide your finger across the TouchPad surface to move the cursor. Click the left button to select items.



### 5 Enjoying your computer with supplied softwares

#### OneKey Rescue System

OneKey Rescue System is an easy-to-use system which includes several applications to help you detect and remove viruses, and recover Windows system and personal data.

You can press OneKey Rescue System button  to activate OneKey Rescue System when your PC is turned off. Within the program, you can upgrade the virus definition and use antivirus tools, repair system kernel files, restore your system partition to the original factory status or to a previously generated backup. You may also transfer critical data or documents to other storage devices. All these features make OneKey Rescue System an important utility to secure your data.

#### EnergyCut

EnergyCut manages your computer's power supply. It makes your computer work effectively at a low energy cost according to different modes.

#### Power2Go

Power2Go burns data, music, videos and photos onto CDs, DVDs.

#### Norton Internet Security

Norton Internet Security, the newest product of Symantec company in 2008, is designed to protect the network security concerned by users against the latest threats and has considerable functions, such as anti-virus, fire wall, anti-spyware, privacy protection and anti-phishing.

#### Adobe Reader

Adobe Acrobat Reader enables you to view PDF files. With its snapshot tool and text selector, you can copy the content into various editing software programs.

\* Your computer may not come with these supplied softwares because of the operation system and where you purchase the computer.

Lenovo, lenovo logo, IdeaPad, VeriFace, OneKey Recovery, OneKey Antivirus, OneKey Rescue, APS, Power express, Energy management and ReadyComm are either registered trademarks or trademarks of Lenovo in the United States and/or other countries.

## Unpack

Computer



Battery pack



AC adapter



Power cord



Manuals



- Setup Poster  
- User Guide  
- Other publications



- ① Some models may contain items that are not listed.
- ② If any item is missing or damaged, please contact your retailer.




P/N:148000469  
Printed in China

# Buttons and functions

















## Power button / OneKey Rescue System button

-  Start the computer.
-  Repair windows system kernel files or restore system to its original state in case of an unrecoverable error.


## Fn key

-  Use in combination with other keys to access special features.





## Function key combinations +

- |   |   |
|---|---|
|  Enter/exit sleep mode.  |  Turn off/on the LCD screen.     |
|  Choose the display scheme.  |  Select the aspect ratio.        |
|  Turn on/off the wireless device function. (Specific model only) |  Enable/disable TouchPad.      |
|  Play/Pause  |  Stop                          |
|  Previous  |  Next                          |
|  Switch between character or numeric input mode.                 |  Activate the system request.  |
|  Stop the scrolling of text.                                     |  Activate the break function.  |
|  Adjust the volume   |  Adjust the display brightness |

## Integrated camera (Specific model only)


-  The integrated camera offers an improved notebook experience for video-centric applications.

## Custom buttons / Volume buttons

-  Mute
-  Volume down
-  Volume up
-  Open the User Define Utility.

## Wireless device switch (Specific model only)

-  Turn on/off both Wireless LAN and Bluetooth.



\* The illustrations in this manual may differ from the actual product.