

RS82

HERITAGE TRACTOR

CODE 148D

SPARE PARTS MANUAL

English Version
CODE FROM SERIAL NO:
148D 26000001
Issue: 27.10.05


MANUAL PART NO: 111-0550 (REV.A.)

<i>STEERING & FRONT AXLE</i>	<i>1.4 - 1.7</i>
<i>ENGINE COVER & PANELS</i>	<i>1.8 - 1.9</i>
<i>CUTTERDECK</i>	<i>1.10 - 1.13</i>
<i>GRASSBAG ASSEMBLY</i>	<i>1.14 - 1.15</i>
<i>REAR AXEL & CONTROL PEDALS</i>	<i>1.16 - 1.19</i>
<i>GRASSBAG MOUNTING</i>	<i>1.20 - 1.21</i>
<i>ENGINE BATTERY & DRIVE</i>	<i>1.22 - 1.25</i>
<i>SEAT ASSEMBLY</i>	<i>1.26 - 1.27</i>
<i>ELECTRICS</i>	<i>1.28 - 1.29</i>

When ordering spare parts please give the following information.


**PART NUMBER, DESCRIPTION AND QUANTITY REQUIRED,
MACHINE TYPE, MODEL AND SERIAL NUMBER.**

Use only Hayter spare parts, others may be dangerous and will invalidate the machine warranty.




148DTH01

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Steering Wheel	AL461117	1	
2	Roll Pin	AL700664	1	
3	Washer	AL521115	1	
4	Bush Flanged	AL514197	2	
5	Cover	AL514085	1	
6	Bolt	AL700553	4	
7	Nut	AL321126	1	
8	Hood Lock Down	AL514416	1	
9	Bolt	AL700555	1	
10	Washer	AL700200	1	
11	Clip	AL702724	4	
12	Washer	AL461290	1	
13	Shim	AL701166	2	
14	Nut	AL704536	9	
15	Washer	AL700148	8	
16	Steering Rod	AL514032	1	
17	Support Rod	AL514049	1	
18	Bolt	AL703191	4	
19	Key	AL704275	1	
20	Washer	AL701765	4	
21	Nut	AL704537	6	
22	Steering Gear	AL514009	1	
23	Spacer	AL51438730	1	
24	C Clip	AL702893	1	
25	Washer	AL702574	1	
26	Washer	AL704540	1	
27	Spacer	AL461109	1	
28	Quadrant Assembly	AL46110530	1	
29	Washer	AL521123	1	
30	Bolt	AL702381	1	
31	Nut	AL461231	1	
32	Nut	AL704537	1	
33	Bracket - Lower	AL46110730	1	
34	Bracket - Upper	AL46110830	1	
35	Nut	AL704534	4	
36	Rod	AL46111130	1	
37	Ball Joint	AL514701	4	
38	Bush	AL461110	1	
39	Nut	AL348988	1	
40	Bolt	AL523134	1	
41	Nut	AL461231	1	
42	Washer	AL701083	2	
43	Bushing	AL51436030	1	
44	Bush Flanged	AL514042	4	
45	Axle	AL51447701	1	
46	Nipple-Grease	AL700203	1	
47	LH Axle	AL521170	1	
48	Bearing	AL521268	2	
49	Wheel Assembly	AL52185040	2	incl.items 50,60
50	Inner Tube	AL546219	2	Not Illustrated
51	Rod	AL51404130	1	
52	RH Axle	AL521171	1	
53	Bolt	AL701985	1	
54	Bolt	AL702812	1	
55	Bolt	AL701489	2	




148DTH01

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
56	Chassis	AL51405101	1	
57	Bush Wheel	AL450263	4	
58	Centre Cap	AL46111801	1	
59	Nut	AL703813	3	
60	Tyre	AL461533	2	
61	Screw	AL700553	2	
62	Cap	AL461289	2	
63	Screw	AL701985	1	
64	Spacer	AL461499	1	
65	Washer	AL461501	2	
66	Arm	AL461497	1	
67	Spring	AL461500	1	
68	Rod	AL461498	1	
69	Spacer	AL461502	2	




148DTH02


ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Decal Grass Blade	410064	1	
2	Panel	AL52157813	1	
3	Screw	AL521679	2	
4	Lens Assembly	AL521554	1	
5	Grille	AL52157413	1	
6	Screw	AL514317	3	
7	Nut	AL514331	7	
8	Screw	AL704752	13	
9	Receptacle fastener	AL521676	6	
10	Decal - Caution	AL526506	1	
11	Strut	AL521460	1	
12	Decal RH	148007	1	
13	Panel RH	AL52157513	1	
14	Hood Assembly	AL52157213	1	
15	Screw	AL510177	2	
16	Washer	AL700148	6	
17	Rod	AL514419	1	
18	Cover	AL521529	1	
19	Screw	AL518482	2	
20	Screw	AL514316	6	
21	Washer	AL703005	11	
22	Screw	AL700553	6	
23	Cover	AL51400213	1	
24	Nut	AL704536	6	
25	Mat RH	AL51416101	1	
26	Decal LH	148006	1	
27	Panel LH	AL52157613	1	
28	Mat LH	AL52127601	1	
29	Screw	AL514544	4	
30	Cover RH	AL51414801	1	
31	Deck seat	AL51400513	1	
32	Deck	AL51400413	1	
33	Cover LH	AL51414601	1	
34	RH Front Bracket	AL521461	1	
35	LH Front Bracket	AL521462	1	
36	Bolt	AL704138	4	
37	Nut	AL321126	4	
38	Decal Parking Brake	AL	1	
39	Screw	AL348947	2	
40	Plug	AL51499901	1	
41	Plug	AL52113801	1	




ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Belt Cutter	AL514083	1	
2	Clip	AL543474	4	
3	Bolt	AL52118130	3	
4	Latch	AL52114730	4	
5	Pin	AL52114830	1	
6	Spring	AL521202	1	
7	Square Link	AL52114930	1	
8	Washer	AL704538	4	
9	Pulley	AL514098	1	
10	Washer	AL700141	1	
11	Nut	AL700232	1	
12	Nut	AL704537	3	
13	Washer	AL700148	3	
14	Pulley	AL514716	1	
15	Screw	AL701168	2	
16	Packer	AL514434	1	
17	Bracket	AL51440230	1	
18	Cir - Clip	AL700413	1	
19	Washer	AL704539	2	
20	Nut	AL700119	2	
21	Spacer	AL51421630	1	
22	Bracket	AL51439430	1	
23	Bracket	AL51440530	1	
24	Bolt	AL701672	1	
25	Bush	AL51422030	2	
26	Direction Rod	AL52138330	1	
27	Washer	AL702882	6	
28	Chute	AL521089	1	
29	Screw	AL348947	7	
30	Spring	AL514439	1	
31	Screw	AL700702	3	
32	Height Adjust	AL521129	1	
33	Washer	AL701647	1	
34	Latch Lever	AL52119030	2	
35	Nut	AL704536	7	
36	Bar	AL51425330	2	
37	Pin	AL701626	2	
38	Clip - Hitch Pin	AL51420801	1	
39	Bolt	AL700704	8	
40	Rear Adjuster Spacer	AL51415930	2	
41	Bearings	AL700503	1	
42	Bolt	AL523134	2	
43	Pin	AL51412830	1	
44	Spring	AL514437	1	
45	Quill	AL514258	1	
46	Bracket	AL52138230	1	
47	Washer - Star	AL607801	1	
48	Deck	AL51420401	1	
49	Ring	AL522575	1	
50	Connector	AL321347	1	




ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
51	Screw	AL521281	3	
52	Screw Hexagon	AL701127	1	
53	Washer	AL701765	4	
54	Connector - Jet	AL321182	1	
55	Spacer	AL514094	1	
56	Bearing	AL700503	1	
57	Deck Bush	AL521695	1	
58	Shaft	AL514092	1	
59	Key	AL701595	4	
60	Blade	AL514658	1	
61	Blade Fixing - Kit	AL514659	1	includes,wing tips, 6 bolts,6 nuts.
62	Washer	AL702254	2	
63	Screw	AL700704	1	
64	Blade - Holder	AL514176	1	
65	Front Height Adjuster	AL46113601	1	
66	Height Adjuster	AL51421301	2	
67	Nut	AL703813	6	
68	Washer	AL700151	9	
69	Decal - Hands & Feet	AL526507	2	
70	Washer	AL704863	1	
71	Nut	AL703813	2	
72	Bolt	AL700573	2	
73	Nut	AL704536	2	
74	Bolt	AL703374	1	




ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Handle - Grip	AL514079	1	
2	Lever	AL51407830	1	
3	Screw Hexagon	AL703363	9	
4	Washer	AL703005	9	
5	Handle	AL514655	1	
6	Cover	AL514006	1	
7	Bolt	AL514802	2	
8	Washer	AL700148	2	
9	Latch	AL521038	1	
10	Screw	AL348954	2	
11	Pin	AL700166	1	
12	Frame - Upper Grass Collector	AL51499401	1	
13	Washer	AL700137	13	
14	Nut	AL704536	11	
15	Screw	AL510433	1	
16	Frame - Lower Grass Collector	AL514182	1	
17	Bar	AL51424330	1	
18	Bar	AL514183	1	
19	Grassbag Fabric	AL514080	1	
20	Screw	AL703563	2	




ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Spring	AL514386	1	
2	Star Washer	AL510566	2	
3	Pin - Pedal	AL51442430	2	
4	Bolt	AL514316	2	
5	Pedal	AL51406701	1	
6	Pedal Arm	AL51406830	1	
7	Bolt	AL700555	3	
8	Clip	AL514396	2	
9	Switch	AL514327	2	
10	Rivet	AL701395	4	
11	Switch Halter	AL514385	2	
12	Aduster Cover - Black	AL302231	1	
13	Arm - RH	AL514410	1	
14	Nut	AL704368	1	
15	Cable	AL514157	1	
16	Nut	AL704537	14	
17	Ball Joint	AL514239	2	
18	Rod	AL514132	1	
19	Screw	AL704546	3	
20	Bracket - Cable	AL51418130	1	
21	Nut	AL700246	1	
22	Nut	AL704533	2	
23	Bracket	AL51424130	1	
24	Bolt	AL703892	1	
25	Washer	AL701765	1	
26	Control Lever Drive	AL51413130	1	
27	Bushing - Sliding	AL514446	1	
28	Bushing	AL51424030	1	
29	Bracket - Pivot	AL51475730	1	
30	Knob	AL514174	1	
31	Lever	AL51482230	1	
32	Bracket Lever	AL51477430	1	
33	Bolt	AL704270	1	
34	Washer	AL700656	1	
35	Spacer	AL51423730	1	
36	C-Clip	AL702724	2	
37	Washer	AL461290	2	
38	Washer	AL704263	4	
39	Rear Wheel Assembly	AL52185140	2	incl,items 40,55
40	Inner Tube	AL546221	2	Not Shown
41	Spacer	AL51476730	1	
42	Key - Drive Shaft	AL514313	2	
43	Screw	AL701612	1	
44	Washer	AL700200	1	
45	Spring	AL514605	1	
46	Bolt	AL700303	4	
47	6 Speed Manual Gearbox	AL514011	1	
48	Gear Shift Lever	AL51444830	1	
49	Washer	AL700148	1	
50	Screw	AL511461	1	



ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
51	Washer	AL704538	1	
52	Spacer	AL51866030	1	
53	Bolt	AL701704	6	
54	Bolt	AL704546	2	
55	Tyre	AL461534	2	
56	Bearing Assembly	AL514081	1	
57	Pulley	AL514075	1	
58	Spring LH	AL514295	1	
59	Pedal Arm Left	AL52118530	1	
60	Pedal Left	AL51416801	1	
61	Pedal Stop	AL521188	1	
62	Screw	AL582737	2	
63	Lock Fix	AL52118630	1	
64	Lock Pivot	AL52118730	1	
65	Clutch Cable	AL514070	1	
66	Key	AL522531	1	
67	Nut	AL704537	7	
68	Nut	AL-----	4	
69	Throttle Control	AL514382	1	
70	Remote Control Lever	AL514395	1	
71	Screw	AL700961	1	
72	Nut	AL701352	1	
73	Screw Left	AL702830	2	
74	Nut	AL700119	2	
75	Nut	AL521375	2	
76	Washer	AL700200	2	
77	Nut	AL704536	2	
78	Washer	AL703005	1	
79	Screw Hexagon	AL704368	2	
80	Cap	AL461289	2	




ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Nut - Lock	AL704537	13	
2	Reinforced Plate	AL514689	1	
3	Bolt	AL700967	2	
4	Bolt	AL701672	1	
5	Bracket	AL51481901	1	
6	Screw	AL704546	4	
7	Screw	AL511461	1	
8	Back Plate	AL51475101	1	
9	Washer	AL700147	2	
10	Washer	AL700150	9	
11	Cover Only	AL-----	1	
12	Grip Fix	AL526521	2	
13	Audible Switch Assembly	AL521339	1	Includes item 11,12,14
14	Lever Plastic	AL514682	1	
15	Screw	AL511693	2	
16	Screw	AL701375	8	
17	Nut	AL700276	8	
18	Bolt	AL703892	6	
19	Bracket - RH	AL51418501	1	
20	Bracket - LH	AL51418601	1	
21	Roll Pin	AL700661	1	
22	Rivet	AL358710	2	




148DTH08

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Strip - Rubber	AL514818	1	
2	Battery	AL451000	1	
3	Screw 5 x 16	AL700974	2	
4	Washer	AL701365	2	
5	Nut	AL701366	2	
6	Clip	AL512101	1	
7	Clip	AL512100	1	
8	Tray	AL514670	1	
9	Fuel Cap	AL544600	1	
10	Fuel Tank	AL514839	1	
11	Fuel Pipe	AL51437910	1	
12	Nut	AL348988	6	
13	Washer	AL701765	4	
14	Belt Guide	AL514398	1	
15	Bolt	AL700573	2	
16	Belt Guide	AL514347	1	
17	Belt Guide	AL514399	1	
18	Nut	AL704536	2	
19	Belt Guide	AL514620	1	
20	Spring	AL522087	1	
21	Belt	AL514074	1	
22	Pulley	AL514717	1	
23	Washer	AL700148	2	
24	Bolts	AL523134	6	
25	Spacer	AL51480430	1	
26	Washer	AL700656	1	
27	Bolt	AL701171	1	
28	Pulley	AL514716	1	
29	Washer	AL70108310	1	
30	Tensioning Roll	AL52109630	1	
31	Screw	AL700551	3	
32	Pulley	AL514322	1	
33	Clutch Cable	AL514070	1	
34	Washer	AL704266	1	
35	Bolt	AL522515	1	
36	Belt Guide Starter	AL51438830	1	
37	Screw	AL704546	3	
38	Washer	AL700150	3	
39	Clip	AL544515	2	
40	Briggs & Stratton	-----	1	Contact Dealer
41	Battery Charger	AL117354	1	Not Shown
42	Nut - Lock	AL704537	7	
43	Key	AL514326	1	
44	Nut	AL704537	4	
45	Bolt	AL700483	2	
46	Screw	AL701138	4	
47	Washer	AL700959	4	
48	Deflector	AL521733	1	
49	Exhaust Box	AL521732	1	




148DTH08

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
50	Protective Front Plate	AL521476	1	
51	Nut	AL700798	2	
52	Bolt	AL700483	2	
53	Nut	AL321126	2	
54	Screw	AL700545	2	
55	Exhaust Housing	AL521469	1	
56	Exhaust Pipe	AL461120	1	
57	Sealing Flange Exhaust	AL514987	1	
58	Bolt	AL461209	2	
59	Washer	AL702756	2	
60	Nut	AL704533	2	
61	Bolt	AL500207	1	



148DTH05

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Seat	AL514167	1	
2	Adjustable Sleeve	AL514230	1	
3	Screw	AL700051	2	
4	Washer	AL701765	4	
5	Knob	AL521480	2	
6	Star Washer	AL510566	2	
7	Articulated Rod	AL51414130	1	
8	Base - Seat	AL521395	1	
9	Cap Cover	AL514346	2	
10	Screw	AL704546	2	
11	Seat Switch	AL514327	1	
12	Washer	AL700150	4	
13	Spring	AL514307	2	
14	Cable	AL514157	1	
15	Gear Segment	AL625877	1	
16	Lever	AL514224	1	
17	Washer	AL700151	1	
18	Bolt	AL704264	1	
19	Washer - Star	AL504729	1	
20	Spring	AL2045480006	1	
21	Button	AL2042850001	1	
22	Grip Handle	AL375725	1	
23	Nut	AL704537	8	
24	Bolt	AL700545	4	
25	Heat - Deflector	AL521475	1	
26	Plug	AL504516	2	
27	Bar - Front	AL52184401	1	
28	Rocker Stop	AL514299	2	
29	Screw	AL701011	2	
30	Bolt	AL701070	1	
31	Nut	AL703818	1	
32	Spacer	AL521727	2	



148DTH07

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Key - ignition	AL525316	2	
2	Washer - Locking	AL514335	1	
3	Spacer	AL514336	1	
4	Switch - Ignition	AL525315	1	
5	Light Switch	AL514328	1	
6	Cap	AL514337	1	
7	Seat - Switch	AL514327	2	
8	Cable Tie	3966	2	
9	Lens	AL514980	1	
10	Clip	AL521606	2	
11	Bulb	AL514251	2	
12	Holder	AL514252	2	
13	Solenoid	AL521361	1	
14	Horn Audible	AL514319	1	
15	Circlip	AL701296	1	
16	Loom	AL521364	1	
17	Lead - Pos	AL514889	1	
18.	Lead - Pos	AL521366	1	
19.	Fuse 5 Amp	AL514473	1	
20	Battery	AL451000	1	
21	Starter Relay	AL514468	1	
22	Screw	AL701138	1	

