


ILLUSTRATED PARTS


AMERICAN  AMERICAN
M A D E O W N E D
OUTDOOR POWER EQUIPMENT



1994

**Hydrostatic
Lawn Tractors
600-609; 690-699 Series**

Style 0



Style 0

PARTS LIST FOR MODELS 600 AND 690 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	17551A	N	Hood	24	725-0201	N	Ignition Key
2	738-0724		Shld. Bolt .375" Dia. x .125" Lg.	25	746-0616A		Choke Control†
3	736-0342		Fl-Wash. .28" I.D. x .75" O.D.		746-0614A		Choke Control††
4	710-0258		Hex Bolt 1/4-20 x .62" Lg.*		746-0720		Choke Control (Tec.)
5	736-0329		L-Wash. 1/4" I.D.*		746-3021		Choke Control (Vanguard)
6	712-0287		Hex Nut 1/4-20 Thd.*	26	725-0634		Light Switch**
7	749-0812		Grille Support Rod	27	725-0925		Ammeter**
8	731-1099A		Headlight Lens	32	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
9	712-0380		Flange L-Nut 1/4-28 Thd.	35	17871A		Fender w/Cutout
10	731-1097B		Grille	38	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.
11	736-3078		Fl-Wash. .344" I.D. x 1" O.D.	41	831-0823A		Throttle Box Ass'y.
12	712-0267		Hex Nut 5/16-18 Thd.*	42	710-0779A		Truss Mach. AB-Tap Scr. #10 x .5" Lg.
13	725-0963		Lamp	43	746-0501		Throttle Control Wire†
14	725-1649		Socket		746-0634		Throttle Control Wire††
15	710-0703		Carriage Bolt 1/4-20 x .75" Lg.		746-0638		Throttle Control Wire (12 H.P. Tec.)
16	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.	44	777-9206		Grille Reflector Label
17	736-0173	N	Fl-Wash. .281" I.D. x .73" O.D.	45	710-0603		Hex Wash. Hd. B-Tap Scr. 5/16-18 x .5" Lg.
18	726-0233		Bolt Retainer 1/4" I.D.	46	17782		Choke Retainer
19	712-0185		Speed Nut 1/4-20 Thd.	47	710-0642		Hex TT-Tap Scr. 1/4-20 x .75" Lg.
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.	—	See Chart		Muffler (Single Cylinder Engines)
21	17632A		Gas Tank Support Brkt.				
22	731-1096B		Dash w/Ammeter Hole				
23	731-1337		Dash				
	725-0267		Ignition Switch				

** Optional Parts


† Used w/Single Cylinder Engine Only.

†† Used w/Twin Cylinder Engine Only.

†MUFFLER CHART

Engine	Muffler	Hardware & Related Parts
11.5, 12 & 12.5 H.P. B&S	751-0302	712-0250 Conduit L-Nut
12 & 12.5 H.P. Tecumseh	751-0443A	721-0208 Gasket 738-0636 Shoulder Bolts

Style 4



Style 4


PARTS LIST FOR MODELS 604 AND 694 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
2	712-0147		Speed Nut #10-24 Thd.†	75	725-1396		Ignition Switch
4	721-0208		Gasket†	76	731-1433		Hood
5	710-0323		Truss Mach. Scr. 5/16-18 x .75"†	77	710-0779A		Truss Mach. AB-Tap Scr. #10 x .5" Lg.
6	736-0607		External L-Wash. 5/16" I.D.†				Light Switch
7	725-0980		Ground Wire†	78	725-0634		Choke Control†
8	16936		Muffler Heat Shield—Front†	79	746-3021		Choke Control††
9	683-0042		Muffler Heat Shield—L.H.†		746-0614A		Hex Wash. Hd. Tap Scr. 1/4 x .75" Lg.
10	710-0224		Hex Wash. Tap Scr. #10 x .5" Lg.†	80	710-0642		Hex Tap Scr. 1/4-20 x .5" Lg.
11	710-0294		Hex Bolt 1/4-20 x 3/8" Lg.*†	81	710-0599		Push Nut Fastener
12	738-0636		Shld. Bolt 7/16" Dia. x 3-5/8" Lg.†	82	726-0233		FI-Wash. .27" I.D. x .948"
				83	736-0176		Ammeter
13	712-0287		Hex Nut 1/4-20 Thd.*	84	725-0925		Speed Nut 1/4-20 Thd.
14	736-0329		L-Wash. 1/4" I.D.	85	712-0185		Dash Panel
16	736-3078		FI-Wash. .344" I.D. x 1" O.D.	86	731-0961A		Hex Wash. Hd. B-Tap Scr. 1/4 x .62" Lg.
25	736-0175		Spr. Wash. .265" I.D.†	87	710-0896		Hood Reinforcement
26	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.	88	783-0121	N	Hood Hinge
27	736-0142		FI-Wash. .218" I.D. x .5" O.D.	89	783-0123	N	Hood Reinforcement Spacer
32	731-0911		Rubber Foot Pad—L.H. (Optional)	90	17762		Light Bracket
	731-0912		Rubber Foot Pad—R.H. (Optional)	92	17223		Hex L-Nut 5/16-18 Thd.
33	710-0118		Hex Bolt 5/16-18 x .75" Lg.*	93	712-0158		Hex L-Nut 1/4-20 Thd.
38	710-0258		Hex Bolt 1/4-20 x .62" Lg.*	94	712-0107		Hex Jam Nut 5/16-18 Thd.
44	751-0465		Muffler†	95	712-3007		Hex Bolt 5/16-18 x 7/8" Lg.
51	712-0267		Hex Nut 5/16-18 Thd.*	96	710-3038		Truss Mach. B-Tap Scr. #10 x .5" Lg.
52	736-0275		FI-Wash. .343" I.D. x .687"	97	710-0351		Side Cover—R.H.
60	731-0955		Steering Wheel Insert (Optional)	98	731-1434	N	Side Cover—L.H. (Not Shown)
65	783-0041		Pivot Bar Brkt.		731-1435	N	Grille
66	17324B		Fender	99	731-1442	N	Lens—L.H.
67	710-0167		Carriage Bolt 1/4-20 x .62" Lg.	100	731-0949		Lens—R.H.
68	725-3000		Reflector (Optional)		731-0948		Twist Lock—Lamp Socket
70	746-0501		Throttle Wire 18.5" Lg.†	101	725-1650		Lamp
	746-0634		Throttle Wire 35" Lg.††	102	725-0963		Headlight Housing
71	831-0823A		Throttle Control Box Ass'y.	103	731-0705		Dash Support Brkt.
72	725-1341B		Ignition Key	104	17300D		Support Brkt.
73	725-1346		Ignition Switch Nut	105	17633A		Choke Retainer
74	725-1347		Ignition Switch Cap	106	17782		Engine Pulley (30" Deck Only)
				107	756-0522		

†Used with single cylinder engine only.

††Used with twin cylinder engine only.

Style 5



Style 5

PARTS LIST FOR MODELS 605 AND 695 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	783-0250	N	Hood	41	831-0823A		Throttle Box Ass'y.
2	738-0724		Shld. Bolt .375" Dia. x .125" Lg.	42	710-0779A		Truss Mach. AB-Tap Scr.
3	736-0342		Fl-Wash. .28" I.D. x .75" O.D.				#10 x .5" Lg.
6	712-0287		Hex Nut 1/4-20 Thd.*	43	746-0501		Throttle Control Wire†
8	731-1099A		Headlight Lens		746-0634		Throttle Control Wire††
9	712-0380		Flange L-Nut 1/4-28 Thd.	44	777-9206		Grille Reflector Label
10	731-1097B	N	Grille	45	710-0603		Hex Wash. Hd. B-Tap Scr.
11	736-3078		Fl-Wash. .344" I.D. x 1" O.D.				5/16-18 x .5" Lg.
12	712-0267		Hex Nut 5/16-18 Thd.*	46	17782		Choke Retainer
13	725-0963		Lamp	47	710-0642		Hex TT-Tap Scr. 1/4-20 x .75"
14	725-1649		Socket				Lg.
15	710-0703		Carriage Bolt 1/4-20 x .75" Lg.	48	736-0270		Bell-Wash. 1/4" I.D.
16	710-0599		Hex Wash. Hd. TT-Tap Scr.	49	783-0150	N	Side Panel—R.H.
			1/4-20 x .5" Lg.	50	783-0151	N	Side Panel—L.H.
17	736-0173		Fl-Wash. .281" I.D. x .73" O.D.	51	17199		Cooling Fan†
18	726-0233		Bolt Retainer 1/4" I.D.	52	16936		Muffler Heat Shield—Front†
19	712-0185		Speed Nut 1/4-20 Thd.	53	710-0323		Truss Mach. Scr. 5/16-18 x .75"
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.				Lg.†
21	17632A		Gas Tank Support Brkt.	54	725-0980		Ground Wire†
22	731-1096B	N	Dash	56	736-0175		Spr. Wash. 1/4" I.D.†
23	725-0267		Ignition Switch	58	710-0294		Hex Bolt 1/4-20 x 3/8" Lg.†
24	725-0201		Ignition Key	60	710-0429		Hex B-Tap Scr. #10 x .38" Lg.†
25	746-0616A		Choke Control†	61	738-0636		Shoulder Bolt†
	746-0614A		Choke Control††	63	721-0208		Exhaust Gasket†
	746-3021		Choke Control (Vanguard)	64	683-0042		Muffler Heat Shield—L.H.†
	746-0720		Choke Control (16 H.P. Tec.)	65	712-0147		Speed Nut #10-24 Thd.†
26	725-0634		Light Switch	69	751-0465		Muffler†
27	725-0925		Ammeter	70	736-0329		L-Wash. 1/4" I.D.*
32	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.	—	See Chart		Muffler (Single Cylinder Engines)
35	17871A		Fender w/Cutout				
38	710-0726		Hex Wash. Hd. AB-Tap Scr.				
			5/16 x .75" Lg.				

** Optional Parts


† Used w/Single Cylinder Engine Only.

†† Used w/Twin Cylinder Engine Only.

†MUFFLER CHART

Engine	Muffler	Hardware & Related Parts
11.5, 12 & 12.5 H.P. B&S	751-0302	712-0250 Conduit L-Nut
12 & 12.5 H.P. Tecumseh	751-0443A	721-0208 Gasket 738-0636 Shoulder Bolts

Style 7



Style 7

PARTS LIST FOR MODELS 607 AND 697 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	783-0020		Hood	26	725-0634		Light Switch
2	738-0724		Shld. Bolt .375" Dia. x .125" Lg.	27	725-0925		Ammeter
3	736-0342		Fl-Wash. .28" I.D. x .75" O.D.	32	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
4	710-0206		Hex Bolt 1/4-20 x .88" Lg.*	35	17871A		Fender w/Cutout
5	736-0329		L-Wash. 1/4" I.D.*	41	831-0823A		Throttle Box Ass'y.
6	712-0287		Hex Nut 1/4-20 Thd.*	42	710-0779A		Truss Mach. AB-Tap Scr. #10 x .5" Lg.
7	749-0916		Grille Support Rod				Throttle Control Wire†
8	731-1362		Headlight Lens	43	746-0501		Throttle Control Wire††
9	712-0380		Flange L-Nut 1/4-28 Thd.		746-0634		Throttle Control Wire (12 H.P. Tec.)
10	783-0018		Grille		746-0638		Throttle Control Wire (16 H.P. Tec.)
11	736-0119		L-Wash. 5/16" I.D.*		746-0637		Hex Wash. Hd. B-Tap Scr. 5/16-18 x .5" Lg.
12	712-0267		Hex Nut 5/16-18 Thd.*				Choke Retainer
13	725-0963		Lamp	45	710-0603		Dash Reinforcement Brkt.—L.H.
14	725-1651		Socket				Dash Reinforcement Brkt.—R.H.
15	710-0703		Carriage Bolt 1/4-20 x .75" Lg.	46	17782	N	Hood Spring
16	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.	49	783-0035A	N	Flat Fastener (Special)
18	726-0233		Bolt Retainer 1/4" I.D.	50	783-0036A		Fl-Wash. .344" I.D. x 1" O.D.
19	726-0130		Speed Nut #10-24 Thd.	51	732-0714		Spr. Wash. .39" I.D. x .62" O.D.
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.	52	726-0326		Bell-Wash. .345" I.D. x .88" O.D.
21	17633A		Gas Tank Support Brkt.	53	736-3078		Pan Hd. Scr. 1/4-20 x .75" Lg.
22	731-1348		Dash	54	736-0413		Truss Mach. Scr. #10-24 x .5" Lg.
23	725-0267		Ignition Switch	55	736-0242		Muffler (Single Cylinder Engines)
24	725-0201		Ignition Key	56	710-0924		
25	746-0616A		Choke Control†	57	710-0351		
	746-0614A		Choke Control††	—	See Chart		
	746-3021		Choke Control (Vanguard)				
	746-3026	N	Choke Control (Tec.)				


† Used w/Single Cylinder Engine Only.

†† Used w/Twin Cylinder Engine Only.

†MUFFLER CHART

Engine	Muffler	Hardware & Related Parts
11.5, 12 & 12.5 H.P. B&S	751-0302	712-0250 Conduit L-Nut
12 & 12.5 H.P. Tecumseh	751-0443A	721-0208 Gasket 738-0636 Shoulder Bolts

Style 8



Style 8

PARTS LIST FOR MODELS 608 AND 698 LAWN TRACTORS


REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	16787A		Hood	42	710-1026		Hex TT-Tap Scr. 1/4-20 x 1.75" Lg.
2	710-0206		Hex Bolt 1/4-20 x .88" Lg.				Rear Fender w/Cutout
3	736-0413		Washer .39" I.D. x .62"	44	17871A		Spacer 1.32" Lg.
4	683-0042		Muffler Heat Shield—L.H.†	52	750-0768		Support Brkt.
5	712-0147		Speed Nut #10-24 Thd.†	53	17633A		Truss Hd. Scr. 1/4-20 x .75"
6	712-0272		Hex Sems Nut #10-24 Thd.*	54	710-0255		Side Panel—R.H.†
7	710-0429		Hex B-Tap Scr. #10 x .38" Lg.†	55	17308A		Side Cover—R.H. (Tec.)†
8	727-0290		Hood Stop		16723		Side Cover w/Foam—R.H. (B&S)††
9	710-0473		Truss Hd. Scr. #10-24 x 1/2"		17458A		Side Panel—L.H. (Not Shown)†
10	16936		Muffler Heat Shield—Front†		17309A		Side Cover w/Foam—L.H. (Not Shown)††
11	710-0603		Hex Wash. Hd. B-Tap Scr. 5/16-18 x .5" Lg.		17459A		Truss Mach. Scr. 1/4-20 x .50" Lg.*
12	17199		Cooling Fan†	56	710-0286		Fl-Wash. .281" I.D. x .73" O.D.
13	736-3078		Fl-Wash. .344" I.D. x 1" O.D.				Throttle Control Box Ass'y.
14	710-0599		Hex Tap Scr. 1/4-20 x .5" Lg.†	57	736-0173		Throttle Control Wire (B&S)†
15	725-0963		Bulb	59	831-0823A		Throttle Control Wire (Tec.)†
16	725-1650		Twist Lock—Bulb Socket	60	746-0500		Throttle Control Wire (B&S)††
17	731-0705		Headlight Housing		746-0638		Ignition Key
18	731-0706		Lens		746-0634		Ignition Switch
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.*		725-0201		Dash Panel
21	15806B		Grille	63	725-0267		Light Switch
	16456B		Grille—Used w/Headlight Bezel	64	17295		Ammeter
22	17300D		Dash Support Bracket	65	725-0634		Trim Strip—31"
23	736-0119		L-Wash. 5/16" I.D.*	66	725-0925		Hood Spring
24	712-0267		Hex Nut 5/16-18 Thd.*	67	731-0511-31		Hex Scr. #10-24 x 1.0" Lg.
25	738-0759		Shld. Spacer	68	732-0462		Hex Wash. Hd. Tap Scr. 1/4 x .75" Lg.
26	710-0294		Hex Bolt 1/4-20 x 3/8" Lg.†	69	710-0749		Foam Strip 3/8 x 1-1/8" x 1-1/2 Lg. (4 Req'd.)
27	736-0175		Spr. Wash. 1/4" I.D.†	73	710-0642		Choke Control 29" Lg.†
33	721-0208		Exhaust Gasket†	77			Choke Control 46" Lg.††
34	751-0465		Muffler (B&S)†		710-0779A		Truss Mach. AB-Tap Scr. #10 x .5" Lg.
	751-0443A		Muffler (Tec.)†	78	722-0157		Headlight Bezel**
35	738-0636		Shoulder Bolt†				Truss Mach. Scr. 1/4-20 x .5" Lg.
36	712-0287		Hex Nut 1/4-20 Thd.*	82	746-0615A		Retainer Clip
37	736-0329		L-Wash. 1/4" I.D.*		746-0613A		
38	710-0323		Truss Mach. Scr. 5/16-18 x .75" Lg.*†	83	710-0779A		
39	725-0980		Ground Wire 7.5"†	86	731-0967		
40	731-0511-12		Trim Strip—12"	88	710-0286		
41	712-0264		Acorn Nut 1/4-20 Thd.	89	17782		

**Optional Parts

†Used with Single Cylinder Engine Only.

††Used with Twin Cylinder Engine Only.

Style 9



Style 9

PARTS LIST FOR MODELS 609 AND 699 LAWN TRACTORS


REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
3	710-0118		Hex Bolt 5/16-18 x .75" Lg.	40	710-1005		Hex Wash. Hd. Tap Scr. 1/4-20 x .5" Lg.
5	710-0603		Hex Wash. Hd. Scr. 5/16" x .5" Lg.	41	731-1048B	N	Dash
7	710-0167		Carriage Bolt 1/4-20 x .5" Lg.	42	725-0925		Ammeter
8	710-0726		Hex Wash. Hd. Tap Scr. 5/16 x .75" Lg.	43	831-0823A		Throttle Control Box Ass'y.
9	17633A		Support Bracket	44	710-0919		Mach. Scr. #10 x .44" Lg.
10	17300D		Dash Support Bracket	45	746-0616A		Choke Control 23" Lg.†
11	17324B		Rear Fender		746-0614A		Choke Control 38" Lg.††
12	730-3000		Reflector (Optional)	46	746-0501		Throttle Control Wire 18.5" Lg.†
14	17308A		Side Panel—R.H.†		746-0634		Throttle Control Wire 35" Lg.††
	17309A		Side Panel—L.H. (Not Shown)†		746-0638		Throttle Control Wire 22" Lg. (16 H.P. Tec.)
	16723		Side Panel—R.H. (16 H.P. Tec.)	47	725-0267		Ignition Switch
	17458A		Side Panel w/Foam—R.H.††	48	725-0201		Ignition Key
	17459A		Side Panel Ass'y. w/Foam—L.H. (Not Shown)††	49	731-1491	N	Hood—Red
15	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.		731-1492	N	Hood—Midnight Blue
16	710-0166		Truss Mach. Scr. 1/4-20 x 1.0" Lg.		731-1497	N	Hood—Oyster Gray
17	710-1026		Hex Wash. TT-Tap Scr. 1/4-20 x 1.75" Lg.		731-1531	N	Hood—Charcoal Gray
18	750-0768		Spacer .26" I.D. x 1.32"		731-1532	N	Hood—Orange
19	710-0642		Hex Rolling Tap Scr. 1/4-20 x .75" Lg.		731-1533	N	Hood—Green
21	731-0511-18		Trim Strip—18" Lg.	50	17199		Cooling Fan†
22	736-0329		L-Wash. 1/4" I.D.*	52	16936		Muffler Heat Shield—Front†
23	712-0287		Hex Nut 1/4-20 Thd.*	53	710-0323		Truss Mach. Scr. 5/16-18 x .75" Lg.†
24	726-0201		Speed Nut 5/16" Thd.	54	725-0980		Ground Wire†
25	712-0267		Hex Nut 5/16-18 Thd.*	56	736-0175		Spr. Wash. 1/4" I.D.†
26	736-3078		Fl-Wash. .344" I.D. x 1" O.D.	58	710-0294		Hex Bolt 1/4-20 x 3/8" Lg.*†
27	17410		Grille Ass'y.	60	710-0429		Hex B-Tap Scr. #10 x .38" Lg.†
28	731-1044		Headlight Lens	61	738-0636		Shoulder Bolt†
29	731-0705		Headlamp Housing	63	721-0208		Exhaust Gasket†
30	725-0963		Headlamp	64	683-0042		Muffler Heat Shield—L.H.†
31	725-1650		Twist Lock Lamp Socket	65	712-0147		Speed Nut #10-24 Thd.†
32	736-0242		Bell-Wash. .345" I.D. x .88"	69	751-0465		Muffler†
33	712-0429		Hex L-Nut 5/16-18 Thd.	71	749-0814		Grille Support Tube
34	735-0126		Rubber Washer	73	736-0607		External L-Wash. 5/16" I.D.
35	783-0190	N	Hood Hinge	76	17782		Choke Retainer
36	710-0599		Hex Wash. Hd. B-Tap Scr. 1/4-20 x .5" Lg.	77	725-0634		Light Switch
37	750-0218		Spacer .262" I.D. x .31"	78	736-3010		Fl-Wash. .406" I.D. x .812" O.D.
39	16903A		Hood Plate	79	710-0258		Hex Bolt 1/4-20 x .62" Lg.
				80	783-0013		Dash Fastening Tab
				81	725-0157		Cable Tie
				82	777-8568A	N	Chrome Label

† Used with Single Cylinder Engine Only.

†† Used with Twin Cylinder Engine Only.

Models 600 thru 609

Models 690 thru 699



Models 600 thru 609

Models 690 thru 699


REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	731-0220		Steering Wheel Cap	34	**		Front Wheel Rim Only
	731-1459	N	Steering Wheel Cap (Sq.—MTD)	35	**		Bearing
	731-1460	N	Steering Wheel Cap (Square—No Logo)	36	736-0285		Fl-Wash. .635 I.D. x 1.59" O.D.
2	712-0411		Hex L-Nut 5/16-24 Thd.	37	731-0484A		Front Wheel Hub Cap
3	736-0242		Belleville Wash. .345" I.D.		731-1787		Spoked Hub Cap (Yellow—Optional)
4	731-0805		Steering Wheel (3 Spoke)†		734-1613		Spoked Hub Cap (Gray—Optional)
	731-1406	N	Steering Wheel (3 Spoke)††		734-1612		Spoked Hub Cap (Beige—Optional)
	731-0806A		Steering Wheel (4 Spoke)†				
5	731-0559		Steering Bellow—4.5" (Style 8)	38	714-0470		Cotter Pin 1/8" Dia. x 1.25"
	731-0954		Steering Bellow—9" (Style 0, 1, 3, 4, 5, 6, 9)	39	736-0187		Fl-Wash. .640" I.D. x 1.24" O.D.
	731-1542	N	Steering Bellow—3.25" (Style 7)	40	726-0214		Push Cap 5/8" Dia. Rod
6	737-0280		Grease Fitting (Optional)	42	712-0446		Hex Jam Nut 3/8-24 Thd.
7	741-0587		Flange Bearing .628" I.D. x 1.36 O.D. (Style 8)	43	710-0538		Hex L-Bolt 5/16-18 x .62"
				44	736-0119		L-Wash. 5/16" I.D.*
9	17198A		Retainer Plate	45	736-0343		Fl-Wash. .33" I.D. x 1.25" O.D.
10	738-0141		Shoulder Bolt .437" Dia. x .35 Lg. 5/16-18 Thd.	46	750-0532		Spacer (Plastic)
				47	712-0214		Hex Cent. L-Nut 3/8-24 Thd.
11	710-0152		Hex Bolt 3/8-24 x 1.0" Lg. (Gr. 5)	48	736-0169		L-Wash. 3/8" I.D.*
13	750-0535		Spacer .380" I.D. x .625" O.D. x .227	49	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
				50	736-0119		L-Wash. 5/16" I.D.*
14	736-0217		L-Wash. 3/8" I.D. (H.D.)	51	717-0622A		Steering Gear Segment
15	710-0726		Hex Wash. Hd. Self-Tap Scr.	52	741-0225		Hex Flg. Brg. .634 I.D.
16	711-1001		Steering Drag Link	53	736-0187		Fl-Wash. (Hardened)
17	783-0041		Front Pivot Brkt.	54	738-0743		Steering Shaft
18	738-0527		Shoulder Bolt .498" Dia. x 2.04 Lg. 3/8-16 Thd.	57	710-0837		Oval Hd. Cr.—Sunk Scr. #10 x 5/8" Lg. (Style 8)
							Wave-Wash. .32" I.D. x .62" O.D.
19	712-0798		Hex Nut 3/8-16 Thd.*	58	736-0271		Fl-Wash. (Hardened)
20	736-0169		L-Wash. 3/8" I.D.*	59	736-0187		Drag Link Ball Joint 3/8-24 Thd.
21	712-0411		Hex L-Nut 5/16-24 Thd.	60	723-3018		Ext. L-Wash. 5/16" I.D.
22	16481A		Steering Arm Front Axle	61	736-0607		Spring Clip (Used w/Spoked Hub Cap)
23	710-0772		Hex Bolt 5/16-24 x 2.00" Lg. (Grade 5)	63	727-0425A		Bell-Wash. .39" I.D. x 1.38" O.D.
24	741-0487A		Hex Flg. Brg. .632 I.D.	64	736-0356		Pivot Bar End Cap (Optional)
25	683-0002		Pivot Bar Ass'y.	65	731-1291		Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
26	**		Front Axle Ass'y.—L.H.	66	710-0459		Plastic Tube 1.54" Lg.
27	712-0241		Hex Nut 3/8-24 Thd.*	69	731-1389		Steering Wheel Insert (Optional)
28	736-0169		L-Wash. 3/8" I.D.*	70	731-0955		Upper Steering Shaft (Used w/46" Deck)
29	723-3018		Ball Joint 3/8-24 Thd.	72	738-0886		Lower Steering Shaft (Used w/46" Deck)
30	747-0753		Tie Rod (Adjustable)				
	747-0861		Tie Rod (Non-Adjustable)	73	650-0001		Hex Bolt 1/4-20 x 1.25" Lg.
31	712-0711		Hex Jam Nut 3/8-24 Thd.*	74	710-0958		Hex L-Nut 1/4-20 Thd.
32	**		Front Axle Ass'y.—R.H.	75	712-0324		
33	**		Wheel Ass'y. Comp.				

† Uses Round Steering Wheel Cap
†† Uses Square Steering Wheel Cap


*For faster service obtain standard nuts, bolts and washers locally.
If these items cannot be obtained locally, order by part number and size as shown on parts list.

**FRONT WHEEL CHART

Description	15" x 6" Plastic Bearing	15" x 6" Plastic Bearing	15" x 6" Ball Bearing
Wheel Ass'y. Comp.	634-0056	634-0105	634-0059
Tire Only	734-0864	734-1731	734-0864
Rim Only	634-0024	634-0024	634-0051
Bearing	741-0487A	741-0487A	741-0569
Air Valve	734-0255	734-0255	734-0255
Grease Fitting (Optional)	737-0211	737-0211	737-0280
Grease Plug	737-0212	737-0212	—
Front Axle Ass'y.—L.H.	17585	17585	17585
Front Axle Ass'y.—R.H.	17584	17584	17584
Front Axle Ass'y.—L.H. (46" Deck)	683-0041	683-0041	683-0041
Front Axle Ass'y.—R.H. (46" Deck)	683-0040	683-0040	683-0040



Models 600 thru 609



****REAR WHEEL CHART**

Description	18" x 9.50"	18" x 6.50"	18" x 9.50"
Wheel Ass'y. Comp.	734-0817	734-0592	634-0103
Tire Only	734-0448	734-0294	734-1730
Rim Only	634-0070	634-0069	634-0070

Round Shoulder	Square Shoulder

Models 600 thru 609

PARTS LIST FOR MODELS 600 THRU 609 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
4	731-1053B		Index Bracket	56	736-0329		L-Wash. 1/4" I.D.*
5	710-0924		Pan Hd. Mach. Scr. 1/4-20 x .75" Lg.	57	712-0287		Hex Nut 1/4-20 Thd.*
6	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.	58	714-0104		Hairpin Clip
7	712-0138		Hex Nut 1/4-28 Thd.	59	736-0262		FI-Wash. .375" I.D. x .87" O.D.
8	736-0329		L-Wash. 1/4" I.D.*	60	736-0413		Spring Wash. .39" I.D.
9	750-0777		Shld. Spacer .38" I.D.	61	712-0116		Hex L-Nut 3/8-24 Thd.
10	710-0195		Hex. Bolt 1/4-28 x .62" Lg.	62	712-0711		Hex Jam Nut 3/8-24 Thd.
11	17619B		Lower Frame Ass'y.	63	783-0090A	N	Neutral Return Brkt.
12	710-1007		Hex Tap Scr. 3/8-16 x 1.5" Lg.	64	711-0832		Ferrule 3/8-24 Thd.
	710-0502A		Hex L-Wash. TT-Tap Scr. 3/8-16 x 1.25" Lg.	65	747-0365		Control Rod
13	736-0247		FI-Wash. .406" I.D. x 1.25"	66	723-0351		Ball Joint 3/8-24 Thd.
14	725-1426		Solenoid	67	748-0234		Shld. Spacer .5" Dia. x .27" Lg.
15	736-0222		Ext. L-Wash. 1/4" I.D.	68	736-0159		FI-Wash. .349" I.D. x .879" O.D.
16	17893		Belt Guard Brkt. Ass'y.	69	710-3007		Hex Wash. Hd. Tap Scr. #12 x 3/8" Lg.
	17358C		Belt Guard Brkt. Ass'y. (14 H.P. OHV only)	70	731-1449		Fan
17	714-0114		Sq. Key 1/4" x 2" Lg.	71	712-0333		Hex Nut 1/2-20 Thd.
18	756-0562		Engine Pulley	72	736-0921		L-Wash. 1/2" I.D.*
	756-0633		Engine Pulley (14 H.P. OHV only)	73	712-0241		Hex Nut 3/8-24 Thd.
19	711-0986		Belt Guard Stud 3.6" Lg.	74	736-0169		L-Wash. 3/8" I.D.
20	736-0322		FI-Wash. 7/16" I.D. x 1.25" O.D.	75	756-0974		Transmission Pulley
21	736-0171		L-Wash. 7/16" I.D.*	76	732-0729		Wire Ring
22	710-0757		Hex Bolt 7/16-20 x 1.5" Lg.	77	754-0349		"V"-Belt
23	735-0196		Foot Pad	78	756-0981		FI-Idler Pulley 2.75" O.D.
24	683-0049		Brake Lockout Brkt. Ass'y.	79	720-0238		Rod End Grip
25	783-0091A	N	Foot Pedal Brkt.	80	747-0894		Bypass Control Lever
26	732-0728		Foot Pedal Return Spring	81	783-0085		Transaxle Support Brkt.-L.H.
27	738-0296		Shld. Bolt .437" Dia. x .268"	82	710-0528		Hex. Bolt 5/16-18 x 1.25" Lg.
28	736-0406		FI-Wash. 7/16" I.D. x 1-3/8" O.D.	83	732-0384		Ext. Spring 6.12
29	747-0608	N	Lock-up Rod	84	683-0048		Idler Brkt. Ass'y.
30	17755A		Bracket	85	710-0116		Hex Bolt 5/16-18 x 2.5" Lg.*
31	736-0119		L-Wash. 5/16" I.D.*	86	710-0118		Hex Bolt 5/16-18 x .75" Lg.*
32	712-0267		Hex Nut 5/16-18 Thd.*	87	748-0234		Shld. Spacer .5" Dia. x .27" Lg.
33	720-0166		Ball Knob	88	783-0086A	N	Transaxle Support Brkt.-R.H.
34	732-0727		Neutral Return Spring	89	747-0886		Brake Rod 24.94" Lg.
35	712-0273		Hex Nut 5/16-24 Thd.	90	732-0716		Ext. Spring
36	736-3078		FI-Wash. .344" I.D. x 1" O.D.	91	747-0893		Bypass Actuator Rod
37	783-0092		Scissor-Flat	92	736-0142		FI-Wash. .281" I.D. x .5" O.D.
38	736-0362		FI-Wash. .33" I.D. x 1.25" O.D.	93	783-0098		Bypass Adjustment Brkt.
39	750-0808		Spacer	94	736-0222		External L-Wash. 1/4" I.D.
40	736-0219		Bell-Wash. .4" I.D. x 1.13" O.D.	95	731-1086A		Sleeve .758" I.D. x 1" O.D.
41	761-0196		Friction Washer	96	710-0604		Hex. Wash. TT-Tap Scr. 5/16-18 x .62" Lg.
42	750-0918		Centering Gauge Spacer	97	17994		Retainer Brkt.-Transaxle
43	783-0095		Neutral Return Mtg. Brkt.	98	710-1266		Hex Bolt 5/16-18 x 3.5" Lg. (Gr. 5)
44	736-0270		Bell-Wash. .265" I.D. x .75" O.D.	99	732-0250		Tension Spring
45	732-0718		Comp. Spring 1.19" Lg.	100	710-0888		Hex Bolt 5/16-24 x 1" Lg. (Special)
46	736-3008		FI-Wash. .312" I.D. x .75" O.D.	101	710-0224		Hex Wash. Hd. AB-Tap Scr. #10 x .5" Lg.
47	712-0123		Hex Nut 5/16-24 Thd.	102	748-0334		Transaxle Spacer
48	710-0299		Hex Bolt 1/4-28 x 1" Lg. (Gr. 5)	103	712-3019		Hex Nut 7/16-14 Thd. (Gr. 5)
49	710-1012		Rib Neck Bolt 5/16-24 x .84" Lg.	104	736-3015		FI-Wash. .469" I.D. x .875" O.D.
50	783-0093		Scissor-Offset	105	736-0439		Bell-Wash. .46" I.D. x 1.13" O.D.
51	747-0887		Neutral Return Rod	106	710-0505		Hex Bolt 7/16-14 x 1" Lg.
52	738-0879		Friction Disc Stud	107	647-0008A	N	Speed Control Lever Ass'y.
53	748-0368		Shld. Spacer	108	17668		Axle Support Brkt.-R.H.
54	783-0096		Neutral Return Lever		17669		Axle Support Brkt.-L.H.
55	736-3092		FI-Wash. .265" I.D. x 1" O.D.				(Not Shown)

Models 600 thru 609


PARTS LIST FOR MODELS 600 THRU 609 LAWN TRACTORS (CONTINUED)

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
109	732-0433		Ext. Spring 2.75" Lg.	128	756-0116		Idler Pulley (14 H.P. OHV Only)
110	736-0141		Spr-Wash. .445" I.D. x .75" O.D.	129	736-0280		Fl-Wash. .39" I.D. (14 H.P. OHV Only)
111	17840		Transaxle Mtg. Brkt.	130	712-0798		Hex Nut 3/8-16 Thd.*
112	725-3169A		Safety Switch (Clutch)	131	720-0218		Shift Knob
113	17962		Switch Plate	132	783-0014		Hitch Plate Extension
114	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.	133	731-1481		Vent Cap
115	710-0650		Hex Wash. TT-Tap Scr. 5/16-18 x .75" Lg.	134	731-1480		Plastic Vent
116	17715B	N	Clutch/Brake Pedal Ass'y.	135	726-0324		Clamp
117	750-0802		Spacer .63" I.D.	136	721-0330		"O"-Ring
118	17860		Pedal Bracket	137	731-1485		Hose Fitting
119	736-0264		Fl-Wash. .344" I.D. x .62" O.D.	138	751-0588-18		Fuel Line 18" Lg.
120	714-0111		Cotter Pin 3/32" Dia.	139	710-0627		Hex Bolt 5/16-24 x .75" Lg.
121	714-0470		Cotter Pin 1/8" Dia.	140	736-0242		Bell-Wash. .345" I.D. x .88" O.D.
122	736-0256		Fl-Wash. .64" I.D. x .94" O.D.	141	734-0255		Air Valve
123	710-0227		Hex Wash. Hd. AB-Tap Scr. #8 x .5" Lg.	142	**		Rim Only
124	726-0320		Insulator Nut Plate	143	**		Wheel Ass'y. Comp.
125	725-1643		Reverse Safety Switch	144	734-1615		Tire Only
126	725-1399		Extension Wire		734-1614		Hub Cap (Gray—Optional)
127	710-0520		Hex Bolt 3/8-16 x 1.5" Lg. (14 H.P. OHV Only)		734-1788		Hub Cap (Beige—Optional)
				145	727-0425A		Hub Cap (Yellow—Optional)
							Spring Clip

*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

Models 600 thru 609

TORQUE TO 80-100 IN.-LBS.




PARTS LIST FOR MODELS 600 THRU 609 LAWN TRACTORS

REF. NO.	PART NO.	QTY.	DESCRIPTION
1	718-0255	1	Transmission Comp.
2	HG-9008000-0128	1	Seal—Lip
3	HG-9008000-0126	1	Seal—Lip
4	HG-45074	1	Seal—Lip 10X25X7
5	HG-50126	1	Arm—Bypass
6	HG-44870	1	Ring—Retaining
7	HG-44094	1	Arm—Actuating
8	HG-44891	2	Pin—Actuating
9	HG-50108	1	Nut—Hex Lock 5/16-24 UNJC
10	HG-44130	1	Washer 7/16" x 7/8" x .060"
11	HG-50042	1	Breather Ass'y.
12	HG-45007	1	Arm—Control
13	HG-50034	1	Puck—Dampener
14	HG-50018	1	Set Screw
15	HG-50129	1	Strap, Locking

Models 600 thru 609


Models 690 thru 699



REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
2	710-1208		Hex Wash. Hd. Tap Scr. 5/16-18 x 3.25" Lg.	38	710-0118		Hex Bolt 5/16-18 x .75" Lg.*
3	738-0155		Shld. Bolt .437" Dia. x .162"	39	783-0042	N	Upper Frame—R.H.
4	738-0145		Shld. Bolt .50" Dia. x .84"	41	712-0798		Hex Nut 3/8-16 Thd.*
5	736-0141		Spr-Wash. .445" I.D. x .75	42	732-0581B		Extension Spring 5.31" Lg.
6	783-0039		Seat Pivot Bracket	43	731-1200		Battery Cover
7	751-0603		Fuel Cap	44	725-1635		12-V Battery
8	751-0553		Fuel Tank (12.5 H.P. & Smaller)	45	783-0043	N	Upper Frame—L.H.
	751-0555		Fuel Tank (13 H.P. & Larger)	46	783-0133	N	Shift Cover
9	726-0209		Tie Strap	48	726-0279		Insulator Plate
10	751-0535-15		Fuel Line	49	17951		Seat Pivot Brkt. Support—L.H.
11	726-0205		Hose Clamp	50	17953		Hitch Plate
13	712-0287		Hex Nut 1/4-20 Thd.*	51	712-0267		Hex Nut 5/16-18 Thd.*
14	736-0329		L-Wash. 1/4" I.D.	52	736-0119		L-Wash. 5/16" I.D.*
16	732-0735	N	Compression Spring	53	17239A		Seat Lift Brkt.
21	738-0526		Running Board Rod	54	757-0363		Seat 8-7/8" High
22	710-0227		Hex Wash. Hd. AB-Tap Scr. #8 x .50" Lg.		757-0364		Seat 8-7/8" High (Yellow)
23	726-0139		Speed Nut #10Z		757-0360		Seat 10-5/8" High
24	783-0041		Front Pivot Brkt.		757-0365		Seat 10-5/8" High (Yellow)
25	710-0623		Hex Tap Scr. 3/8-16 x .75"		757-0350		Seat 14-1/4" High
26	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.		757-0372		Seat 14-1/4" High (Yellow)
28	710-0134		Carriage Bolt 1/4-20 x .62"	55	17950		Seat Pivot Brkt. Support—R.H.
29	17770A		Running Board (R.H. & L.H.)	56	738-0296		Shld. Bolt .437" Dia. x .268"
30	761-0168A		Blade Brake Ass'y.	57	725-1303		Spring Switch
32	731-0909		Rubber Foot Pad—L.H.**	59	710-0650		Hex Wash. TT-Tap Scr. 5/16-18 x 7/8" Lg.
	731-0910		Rubber Foot Pad—R.H.**	63	725-1439		Safety Switch (Seat)
	723-0422		Abrasive Foot Pad**	64	732-0674		Battery Tray Clip (Single Cylinder)
33	710-0323		Truss Mach. Scr. 5/16-18 x .75" Lg.*	65	17952		Battery Tray
34	683-0065	N	Lower Frame	66	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.
35	736-0169		L-Wash. 3/8" I.D.*	67	748-0347		Spring Spacer
36	726-0278		Insulator Boss Plate	68	710-1221		Pan Hd. Cutting Scr. 5/16-18 x .75" Lg.
37	736-0264		Fl-Wash. .344" I.D. x .625" O.D.	69	710-0118		Hex Bolt 5/16-18 x .75" Lg.*
				70	731-0405		Snap Bushing

**Optional Parts

Models 690 thru 699



****REAR WHEEL CHART**

Description	20" x 8.0"	20" x 8.0"
Wheel Ass'y. Comp.	734-1675	634-0104
Tire Only	734-1596	734-1730
Rim Only	634-0070	634-0070

Round Shoulder	Square Shoulder

Models 690 thru 699

PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
4	731-1053B		Index Bracket	62	712-0711		Hex Jam Nut 3/8-24 Thd.
5	710-0924		Pan Hd. Mach. Scr. 1/4-20 x .75" Lg.	63	783-0090A		Neutral Return Brkt.
6	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.		783-0097		Neutral Return Brkt. (w/46" Deck)
7	712-0138		Hex Nut 1/4-28 Thd.	64	711-0832		Ferrule 3/8-24 Thd.
8	736-0329		L-Wash. 1/4" I.D.*	65	747-0365		Control Rod
9	750-0777		Shld. Spacer .38" I.D.	66	723-0351		Ball Joint 3/8-24 Thd.
10	710-0412		Hex Bolt 1/4-28 x .75" Lg.	67	748-0234		Shld. Spacer .5" Dia. x .27" Lg.
11	17619B		Lower Frame Ass'y.	68	736-0159		FI-Wash. .349" I.D. x .879" O.D.
12	710-1007		Hex Tap Scr. 3/8-16 x 1.5" Lg.	69	710-3007		Hex Wash. Hd. Tap Scr. #12 x 3/8" Lg.
13	736-0247		FI-Wash. .406" I.D. x 1.25"	70	731-1449		Fan
14	725-1426		Solenoid	71	712-0333		Hex Nut 1/2-20 Thd.
15	736-0222		Ext. L-Wash. 1/4" I.D.	72	736-0921		L-Wash. 1/2" I.D.*
16	17358C		Belt Guard Brkt. Ass'y.	73	712-0241		Hex Nut 3/8-24 Thd.
17	714-0114		Sq. Key 1/4" x 2" Lg.	74	736-0169		L-Wash. 3/8" I.D.
18	756-0633		Engine Pulley	75	756-0975		Transmission Pulley
19	711-0986		Belt Guard Stud 3.6" Lg.	76	732-0729		Wire Ring
20	736-0322		FI-Wash. 7/16" I.D. x 1.25" O.D.	77	754-0441		"V"-Belt
21	736-0171		L-Wash. 7/16" I.D.*	78	756-0981		FI-Idler Pulley 2.75" O.D.
22	710-0757		Hex Bolt 7/16-20 x 1.5" Lg.	79	720-0238		Rod End Grip
23	735-0196		Foot Pad	80	747-0894		Bypass Control Lever
24	683-0049		Brake Lockout Brkt. Ass'y.	81	783-0085		Transaxle Support Brkt.-L.H.
25	783-0091A	N	Foot Pedal Brkt.	82	710-0528		Hex. Bolt 5/16-18 x 1.25" Lg.
26	732-0728		Foot Pedal Return Spring	83	732-0384		Ext. Spring 6.12
27	738-0296		Shld. Bolt .437" Dia. x .268"	84	683-0051		Idler Brkt. Ass'y.
28	736-0406		FI-Wash. 7/16" I.D. x 1-3/8" O.D.		683-0048		Idler Brkt. Ass'y. (w/46" Deck)
29	747-0608	N	Lock-up Rod	85	710-0116		Hex Bolt 5/16-18 x 2.5" Lg.*
30	17755A		Bracket	86	710-0118		Hex Bolt 5/16-18 x .75" Lg.*
31	736-0119		L-Wash. 5/16" I.D.*	87	748-0234		Shld. Spacer .5" Dia. x .27" Lg.
32	712-0267		Hex Nut 5/16-18 Thd.*	88	783-0086A	N	Transaxle Support Brkt.-R.H.
33	720-0166		Ball Knob	89	747-0886		Brake Rod 24.94" Lg.
34	732-0727		Neutral Return Spring	90	732-0716		Ext. Spring
35	712-0273		Hex Nut 5/16-24 Thd.	91	747-0893		Bypass Actuator Rod
36	736-3078		FI-Wash. .344" I.D. x 1" O.D.	92	736-0142		FI-Wash. .281" I.D. x .5" O.D.
37	783-0092		Scissor-Flat	93	783-0098		Bypass Adjustment Brkt.
38	736-0362		FI-Wash. .33" I.D. x 1.25" O.D.	94	736-0222		External L-Wash. 1/4" I.D.
39	750-0808		Spacer	95	731-1086A		Sleeve .758" I.D. x 1" O.D.
40	736-0219		Bell-Wash. .4" I.D. x 1.13" O.D.	96	710-0604		Hex. Wash. TT-Tap Scr. 5/16-18 x .62" Lg.
41	761-0196		Friction Washer	97	17994		Retainer Brkt.-Transaxle
42	750-0918		Centering Gauge Spacer	98	710-0176		Hex Bolt 5/16-18 x 2.75" Lg. (Gr. 5)
43	783-0095		Neutral Return Mtg. Brkt.		710-1266		Hex Bolt 5/16-18 x 3.5" Lg. (Used w/46" Deck)
44	736-0270		Bell-Wash. .265" I.D. x .75" O.D.	99	732-0250		Tension Spring
45	732-0718		Comp. Spring 1.19" Lg.	100	710-0888		Hex Bolt 5/16-24 x 1" Lg. (Special)
46	736-3008		FI-Wash. .312" I.D. x .75" O.D.	101	710-0224		Hex Wash. Hd. AB-Tap Scr. #10 x .5" Lg.
47	712-0123		Hex Nut 5/16-24 Thd.	103	712-3019		Hex Nut 7/16-14 Thd. (Gr. 5)
48	710-0299		Hex Bolt 1/4-28 x 1" Lg. (Gr. 5)	104	736-3015		FI-Wash. .469" I.D. x .875" O.D.
49	710-1012		Rib Neck Bolt 5/16-24 x .84" Lg.	105	736-0439		Bell-Wash. .46" I.D. x 1.13" O.D.
50	783-0093		Scissor-Offset	106	710-0505		Hex Bolt 7/16-14 x 1" Lg.
51	747-0887		Neutral Return Rod	107	647-0008A	N	Speed Control Lever Ass'y.
52	738-0879		Friction Disc Stud	108	17668		Axle Support Brkt.-R.H.
53	748-0368		Shld. Spacer		17669		Axle Support Brkt.-L.H. (Not Shown)
54	783-0096		Neutral Return Lever	109	732-0433		Ext. Spring 2.75" Lg.
55	736-3092		FI-Wash. .265" I.D. x 1" O.D.	110	736-0141		Spr-Wash. .445" I.D. x .75" O.D.
56	736-0329		L-Wash. 1/4" I.D.*	111	17840		Transaxle Mtg. Brkt.
57	712-0287		Hex Nut 1/4-20 Thd.*	112	725-3169A		Safety Switch (Clutch)
58	714-0104		Hairpin Clip				
59	736-0262		FI-Wash. .375" I.D. x .87" O.D.				
60	736-0413		Spring Wash. .39" I.D.				
61	712-0116		Hex L-Nut 3/8-24 Thd.				

Models 690 thru 699


PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS (CONTINUED)

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
113	17962		Switch Plate	132	783-0014		Hitch Plate Extension
114	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.	133	783-0099		Idler Brkt.
115	710-0650		Hex Wash. TT-Tap Scr. 5/16-18 x .75" Lg.	134	731-1480		Plastic Vent
116	17715B		Clutch/Brake Pedal Ass'y.	135	726-0324		Clamp
117	750-0802		Spacer .63" I.D.	136	721-0330		"O"-Ring
118	17860		Pedal Bracket	137	731-1485		Hose Fitting
119	736-0264		Fl-Wash. .344" I.D. x .62" O.D.	138	751-0588-18		Fuel Line 18" Lg.
120	714-0111		Cotter Pin 3/32" Dia.	139	710-0627		Hex Bolt 5/16-24 x .75" Lg.
121	714-0470		Cotter Pin 1/8" Dia.	140	736-0242		Bell-Wash. .345" I.D. x .88" O.D.
122	736-0256		Fl-Wash. .64" I.D. x .94" O.D.	141	734-0255		Air Valve
123	710-0227		Hex Wash. Hd. AB-Tap Scr. #8 x .5" Lg.	142	**		Rim Only
124	726-0320		Insulator Nut Plate	143	**		Wheel Ass'y. Comp.
125	725-1643		Reverse Safety Switch	144	734-1615		Tire Only
126	725-1399		Extension Wire		734-1614		Hub Cap (Gray—Optional)
127	710-0344		Hex Bolt 3/8-16 x 1.5" Lg.		734-1788		Hub Cap (Beige—Optional)
128	756-0116		Idler Pulley	145	727-0425A		Hub Cap (Yellow—Optional)
130	712-0798		Hex Nut 3/8-16 Thd.*				Spring Clip
131	720-0218		Shift Knob	146	731-1481		Vent Cap
				147	750-0258		Spacer .315" I.D. x .75" O.D.
				148	710-3195		Hex Bolt 5/16-18 x 4.5" Lg. (Used w/46" Deck)

*For faster service obtain standard nuts, bolts and washers locally.
If these items cannot be obtained locally, order by part number
and size as shown on parts list.

Models 690 thru 699

TORQUE TO 80-100 IN.-LBS.




PARTS LIST FOR MODELS 690 THRU 699 LAWN TRACTORS

REF. NO.	PART NO.	QTY.	DESCRIPTION
1	718-0255		Transmission Comp.
2	HG-9008000-0128	1	Seal—Lip
3	HG-9008000-0126	1	Seal—Lip
4	HG-45074	1	Seal—Lip 10X25X7
5	HG-50126	1	Arm—Bypass
6	HG-44870	1	Ring—Retaining
7	HG-44094	1	Arm—Actuating
8	HG-44891	2	Pin—Actuating
9	HG-50108	1	Nut—Hex Lock 5/16-24 UNJC
10	HG-44130	1	Washer 7/16" x 7/8" x .060"
11	HG-50042	1	Breather Ass'y.
12	HG-45007	1	Arm—Control
13	HG-50034	1	Puck—Dampener
14	HG-50018	1	Set Screw
15	HG-50129	1	Strap, Locking

Models 600 thru 609


Models 690 thru 699



REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	783-0103		Connecting Rod	25	726-0272		Clamp
2	683-0029		Pivot Link Ass'y.—L.H.	26	738-0526		Running Board Rod
3	683-0028		Pivot Link Ass'y.—R.H. (Uses "E"-Ring)	27	710-3007		Hex Wash. Hd. Tap Scr.
4	17710		Deck Hanger Link Ass'y.	28	14802A		Link Deck Lift Ass'y.
5	14800A		Deck Hanger Link Ass'y.	29	711-0723A		Adj. Ferrule 3/8-24 Thd.
6	14804A		Deck Hanger Link Ass'y.	30	17712		Adj. Deck Lift Link
7	748-0331		Shld. Spacer .318" I.D.	31	712-3066		Hex Nut 1/2-20 Thd. (Gr. 5)
8	736-0264		Fl-Wash. .344" I.D. x .62" O.D.	32	711-0841		Lift Link Adjuster
9	736-0119		L-Wash. 5/16" I.D.*	33	17637A		Lift Shaft Ass'y.
10	712-0267		Hex Nut 5/16-18 Thd.*	34	725-0803C		Safety Switch (Deck)
12	714-0470		Cotter Pin 1/8" Dia.	35	714-0145		Inter. Cotter Pin 3/8" Dia.
13	736-0256		Fl-Wash. .635" I.D. x 1.0" O.D.	36	732-0637		Extension Spring
14	683-0003		Height Adj. Stop Lever Ass'y. (Incl. Ref. 15)†	37	17636B		Stabilizer Bracket
15	08540		Knob†	38	738-0670		Shaft 1/2" Dia. x 10.28" Lg.
16	710-0604		Hex Wash. TT-Tap Scr. 5/16-18 x .75" Lg.	39	732-0638		Extension Spring
17	748-0176		Flange Brg. .63" I.D.†	40	720-0233		Grip (Lift Handle)
18	710-1238		Hex Wash. Hd. Scr. 5/16-18 x .875" Lg.	41	17675		Deck Lift Handle Ass'y.
19	710-0118		Hex Bolt 5/16-18 x .75" Lg.	42	738-0669		Shaft 3/8" Dia. x 9.34" Lg.
20	17730		Index Brkt.	43	747-0598		Disengagement Rod
21	783-0042	N	Upper Frame—R.H.	44	17624		Stabilizer Shaft Ass'y.
23	736-0267		Fl-Wash. .385" I.D. x .87" O.D.	45	732-0556		Extension Spring 7.58" Lg.
24	736-0160		Fl-Wash. .531" I.D. x .93" O.D.	46	783-0043	N	Upper Frame—L.H.
				47	741-0313		Flange Brg. .632" I.D.
				48	17128		Spring Retainer Brkt.
				49	716-0104		"E"-Ring
				50	736-0425		Bell-Wash. .325" I.D.


†Optional

Models 600 thru 609 (Tecumseh) / 690 thru 699



REF. NO.	PART NO.	CODE	DESCRIPTION
1	710-1007		Hex L-Wash. TT-Tap Scr. 3/8-16 x 1.5" Lg.
2	736-0247		FI-Wash. 3/8" I.D. x 1-1/4" O.D.
3	750-0965		Shld. Spacer .38" I.D. x 1.25" O.D.
4	710-0323		Pan Hd. Mach. Scr. 5/16-18 x .75" Lg.
5	738-0636		Shld. Bolt 7/16" Dia. x 3-5/8" Lg. (12 & 12.5 H.P. Only)
6	751-0443A		Muffler (12 & 12.5 H.P. Only)
7	721-0208		Muffler (16 H.P. Supplied by Engine Manufacturer)
8	726-0197		Exhaust Gasket (12 & 12.5 H.P. Only)
9	710-0899A		Cable Tie
10	751-0360A		Hex Sems Scr. #10-32 x 5/8" Lg.
11	751-0535-15		Casing Clamp
12	726-0205		Fuel Line
13	710-1035		Hose Clamp
14	750-0965		Hex L-Wash. TT-Tap Scr. 3/8-16 x 2.5" Lg. (16 H.P. Only)
15	—		Shld. Spacer .38" I.D. x 1.25" O.D. (16 H.P. Only)
			Engine


Models 600 thru 609 (Single Cylinder) / 690 thru 699



REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	725-1635		Battery	13	725-1649		Socket (Used on Styles 0, 5)
2	725-1426		Solenoid		725-1650		Socket (Used on Styles 8, 9)
3	725-1625		Fuse 7.5 Amps		725-1651		Socket (Used on Styles 1, 3, 7)
4	725-0634		Light Switch (Optional)	14	725-0963		Bulb (Headlight)
5	725-0925		Ammeter (Optional)	15	725-1303		Safety Switch (Seat)
6	725-0267		Ignition Switch	16	725-0980		Ground Wire 7.5" Lg.
7	725-1657	N	Safety Switch (Clutch)	17	725-1439		Safety Switch (Seat)
9	629-0201		Wire Harness w/o Ammeter	18	629-0207		Harness Adaptor
	629-0203		Wire Harness w/Ammeter	19	629-0132	N	Monitor Harness†
	629-0205		Wire Harness w/Monitor	20	725-1365		Monitor Bulb†
12	725-1643		Safety Switch (Reverse)				


†Optional Parts

Models 600 thru 609 (O.H.V.) Models 690 thru 699




REF. NO.	PART NO.	DESCRIPTION
1	651-0005	Exhaust Pipe Ass'y.
2	683-0072	Heat Shield Ass'y.
3	710-0323	Pan Hd. Mach. Scr. 5/16-18 x .75"
4	710-0599	Hex Wash. Hd. Scr. 1/4-20 x .5"
5	710-1237	Hex Slot Wash. Hd. #10-32 x 5/8" Lg.
6	710-0148	Hex Wash. Hd. F-Tap Scr. #8-32 x .38"
7	710-1007	Hex L-Wash. TT-Tap Scr. 3/8-16 x 1.5"
8	726-0205	Hose Clamp—.49" Dia.
10	726-0197	Cable Tie—4" I.D.
11	736-0247	Flat Wash. 3/8" I.D. x 1.25" O.D.
13	737-0199	Pipe Nipple 3/8-18 NPT x 2" Lg.
14	737-0143	Cap—Oil Drain
15	750-0965	Shld. Spacer .38" I.D. x 1.25" O.D.
16	751-0360A	Casing Clamp
17	751-0535-15	Fuel Line Hose
20	751B221535	Casing Clamp
23	—	Engine

Models 600 thru 609 (Twin Cylinder) Models 690 thru 699



REF. NO.	PART NO.	CODE	DESCRIPTION
1	710-0776A	N	Hex AB-Tap Scr. 1/4 x .62"
2	17450		Muffler Heat Shield Mtg. Brkt.—R.H. (Not Shown)
	17449		Muffler Heat Shield Mtg. Brkt.—L.H.
3	751-0474		Muffler
4	16934		Front Heat Shield
5	736-0170		Spec. L-Wash. 5/16 x .88"
6	712-0267		Hex Nut 5/16-18 Thd.
7	731-0511-12		Trim Strip 12" Lg.
8	737-0164		Pipe Nipple
9	737-0143		Oil Drain Cap
10	16804C		Rear Baffle (Used on Styles 8 and 9)
11	—		Engine
12	726-0272		Clamp
13	736-3067		FI-Wash. .188" I.D. x .438"
14	710-0779A		Truss Mach. AB-Tap Scr. #10 x .5" Lg.
15	783-0161		Heat Shield (Styles 3 & 5 Only)
16	726-0328		Rubber Grommet (Used w/Ref. 15)
17	736-0247		FI-Wash. .406" I.D. x 1-1/4" O.D.
18	710-0502A		Hex L-Wash. TT-Tap Scr. 3/8-16 x 1.5" Lg.
19	710-1087		Hex Bolt 5/16-18 x 5/8" Lg.

Models 600 thru 609 (O.H.V.)
Models 690 thru 699




PARTS LIST FOR ELECTRICAL SYSTEM

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	725-1635	Battery	13	725-1649	Socket (Styles 0, 5)
2	725-1426	Solenoid		725-1650	Socket (Used on Styles 8, 9)
3	725-1625	Fuse 7.5 Amps		725-1651	Socket (Used on Styles 1, 3, 7)
4	725-0634	Light Switch	14	725-0963	Bulb (Headlight)
5	725-0925	Ammeter	15	725-1303	Safety Switch (Seat)
6	725-1396	Ignition Switch	16	725-0980	Ground Wire 7.5" Lg.
7	725-1657	Safety Switch (Clutch)	17	725-1439	Safety Switch (Seat)
9	629-0202	Wire Harness	18	629-0132	Monitor Harness†
	629-0204	Wire Harness w/Monitor†	19	725-1365	Monitor Bulb†
12	725-1643	Safety Switch (Reverse)			

†Optional Parts

Models 600 thru 609 (Twin Cylinder)

Models 690 thru 699




PARTS LIST FOR ELECTRICAL SYSTEM

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	725-1635		Battery	14	725-0963		Bulb (Headlight)
2	725-1426		Solenoid	15	725-1303		Safety Switch (Seat)
3	725-1625		Fuse 7.5 Amps	16	725-0980		Ground Wire 7.5" Lg.
4	725-0634		Light Switch	17	725-1439		Safety Switch (Seat)
5	725-0925		Ammeter	18	629-0125		Harness Adapter
6	725-0267		Ignition Switch	19	629-0208		Harness Adapter
7	725-1657		Safety Switch	20	629-0132	N	Monitor Harness†
9	629-0203		Wire Harness	21	725-1365		Monitor Bulb†
	629-0205	N	Wire Harness w/Monitor†	—	731-1284		Harness Conduit (Not Shown)
12	725-0759		Safety Switch (Reverse)				
13	725-1649		Socket (Used on Styles 0, 5)				
	725-1650		Socket (Used on Styles 8, 9)				
	725-1651		Socket (Used on Styles 1, 3, 7)				

†Optional Parts

Deck "F"




PARTS LIST FOR 38" MOWING DECK

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	750-0776		Spacer .33" I.D. x .88"	23	742-0473A		High-Lift Blade
2	710-0672		Hex Bolt 5/16-24 x 1.25" Lg.	25	748-0300		Blade Adapter
3	17503B		38" Deck Ass'y. w/Deck Wheels	26	754-0433		V-Belt
	801-7503		38" Deck Ass'y. Comp w/Deck Wheels (For Service Only)	27	736-0270		Bell-Wash. 1/4" I.D.
	17717B		38" Deck Ass'y. w/o Deck Wheels	28	09322		Brake Disc
	813-06102		38" Deck Ass'y. w/o Deck Wheels (For Service Only)	33	710-0157		Hex Bolt 5/16-24 x .75" Lg.
4	17665		Belt Guard Deck	35	712-0318		Hex Jam Nut 5/8-18 Thd.
6	710-0152		Hex Bolt 3/8-24 x 1.0" Lg.	37	736-0158		L-Wash. 5/8" I.D.*
8	710-0258		Hex Bolt 1/4-20 x .62"	39	717-0906		Blade Spindle Ass'y. Comp.
9	710-0888		Hex Bolt Special 5/16-24 x 1.0"	42	756-0486		5" Dia. Pulley
10	711-0792		Hinge Pin	52	703-1693		Hinge Mtg. Brkt.
11	712-0123		Hex Nut 5/16-24 Thd.*	53	732-0602		Torsion Spring
13	712-0181		Hex Top L-Nut 3/8-16 Thd.†	54	726-0106		Push Nut
14	712-0287		Hex Nut 1/4-20 Thd.*	55	731-1032		Chute Ass'y. Comp. (Incl. Ref. 10, 52, 53, 54, 55)
17	734-0973		Deck Wheel—5"†	56	710-0157		Hex Bolt 5/16-24 x .75" Lg.
18	736-0105		Bell-Wash. .40" I.D. x .38" O.D.†	57	17493A		Deck Hanger Channel
19	736-0119		L-Wash. 5/16" I.D.*	58	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
20	736-0217		L-Wash. 3/8" I.D.—H.D.	59	736-0242		Bell-Wash. .345" I.D. x .88"
22	738-0373		Shld. Bolt .498" Dia. x 1.53"†	60	17863		Skirt Ext.
				61	710-0167		Carr. Bolt 1/4-20 x .5" Lg.
				62	712-0271		Hex Sems Nut 1/4-20 Thd.

*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

†Optional Deck Assembly with Wheels.

Deck "G"




PARTS LIST FOR 42" MOWING DECK

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
3	17600A 813-06119		42" Deck Ass'y. 42" Deck Ass'y. Comp. (For Service Only)	26	754-0371A		V-Belt
4	17664		Belt Guard Deck	27	736-0270		Bell-Wash. 1/4" I.D.
6	710-0152		Hex Bolt 3/8-24 x 1.0" Lg.	28	09322		Brake Disc
7	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.	33	710-0157		Hex Bolt 5/16-24 x .75" Lg.
8	710-0258		Hex Bolt 1/4-20 x .62"	35	712-0318		Hex Jam Nut 5/8-18 Thd.
9	710-0888		Hex Bolt Special 5/16-24 x 1.0"	37	736-0158		L-Wash. 5/8" I.D.*
10	711-0792		Hinge Pin	39	717-0906		Blade Spindle Ass'y. Comp.
11	712-0123		Hex Nut 5/16-24 Thd.*	42	756-0556		5.5" Dia. Pulley
13	712-0181		Hex Top L-Nut 3/8-16 Thd.	52	703-1693		Hinge Mtg. Brkt.
14	712-0287		Hex Nut 1/4-20 Thd.*	53	732-0602		Torsion Spring
17	734-0973		Deck Wheel—5"	54	726-0106		Push Nut
18	736-0105		Bell-Wash. .40" I.D. x .88" O.D.	55	731-1032		Chute Ass'y. Comp. (Incl. Ref. 10, 52, 53, 54, 55)
19	736-0119		L-Wash. 5/16" I.D.*	56	710-0157		Hex Bolt 5/16-24 x .75" Lg.
20	736-0217		L-Wash. 3/8" I.D.—H.D.	57	17493A		Deck Hanger Channel
22	738-0373		Shld. Bolt .498" Dia. x 1.53"	58	736-0242		Bell-Wash. .345" I.D. x .88"
23	742-0499A		High-Lift Blade	59	710-0167		Carr. Bolt 1/4-20 x .5" Lg.
25	748-0300		Blade Adapter	60	17861A		Deck Skirt Ext.—Long
				61	17961		Deck Skirt Ext.—Short
				62	712-0271		Hex Sems Nut 1/4-20 Thd.

*For faster service obtain standard nuts, bolts and washers locally.
If these items cannot be obtained locally, order by part number
and size as shown on parts list.

Deck "H"




Deck "H"

PARTS LIST FOR 46" MOWING DECK

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	618-0111		Blade Spindle Ass'y.	26	736-0105		Bell-Wash. 3/8" x .87" x .064"
2	683-0046B		46" Deck Ass'y.	27	736-0510		Bell-Washer
	813-06413		46" Deck Ass'y. Comp. (For Service)	28	738-0347		Shoulder Spacer .625" I.D. x .169"
3	710-0298		Hex Bolt 5/8-18 x 3.5" Lg.	29	738-0373		Shld. Bolt .498" x 1.525"
4	710-0428		Hex Bolt 1/4-28 x 1.25" Lg.	30	741-0524		Ball Brg. .625" I.D. x 1.574" O.D. x .47"
5	710-0459		Hex Bolt 3/8-24 x 1.5" Lg.	31	742-0543		High Lift Blade 14.88" Lg.
6	710-0152		Hex Bolt 3/8-24 x 1" Lg.	32	742-0542		High Lift Blade 16.28" Lg.
8	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.	33	748-0234		Shoulder Spacer
9	710-0151		Hex Bolt 3/8-24 x 2" Lg.	34	750-0932		Spacer .635" I.D. x .088" O.D.
10	710-1260		Hex Flange Bolt 5/16-24 x .75" Lg.	36	754-0440		V-Belt
11	710-1262		Hex Patch L-Bolt 7/16-20 x 1" Lg.	37	754-0439		V-Belt
12	711-0993		Belt Guard Pin	38	756-0638		Pulley Double Deck 5" O.D.
13	712-0138		Hex Nut 1/4-28 Thd.	39	756-0627		Flat Idler Pulley 3.5 O.D.
14	712-0273		Hex Ins. L-Nut 5/16-24 Thd.	40	783-0046		Idler Deck Bracket
15	712-0241		Hex Nut 3/8-24 Thd.	41	783-0063		Belt Cover L.H.
16	712-0287		Hex Nut 1/4-20 Thd.	42	17116		Deck Brake Brkt. Ass'y.
17	712-0181		Hex Top Jam Nut 3/8-16 Thd.	43	17258A		Belt Cover Brkt. R.H.
18	712-3068		Hex Patch L-Nut 5/16-18 Thd.	44	710-0258		Hex Bolt 1/4-20 x .62" Lg.
19	716-3020		Int. Snap Ring	45	711-0792		Hinge Pin
20	732-0594A		Ext. Spring .88" O.D. x 6.17"	46	736-0270		Bell-Wash. 1/4" I.D.
21	732-0723		Ext. Spring .788" O.D. x 15.5"	47	732-0602		Torsion Spring
22	734-0973		Deck Wheel	48	703-1693		Hinge Mtg. Brkt.
23	736-0290		Fl-Wash. .635" I.D. x 1" O.D. x .06"	49	726-0106		Push Nut
				50	731-1032		Chute Ass'y. Comp. (Incl. Ref. 45, 47, 48, 49, 50)
24	736-0329		L-Wash. 1/4" I.D.*	51	750-0960		Spacer .635" I.D. x 1" O.D.
25	736-0331		Bell-Wash. 3/8" x 1.125" x .062"	52	736-0158		L-Wash. 5/8" I.D.
				53	712-0337		Hex Nut 5/8-18 Thd.

Models 096 (38") and 097 (42")



PARTS LIST FOR MODELS 096 AND 097 MULCHING KITS

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	710-0134	Carriage Bolt 1/4-20 x .62" Lg.	2
2	710-0258	Hex Bolt 1/4-20 x .62" Lg.	1
3	710-3029	Hex Bolt 7/16-20 x 1.25" Lg. (Gr. 5)	4
4	710-0932	Carriage Bolt 1/4-20 x 1" Lg.	1
5	711-0957	Retaining Bolt	1
6	712-0378	Hex Nut 7/16-20 Thd.	4
7	712-0287	Hex Nut 1/4-20 Thd.	3
8	712-0291	Hex L-Nut 1/4-20 Thd.	1
9	712-0397	Wing Nut	2
10	736-0171	L-Wash. 7/16" I.D.	4
11	736-0329	L-Wash. 1/4" I.D.	3
12	742-0539	Mulching Blade 12.5"	2
13	742-0537	Mulching Blade 19.38" (096)	2
	742-0538	Mulching Blade 21.2" (097)	2
14	748-0365	Blade Adapter	2
15	783-0024	Top Mulching Baffle (096)	1
	783-0026	Top Mulching Baffle (097)	1
16	783-0025	Side Mulching Baffle (096)	1
	783-0027	Side Mulching Baffle (097)	1
17	783-0028	Locking Bracket	1
18	736-0217	L-Wash. 3/8" I.D.	2
19	710-1039	Hex Bolt 3/8-24 x 1" Lg. (Gr. 8)	2