



## IMPORTANT SAFEGUARDS

- When using electrical appliances, basic safety precautions should always be followed, including the following:
- Read all instructions.
  - To protect against risk of electrical shock do not immerse cord, plugs or appliance in water or other liquid.
  - Close supervision is necessary when any appliance is used by or near children.
  - Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
  - Avoid contacting moving parts.
  - Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility or call the appropriate toll-free number on the front of this manual for examination, repair or electrical or mechanical adjustment. Or, call the appropriate toll-free number on the cover of this manual.
  - The use of attachments, including canning jars, not recommended by the manufacturer may cause fire, electric shock or injury.
  - Do not use outdoors.
  - Do not let cord hang over edge of table or counter.
  - Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used, but must be used only when the blender is not running.
  - Blades are sharp. Handle carefully.
  - To reduce the risk of injury, never place cutter-assembly blades on base without jar properly attached.
  - Always operate blender with cover in place.
  - When blending hot liquids, remove center piece of two-piece cover.

## SAVE THESE INSTRUCTIONS.

**This product is for household use only.**

## Care and Cleaning

This product contains no user serviceable parts. Refer service to qualified service personnel.

### CLEANING

1. Before cleaning, press the off [0] button on the control panel and unplug the blender.
2. Rinse parts immediately after blending for easier cleanup. Wipe the unit base with a damp cloth and dry thoroughly. Remove stubborn spots by rubbing with a damp cloth and non-abrasive cleaner. Do not immerse the unit base in liquid.
3. All removable parts can be washed by hand or in a dishwasher. The lid, measuring cup, collar, gasket and blade assembly should be placed in the top rack only. Disassemble before placing in the dishwasher. The jars are bottom rack dishwasher-safe. Do not place the jars or any other parts in boiling liquids.
4. If liquids spill into the unit base; first unplug the unit, then wipe with a damp cloth and dry thoroughly. Do not use rough scouring pads or cleansers on parts or finish.

## Recipes

### REFRIED BEANS

2 cans (15-16 oz/425-454 g each) pinto beans or 4 cups (960 ml) freshly cooked pinto beans with their liquid

1 small onion, chopped

2 garlic cloves, chopped

1/4 cup (60 ml) bacon drippings or vegetable oil

1. Drain beans and reserve liquid. In a medium skillet, cook beans, onion and garlic over medium-high heat until onions are very soft.

2. Place 1 cup of the bean mixture in blender jar; cover and mix (speed 2). While blender is running, remove the measuring cup and add a small amount of the reserved bean liquid through the opening as needed to smooth out the mixture. Continue to add beans, 1 cup at a time, and liquid as needed, until all beans are used and mixture is smooth.

Makes approximately 3 cups (720 ml).

### STRAWBERRY-BANANA SMOOTHIE

1/2 cup (120 ml) orange juice

1 cup (about 5 oz./140 g) fresh strawberries, washed and hulled

1 medium banana, cut into 3 pieces

1 container (8 oz./240 ml) vanilla low-fat yogurt

1 Tbsp. honey (15 ml)

3 ice cubes

In blender jar, add first 5 ingredients in order. Cover and mix on (speed 2) for 10 seconds. While blender is running, remove the measuring cup. Add ice cubes and continue to blend until mixture is thick, smooth and creamy.

Makes 2 servings

### POLARIZED PLUG (120V Models Only)

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

### TAMPER-RESISTANT SCREW


**Warning: This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel.**

### ELECTRICAL CORD

- a) A short power-supply cord (or detachable power-supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- b) Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
- c) If a long detachable power-supply cord or extension cord is used,
  - 1) The marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance,
  - 2) If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord, and
  - 3) The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

**Note:** If the power supply cord is damaged, it should be replaced by qualified personnel. In Latin America, by an authorized service center.

### Product may vary slightly from what is illustrated.



1. 2-oz. measuring cup
2. Lid
3. 48-oz. (1.4 L) Glass Jar
4. Gasket
5. Multi-level stainless steel blades
6. Collar
7. Die-cast metal base
8. Controls (see B)

## How to Use

This product is for household use only.

### GETTING STARTED

- Remove all labels, tags and stickers attached to the body or cord.
- Remove and save literature.
- Before first use, wash all removable parts except the unit base as instructed in CARE AND CLEANING section of this manual.
- BLENDER JAR ASSEMBLY**
  1. Place the blade assembly in the collar and place the gasket over the blade assembly.
  2. Holding the jar right-side up, place the jar over the collar and turn it counterclockwise until tight **[A]**.
  3. Place the assembled jar onto the unit base.
  4. Jar is now secure. Do not try to twist jar onto unit base.

### USING YOUR BLENDER

1. Make sure the unit is off [0] and plug the cord into a standard electrical outlet.
2. Place the food to be blended into the jar and put the lid on the jar before blending. Make sure the measuring cup is in place. When crushing ice or hard foods, keep one hand on the lid.
3. Select the appropriate speed setting for your task: Press the off [0] button when finished.
4. Use the pulse button [P] for a few seconds, then release for quick or delicate blending tasks **[B]**.
5. If you want to add ingredients while the blender is on, remove the measuring cup and place through the lid opening.
6. When finished blending, press the off [0] button.
7. To remove the jar, lift it from the unit base. Remove the lid before pouring.

### Blending Tips and Techniques

- Cut food into small pieces, about 2 in. (5 cm) before adding to the blender. To chop, grate or prepare fruit smoothies using fresh or frozen fruit, cut foods into 3/4 in. (2 cm.) pieces.
- For best circulation of foods that are to be blended with some liquid, pour the liquid into the jar first, then add solids.
- Some of the tasks that cannot be performed efficiently with a blender are: beating egg whites, whipping cream, mashing potatoes, grinding meats, mixing dough, and extracting juices from fruits and vegetables.
- The following items should never be placed in the unit as they may cause damage: bones, large pieces of solid frozen foods, or tough foods such as turnips.
- To crush ice, add up to 6 ice cubes. Hold one hand firmly on the lid. If more ice is needed, remove the measuring cup and add cubes one by one through the hole in the lid.

Por favor llame al número correspondiente que aparece en la lista a continuación para solicitar que se haga efectiva la garantía y donde Ud. puede solicitar servicio, reparaciones o partes en el país donde el producto fué comprado. También puede consultarnos en el e-mail servicio@applicamail.com.mx

#### Argentina

SERVICIO TECNICO CENTRAL  
ATTENDANCE  
Avda. Monroe N° 3351  
Buenos Aires - Argentina  
Fonos: 0810 - 999 - 8999  
011 - 4545 - 4700  
011 - 4545 - 5574  
supervision@attendance.com.ar

#### México

Artículo 123 # 95 Local 109 y 112  
Col. Centro, Cuauhtemoc,  
México, D.F.  
Tel. 01 800 714 2503

#### Nicaragua

ServiTotal  
De semáforo de portezuelo  
500 metros al sur.  
Managua, Nicaragua,  
Tel. (505) 248-7001

#### Panamá

Servicios Técnicos CAPRI  
Tumbamurto Boulevard  
El Dorado Panamá  
500 metros al sur.  
Tel. 3020-480-800 sin costo  
(507) 2360-236 / 159

#### Perú

Servicio Central Fast Service  
Av. Angamos Este 2431  
San Borja, Lima Perú  
Tel. (511) 2251 388

#### Puerto Rico

Buckeye Service  
Jesús P. Piñero #1013  
Puerto Nuevo, SJ PR 00920  
Tel.: (787) 782-6175

#### República Dominicana

Plaza Lama, S.A.  
Av. Duarte #94  
Santo Domingo,  
República Dominicana  
Tel.: (809) 687-9171

#### Venezuela

Inversiones BDR CA  
Av. Casanova C.C.  
City Market Nivel Plaza Local 153  
Diagonal Hotel Melia,  
Caracas.  
Tel. (582) 324-0969  
[www.appicaservice.com](http://www.appicaservice.com)  
[servicio@applicamail.com](mailto:servicio@applicamail.com)

### Póliza de Garantía

(Válida sólo para México)

### Duración

Aplica Manufacturing, S. de R. L. de C.V. garantiza este producto por 2 años a partir de la fecha original de compra.

### ¿Qué cubre esta garantía?

Esta Garantía cubre cualquier defecto que presenten las piezas, componentes y la mano de obra contenidas en este producto.

### Requisitos para hacer válida la garantía

Para reclamar su Garantía deberá presentar al Centro de Servicio Autorizado la póliza sellada por el establecimiento en donde adquirió el producto. Si no la tiene, podrá presentar el comprobante de compra original.

### ¿Dónde hago válida la garantía?

Llame sin costo al teléfono 01 800 714 2503, para ubicar el Centro de Servicio Autorizado más cercano a su domicilio en donde usted podrá encontrar partes, componentes, consumibles y accesorios.

### Procedimiento para hacer válida la garantía

Acuda al Centro de Servicio Autorizado con el producto con la póliza de Garantía sellada o el comprobante de compra original, ahí se reemplazará cualquier pieza o componente defectuoso sin cargo alguno para el usuario final. Esta Garantía incluye los gastos de transportación que se deriven de su cumplimiento.

### Excepciones

Esta Garantía no será válida cuando el producto:

- A) Se hubiese utilizado en condiciones distintas a las normales.
- B) No hubiese sido operado de acuerdo con el instructivo de uso que le acompaña.
- C) Cuando el producto hubiese sido alterado o reparado por personas no autorizadas por Aplica Manufacturing, S. de R. L. de C.V.

**Nota:** Usted podrá encontrar partes, componentes, consumibles y accesorios en los centros de servicios autorizados. Esta garantía incluyen los gastos de transportación que se deriven de sus cumplimiento dentro de sus red de servicio.