


C Make and answer calls



- Press **S**: Your Skype contact list is displayed on the handset and on the computer.
- Press **▲/▼** to select the contact you wish to call.
- Press **TALK** to make the call.
- When an incoming Skype call arrives, the phone will ring. The LED on the phone will flash quickly and the phone icon will blink.
- To answer the call, press **TALK**.
- To end the call, press **END**.


Search by letter: Enter the first letter of the contact using the keypad, e.g. to search for "Sam", press **7** four times.

D Features during a call

- **Adjust Earpiece Volume**
Press **▲** to increase the volume.
Press **▼** to decrease the volume.
- **Mute Microphone**
Press **MUTE** to mute the microphone. the LED will flash slowly.
Press **MUTE** again to restore communication.

Note: The microphone volume and the earpiece volume can also be adjusted through the VOIP151 driver. For more information, see detailed user manual available on the VOIP151 CDROM.

E Call SkypeOut number



For details about how to get a SkypeOut account, please visit:
<http://www.skype.com/products/skypeout>

- Use the keypad to dial the number you want to call.
- Press **TALK** to make the call.

OR

- Press **S**: Your Skype contact list is displayed on the handset and on the computer.
- Press **▲/▼** to select the SkypeOut contact you wish to call.
- Press **TALK** to make the call.

To make a SkypeOut call, it is necessary to dial the country prefix before dialing the phone number you are calling, i.e. 00 (& country code), 011 (& country code) or + (& country code).

Note: If you want to make SkypeOut calls, you need to purchase Skype credits. For more details, please visit: <http://www.skype.com/go/store.buy.skypecredit>

Welcome to Philips!

Register your product and get support at
www.philips.com/welcome

Need help?

User Manual

Refer to the User Manual available on the VOIP151 CDROM.

Online help

www.philips.com/support

© 2008 Koninklijke Philips Electronics N.V.

All rights reserved.

Reproduction in whole or in part is prohibited without the written consent of the copyright owner.

Document number: 3111 285 43321



Printed in China

Register your product and get support at
www.philips.com/welcome

Welcome


Quick start guide




- 1 Install
- 2 Connect
- 3 Enjoy

PHILIPS


What's in the box



Handset with 1.2m cable



Installation CD
(contains also the User Manual)




Travel case



Quick start guide


What else you will also need?



- Internet connection (broadband recommended)
- Windows Vista, Windows XP or Windows 2000
- CDROM or DVDROM drive
- a desktop or a laptop with free USB port

I Install


A USB cable



Note: Please make sure the USB connector is **NOT** plugged in before installation starts.

- Unwind the USB cable from your phone.

B Install the software




- Insert the installation CD into the computer's CDROM (or DVDROM) drive
- The installation program will start automatically
- Follow instructions on the screen

Note: If for some reasons the installation does not start automatically:

- In Windows, click on **START**, and then select **Run**.
- Type in **explorer** and navigate to the CD ROM (or DVD ROM) drive.
- Double-click on **SetupWizard.exe**.

2 Connect

Connect USB plug



- Following the instructions, you will be asked to connect the USB plug directly to your computer's USB slot.

Go on following instructions on the screen.


C Finish installation

- Click on **Exit**.
- Remove the installation CD from the computer's CDROM drive.

Use the Skype version provided on the installation CD for the phone to work properly. New features from upgraded Skype version may not be available on VOIP151, check compatibility on www.philips.com/support

3 Enjoy

A Set up for the first time



Note: If you don't have a Skype account, you can find more details about how to create one on <http://www.skype.com>

- Make sure the phone is connected to a USB slot directly on your computer.
- If this is your first installation, the VOIP151 may be launched automatically. It depends on your selection during the installation.
- Otherwise, if the driver is not running, start the VOIP151 driver by double clicking the shortcut icon created on your desktop.
- Start Skype if VOIP151 driver has not started Skype for you. Login with your Skype account.
- If this is your first time running the VOIP151, you will see the message **Another program wants to use Skype**. Select **Allow this program to use Skype** and click **OK**.

B LCD handset display

Skype User & Contact status

- Online / SkypeMe
- Away
- Not Available / Do Not Disturb (DND)
- Offline / Invisible

Handset icons

- Blinking: Mute On
- Blinking: Incoming call
Fix: On-going call
- Call on hold
- On-going
* Conference call
- Ringer Off