



# LifeFitness

ARCTIC SILVER CROSS-TRAINER 95Xe



**Customer Support Services**  
***PARTS MANUAL*** rev 30 Jul 2008


OPERATION MANUAL	M051-00K62-B095
SERVICE MANUAL	M051-00K62-A060
HARDWARE BAG	AK62-00152-0001
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	0017-00008-0204 0017-00008-0205 0017-00008-0206
CRANKSHAFT W/BEARINGS KIT	GK62-00002-0028
ACCESS PANEL ASSEMBLY	AK62-00172-0000
COAX CABLE	AK32-00020-0000
DC POWER CABLE, 80 IN.	AK32-00075-0004
LINE CORD: DOM 10A 125V	0017-00003-0704
LINE CORD: CON 10A 250V	0017-00003-0691
LINE CORD: 10A UK	0017-00003-0889
LINE CORD: AUSTRALIA	0017-00003-0918
POWER SUPPLY w/CORD, 12 v	118E-00001-0161

	Page
CONSOLE SUPPORT & DEADSHAFT COVERS.....	4
HANDLEBARS AND BULLHORNS .....	5
CONSOLE AND RELATED COMPONENTS.....	6
CONSOLE ASSEMBLY .....	7
UPPER FRAME HARDWARE .....	8
ROCKER ARMS AND PEDAL LEVERS .....	9
CRANK COVER AND LOWER CAPS.....	10
LOWER FRAME SHROUDS AND HARDWARE.....	11
PEDAL LEVER COMPONENTS .....	12
DRIVE MODULE COMPONENTS .....	13
DRIVE MODULE HARDWARE.....	14
BLOCK DIAGRAM.....	15

**Note: The 95Xe comes with both Telemetry and LifePulse Sensors.**


**ARCTIC SILVER 95Xe**  
**Console Support & Deadshaft Covers**


**95XE-0XXX-02**  
**S/N ACK100000 and up**



**ARCTIC SILVER 95Xe**  
**Handlebars and Bullhorns**

**95XE-0XXX-02**  
**S/N ACK100000 and up**






<b>CONSOLE ASSEMBLY</b>	
<b>PART NUMBER</b>	<b>DESCRIPTION</b>
GK62-00002-0047	KIT: SERVICE LCD CONSOLE NTSC; ENG
GK62-00002-0048	KIT: SERVICE LCD CONSOLE NTSC; SPN
GK62-00002-0049	KIT: SERVICE LCD CONSOLE NTSC; JAP
GK62-00002-0050	KIT: SERVICE LCD CONSOLE NTSC; FRN
GK62-00002-0051	KIT: SERVICE LCD CONSOLE NTSC; POR
GK62-00002-0054	KIT: SERVICE LCD CONSOLE PAL; ENG
GK62-00002-0055	KIT: SERVICE LCD CONSOLE PAL; GER
GK62-00002-0056	KIT: SERVICE LCD CONSOLE PAL; SPN
GK62-00002-0057	KIT: SERVICE LCD CONSOLE PAL; FRN
GK62-00002-0058	KIT: SERVICE LCD CONSOLE PAL; ITL
GK62-00002-0059	KIT: SERVICE LCD CONSOLE PAL; DUT
GK62-00002-0060	KIT: SERVICE LCD CONSOLE PAL; POR

<b>OVERLAY BEZEL ASSEMBLY</b>	
<b>PART NUMBER</b>	<b>DESCRIPTION</b>
AK62-00308-0001	BZL/SW W/OVERLAY ASSY: MFG; ENG/NTSC
AK62-00308-0004	BZL/SW W/OVERLAY ASSY: MFG; SPN/NTSC
AK62-00308-0006	BZL/SW W/OVERLAY ASSY: MFG; JAP/NTSC
AK62-00308-0007	BZL/SW W/OVERLAY ASSY: MFG; FRN/NTSC
AK62-00308-0010	BZL/SW W/OVERLAY ASSY: MFG; POR/NTSC
AK62-00309-0001	BZL/SW W/OVERLAY ASSY: MFG; ENG/PAL
AK62-00309-0003	BZL/SW W/OVERLAY ASSY: MFG; GER/PAL
AK62-00309-0004	BZL/SW W/OVERLAY ASSY: MFG; SPN/PAL
AK62-00309-0007	BZL/SW W/OVERLAY ASSY: MFG; FRN/PAL
AK62-00309-0008	BZL/SW W/OVERLAY ASSY: MFG; ITL/PAL
AK62-00309-0009	BZL/SW W/OVERLAY ASSY: MFG; DUT/PAL
AK62-00309-0010	BZL/SW W/OVERLAY ASSY: MFG; POR/PAL


**ARCTIC SILVER 95Xe**  
**Console Assembly**

**95XE-0XXX-02**  
**S/N ACK100000 and up**



**ARCTIC SILVER 95Xe**  
**Upper Frame Hardware**

**95XE-0XXX-02**  
**S/N ACK100000 and up**





**ARCTIC SILVER 95Xe**  
**Rocker Arms & Pedal Levers**

**95XE-0XXX-02**  
**S/N ACK100000 and up**


Rocker Arms Kit  
GK62-00002-0070  
contents:  
Rocker Arms (2)  
Hardened Spacers (2)  
Oilite Washers (2)  
Retaining Rings (2)  
*Loctite 620*  
Alcohol pad

Rocker Arms  
AK62-00002-0070  
Shaft Collar w/Screws  
0K61-01259-0000

Life Fitness  
Medallion Assy.  
AK58-00245-0000


Right Pedal  
Lever Assembly  
AK62-00236-0000

Left Pedal  
Lever Assembly  
AK62-00235-0000




**ARCTIC SILVER 95Xe**  
**Crank Cover and Lower Caps**

**95XE-0XXX-02**  
**S/N ACK100000 and up**




**ARCTIC SILVER 95Xe**  
**Lower Frame Shrouds & Hardware**

**95XE-0XXX-02**  
**S/N ACK100000 and up**



**ARCTIC SILVER 95Xe**  
**Pedal Lever Assembly Components**



**95XE-0XXX-02**  
**S/N ACK100000 and up**



Note: If replacing the Tie Rod Assembly or Crank Extension for the first time, order kit GK62-00002-0015. Both sides must be replaced simultaneously in this situation.


**ARCTIC SILVER 95Xe**  
**Drive Module Components**

**95XE-0XXX-02**  
**S/N ACK100000 and up**



**ARCTIC SILVER 95Xe**  
**Drive Module Hardware**

**95XE-0XXX-02**  
**S/N ACK100000 and up**



# ARCTIC SILVER 95Xe

## Block Diagram

95XE-0XXX-02  
S/N ACK10000 and up

