




QUICK SETUP

Model: HT-RC370



Speaker Configuration

- 5.1-channel: ① ② ③ ④ ⑤ ⑥
- 7.1-channel: ① ② ③ ④ ⑤ ⑥ + ⑦ ⑧
- 7.1-channel: ① ② ③ ④ ⑤ ⑥ + ⑨ ⑩
- 7.1-channel: ① ② ③ ④ ⑤ ⑥ + ⑪ ⑫




Please connect ①, ②, ③, ④, ⑤ and ⑥, when connecting 5.1-channel surround.







Connecting a TV with Audio Return Channel



Connecting a TV without Audio Return Channel



When there is no OPTICAL output in the TV, connect the analog output. The function of HDMI THRU can be used by turning on HDMI Control (RIHD) from the setup menu.



Connecting a Portable Player



Portable Player (sold separately)

