




Manitowoc®

MFD-51 COVER REPLACEMENT INSTRUCTIONS

1. If the dispenser is not equipped with an interlock switch, replace the old cover with the new cover and disregard the following instructions.
2. If the dispenser is equipped with an interlock switch, follow the instructions below.
 - A. Remove the interlock switch from the dispenser.
 - B. Remove the yellow lead, which connects the interlock switch with the activating switch, from the "no" side on the activating switch.
 - C. Remove the black lead from the interlock switch and connect it to the "no" side on the activating switch.
 - D. Replace the old cover with the new cover.

CAUTION: DISCONNECT POWER BEFORE WORKING ON ELECTRICAL CIRCUITRY.



Manitowoc Ice, Inc.

2110 South 26th Street, P.O. Box 1720, Manitowoc, WI 54221-1720 USA

Telephone 920-682-0161, Fax - Sales: 920-683-7589, Service/Parts: 920-683-7585, Other: 920-683-7879

Web Site - www.manitowocice.com

8003813

Rev. 10/16/03