



Turn off your computer



Connect the 3.5mm audio connector to the back of the computer



Turn on your computer

Microphone Not Working: Double click on the speaker icon on your system tray. On the menu bar click on Options/Advanced Options. Click on Options menu again and choose Playback, under the Adjust Volume For section, choose Microphone to place a check mark in the box click on ok. If the Microphone section has a check mark in Mute click on it once to remove and close the window.