

INSTALLATION and OPERATING INSTRUCTIONS for STAR SERIES CARVING STATIONS MODELS IFW61WF AND IFW61RR

HOW TO INSTALL:

1. Place the warmer assembly on the cutting board with the star design facing up.
2. Look underneath and line up the (2) holes in the board with the (2) holes in the base of the warmer assembly.
3. Screw the wing screws provided from the bottom up through the board to secure the warmer.
4. Place the 18" x 26" pan under the board in the grooves to catch the scraps and meat drippings.
5. Screw lamp into hood socket.



FIGURE 1

HOW TO CLEAN:



1. Let warmer cool before cleaning.
2. Unplug warmer from wall outlet.
3. Do NOT put warmer in water or spray with water.

Wipe off grease and food splatters **immediately** with a damp cloth and dish detergent.

CAUTION: Hood may be **HOT!**

EVERYDAY:

Wipe warmer hood, plastic-coated arm, and base with a damp cloth.

Do not use gritty cleaners unless really necessary.

REPLACEMENT PARTS:

DESCRIPTION	CMP PART#
Toggle Switch Seal.....	0808-051
Switch (120V).....	0808-002C
Switch (240V).....	0808-122
Power Supply Cord (120V).....	0810-042
Power Supply Cord (240V).....	0810-139
Lamp, Red (250 Watts).....	0820-001
Lamp, White (250 Watts).....	0820-033
Lamp, Red (275 Watts, 240V).....	0820-014
Bun Pan, 18" x 26".....	1038-010
Cutting Board.....	1004-025
Wing Screw.....	0567-783