




OVEN PARTS

For Models: GBD277PRB00, GBD277PRQ00, GBD277PRS00, GBD277PRT00
(Black) (Designer White) (S.Steel) (Biscuit)

27" BUILT-IN ELECTRIC
DOUBLE OVEN
CONVECTION - UPPER OVEN
SELF-CLEAN (GOLD LINE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: GBD277PRB00, GBD277PRQ00, GBD277PRS00, GBD277PRT00
(Black) (Designer White) (S.Steel) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8303648	Literature Parts Installation Instructions	9	4452158	Tube, Vent	33	9760676	Deflector, Vent
	8303645	Use & Care Guide		3196176	Screw		4449154	Screw
	8302068	Tech Sheet (Oven)	10	4452165	Lens, Light	34	4452266	Vent, Center
	3191638	Safer Cooking Tips	11	4452368	Light Assy, Rear		3400832	Screw
	9759133	Safe Cooking Tips	12	4452166	Bulb, Light	37		Safety (TOD) Swtch Thermostat (temp)
2		Trim, Side	14	4455611	Frame, Front		9759242	Upper Oven
	8302917	RH Black		4449040	Screw		9759243	Lower Oven
	8302919	RH White		4450118	Nut		4449809	Screw
	8302921	RH Biscuit	15	4455381	Gasket, Door	43	4455529	Base, Chassis
	8303210	RH S.Steel	18	4452152	Bracket, Mounting		4449809	Screw
	8302918	LH Black	19	4451477	Support, Insulation	49	4448933	Retainer, Gasket
	8302920	LH White		4449809	Screw		4449154	Screw
	8302922	LH Biscuit	21		Rail, Side	50	4451747	Cover, Back
	8303209	LH S.Steel		8302793	Right		4449809	Screw
		Screw		8302794	Left	51		Trim, Bottom
	8281236	Black		4448444	Grommet		8302937	Black
	694091	White		4449154	Screw		8302938	White
3		Receiver, Hinge	24	9759481	Latch, Motorized		8302939	Biscuit
	4455605	Left Hand		4449809	Screw		8302940	S.Steel
	4455606	Right Hand	25	4455641	Side, Chassis (R.H. & L.H.)		3400832	Screw
4	4448520	Bumper, Door		4449809	Screw	53	4449845	Support, Bracket
6	8302348	Divider, Vent	26	4452233	Back, Chassis		4449809	Screw
	4449809	Screw		4449809	Screw	FOLLOWING PARTS NOT ILLUSTRATED		
7	4455864	Top Chassis	27		Liner, Oven (Not serviceable)	INSULATION		
	4449809	Screw	29	4455636	Sensor		4449315	Insulation, Wrap
8	4452490	Spacer, Foam		4449154	Screw		4450364	Insulation, Back
			32	8300154	Insulation, Bottom Vent			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GBD277PRB00, GBD277PRQ00, GBD277PRS00, GBD277PRT00
 (Black) (Designer White) (S.Steel) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	8302844	Black
	8302845	White
2	8302846	Biscuit
		Assy, Switch
	8303182	Black
3	8303224	White
	8303230	Biscuit
	8303817	Assy, Control
4	8301848	Latch, Sister Board
	3400832	Screw
	8302991	Control, Bracket
5	4449745	Screw
	8302878	Trim-Panel (Use on S.Steel model only)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: GBD277PRB00, GBD277PRQ00, GBD277PRS00, GBD277PRT00
 (Black) (Designer White) (S.Steel) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|---|---------|------------------|
| 1 | 8303699 | Door Liner |
| 3 | 4449253 | Glass, Inner |
| 4 | 4451721 | Insulation, Door |
| 5 | 8303166 | Bracket, Handle |
| | 4451040 | Screw |
| | 3400832 | Screw |
| 7 | 9759224 | Glass, Inner |

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|----|---------|--------------------------|
| 12 | | Door Glass, Assy (Upper) |
| | 8303298 | Black |
| | 8303304 | White |
| | 8303308 | Biscuit |
| | 8303286 | S.Steel |
| | | (Lower) |
| | 8303299 | Black |
| | 8303305 | White |
| | 8303309 | Biscuit |
| | 8303287 | S.Steel |


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|----|---------|--------------------|
| 13 | | Door Handle |
| | 8302810 | Black |
| | 8302811 | White |
| | 8302812 | Biscuit |
| | 8303163 | S.Steel |
| 15 | 9759229 | Bracket(2nd Glass) |
| 16 | 9759230 | Bracket(3rd Glass) |
| 19 | 4457102 | Shield, Heat |
| | 4449809 | Screw |
| 20 | 4457131 | Retainer, Glass |
| | 4449809 | Screw |
| 22 | 4457113 | Shield, Heat (Btm) |
| 24 | | Hinge, Door |
| | 8300575 | Right Hand |
| | 8300576 | Left Hand |
| | 4449743 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: GBD277PRB00, GBD277PRQ00, GBD277PRS00, GBD277PRT00
 (Black) (Designer White) (S.Steel) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
2	4456103	Element, Broil
	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448715	Rack, Oven
	9759322	Pad, Rack
7	4452153	Element, Bake
9	4451583	Motor, Convection
	4449154	Screw
10	4452226	Blade, Fan
12	4452227	Nut
21	4448988	Cover, Fan
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GBD277PRB00, GBD277PRQ00, GBD277PRS00, GBD277PRT00
 (Black) (Designer White) (S.Steel) (Biscuit)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust	11	4449868	Block, Terminal	15	9759135	Back, Control
2	4455178	Elbow, Vent-Top		3400080	Screw		4449809	Screw
3	4452003	45MM Lower Oven	13	8303498	Vent, (Control Panel)	16	4450550	Cover, Top Rear
	4457289	65MM Upper Oven		4450038	Screw		4449809	Screw
	4449809	Screw	14	4451597	Right	17	4448664	Clamp
4	4455177	Elbow, Vent-Bottom		4451598	Left		4449809	Screw
5	8300642	Transformer, Control		4449809	Screw	18	4452366	Cover, Top Front
7	8302390	Bracket, Control (Air Stop)		4449154	Screw	20	4451758	Seal, Foam
						21	8302143	Suppressor
							4452260	Spacer, Foam

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GBD277PRB00, GBD277PRQ00, GBD277PRS00, GBD277PRT00
(Black) (Designer White) (S.Steel) (Biscuit)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
72017 White		
261869 Cord Brown		
72032 Black		
<u>PAINT, SPRAY</u>		
350930 White		
261900 Citrine White		
830864 Black		
<u>ADHESIVE</u>		
591014 Adhesive Loctite (1/3 oz.)		
482338 Sealer, Silastic (3 oz.)		
<u>SPLICING WIRES--25FT. LENGTH</u>		
	242828 Wire (12 Ga. 150 c Black)	
	242820 Wire (14 Ga. 150 c Black)	
	242821 Wire (14 Ga. 150 c Blue)	
	242822 Wire (14 Ga. 150 c Brown)	
	242830 Wire (14 Ga. 200 c Brown)	
	242823 Wire (14 Ga. 150 c Green)	
	242824 Wire (14 Ga. 150 c Orange)	
	242829 Wire (12 Ga. 150 c Red)	
	242825 Wire (14 Ga. 150 c Red)	
	242831 Wire (14 Ga. 200 c Red)	
	242826 Wire (14 Ga. 150 c White)	
	242827 Wire (14 Ga. 150 c Yellow)	
	242832 Wire (14 Ga. 200 c Yellow)	
<u>WIRING HARNESS PARTS</u>		
	8301909 Harness, Wire (Latch)	
	4450953 Conduit, Double	
	4448664 Clamp	
	4449809 Screw 112432 Nut	
	4450800 Screw, Ground	
	8301777 Harness, Wire (Main)	
	4452222 Spacer, Harness	
	4454835 Tie, Cable	
	4451761 Support, Wiring	
	4454842 Tie, Cable	
<u>Miscellaneous</u>		
	814381 Pin Hinge Kit	
	4448950 Screw, Install (4)	

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST