


OVEN PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00
 (Black) (White) (Biscuit) (Black Stainless)

30" BUILT-IN ELECTRIC
 COMBO
 SENSOR/SC
 (GOLD LINE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00


(Black) (White) (Biscuit) (Black Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	8	4450038	Screw, 6-32 x 1/2	33	9760677	Deflector, Vent
	8303655	Installation Instructions	9	4452158	Tube, Vent	34	8302592	Vent, Center
		Use & Care Guide	10	4452165	Lens, Light	35	4449906	Ext-Filler
	8303651	Microwave	11	4452368	Oven Light Assy	37	9759243	Thermostat (TOD)
	8303652	Oven	12	4452166	Bulb, Light			(Temp.) SPST
		Cooking Guide (Label)	13	3400832	Screw, 8-18 x 3/8	43	9759713	Base, Chassis
	8300348	Oven	14	9759060	Frame, Front	49	4448933	Retainer, Gasket
	8300346	Microwave	15	4455382	Gasket, Door	50	4451747	Cover, Back
	8303851	Tech Sheet (Oven)	16	4452490	Spacer, Foam	51		Trim, Bottom
	3191638	Safer Cooking Tips	17	4452337	Insulation, Bottom Vent		8302947	Black
	9759133	Safer Cooking Tips	19	4451478	Support, Insulation		8302948	White
	4449237	Cookbook	21		Rail, Side		8302949	Biscuit
		Trim, Side		8303117	Right Side	52	8302950	Stainless Steel
2				8303118	Left Side	53	8303502	Vent, Control
	8302927	RH Black		4448444	Grommet		4451756	Chassis, Back
	8302929	RH White	22	3196176	Screw (3)		4452152	Bracket, Mounting
	8302931	RH Biscuit	23	4449040	Screw			Bottom Trim
	8303217	RH Stainless Steel	24	4450038	Screw	54	4452492	Insulation, Top
	8302928	LH Black	25	4455641	Side, Chassis (R.H. & L.H.)	55	4452491	Insulation, Grill
	8302930	LH White	26	4452234	Back, Chassis	FOLLOWING PARTS NOT ILLUSTRATED		
	8302932	LH Biscuit	27		Liner, Oven (Not Serviceable)	INSULATION		
	8303218	LH Stainless Steel	29	4455636	Sensor		4449316	Insulation, Wrap
3		Hinge, Receiver	30	4449845	Bracket, Support		4450365	Insulation, Back
	4455605	Left Hand						
	4455606	Right Hand						
4	4448520	Bumper, Door						
5	4449809	Screw, 8-18 x 3/8						
6	4449154	Screw, 8/32 x 7/16						
7	4455865	Top, Chassis						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00
 (Black) (White) (Biscuit) (Black Stainless)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	8302848	Black
	8302877	Stainless Steel
	8302849	White
	8302850	Biscuit
2		Assy, Membrane
	8303184	Black
	8303226	White
	8303232	Biscuit
3	3400832	Screw
4	4451592	Filter
5	4452260	Spacer, Foam
6	4451632	Bracket, Filter
7	8303491	Assy, Control
8	4449745	Screw
9	4449809	Screw, 8-18 x 3/8
10	8303119	Backer, Control
11	3400832	Screw, 8-18 x 3/8
12	8303114	Backer, Control

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00
 (Black) (White) (Biscuit) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8303700	Door Liner
2		Hinge, Door
	8300577	R.Side
	8300578	L.Side
3	4449259	Glass, Inner
4	4451722	Insulation, Door And Bottom Door
5	4457132	Retainer, Glass
6	4451040	Screw, 8-16 x 1/2
7	4449743	Screw


Illus. No.	Part No.	DESCRIPTION
8	4449809	Screw, 8-18 x 3/8
10	9759225	Glass, Inner (2)
12		Door Glass
	8303301	Black Model
	8303307	White Model
	8303289	Stainless Steel
	8303311	Biscuit Model
13		Door Handle
	8302813	Black
	8302814	White
	8302815	Biscuit
	8303164	S.Steel

Illus. No.	Part No.	DESCRIPTION
14	8303167	Bracket, Handle
15	9759229	Bracket(2nd Glass)
16	9759230	Bracket(3rd Glass)
18	8303810	Nameplate
19	4457103	Shield, Heat
22	4457114	Shield, Heat (Btm)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00
 (Black) (White) (Biscuit) (Black Stainless)




Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4451758	Seal, Foam
3	8300791	Bracket, Combo Chassis
5	4449809	Screw, 8-18 x 3/8
9	4450408	Baffle, Rear
10	9759525	Latch Assy.
16	4452003	Blower
17	4455178	Vent, Top
18	4455177	Vent, Bottom

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00
 (Black) (White) (Biscuit) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4448988	Cover, Fan
2	4456103	Element, Broil
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	4449154	screw
6	4448717	Rack, Oven
	9759322	Pad, Rack
7	4452153	Element, Bake
8	4452227	Nut
9	4451583	Convection Motor
10	4452226	Fan Blade
11	3181534	Rack, Roasting

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00

(Black) (White) (Biscuit) (Black Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4375299	Bracket, Capacitor	30	4375279	Thermostat	43	4375337	Isolation Plate
3	4375037	Rubber Ring	31	4375079	Thermostat	44	4375338	Cover Plate
4	4375038	Screw	34	4375286	Transformer	45	4375339	Door Plate
5	4375314	Air Duct, Magnetron	35		Hinge, Door	46	4375340	Inner Frame
11	4375315	Damper		4375323	Left	47		Side Plate
12	4375260	Duct, Inlet		4375324	Right		4375341	Left
13	4375316	Insulation, Switch	36	4451009	Torison Spring		4375342	Right
14	4375322	Fan Wheel		4452396	Black Stainless Model	48	4455915	Turntable
15	4375317	Duct, Air	37		Bracket, Hinge	49	4375344	Ring Assembly
16	4375264	Block, Side		4375327	Left	50	4375345	Shaft
17	4375248	Cover Plate, Upper		4375328	Right	51	4375346	Switch
19	4375318	Lens, Lamp	38	4375329	Inlet	52	4375347	Motor, Turntable
20	4375319	Spring	39	4375330	Door Strap	53	4375348	Lamp
21	4375320	Reflector	40	4375333	Fan Cap	54	4375349	Rectifier
25	4375020	Capacitor	41	4375334	Fan Cap Bottom	55	4375350	Cable
26	4375072	Magnetron	42		Switch Holder	56	4375351	Lamp Holder
27	4375321	Fuse		4375335	Left	57	4452220	Rack, Convection Microwave
28	4375231	Block, Fuse		4375336	Right			
29	4375278	Motor, Blower						

IMPORTANT PRODUCT SAFETY INFORMATION


ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO – IT – YOURSELF REPAIRS OF MICROWAVE OVENS.

The U.S. Consumer Product Safety Commission warns against do – it – yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.

STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.

MICROWAVE COMPARTMENT PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00
(Black) (White) (Biscuit) (Black Stainless)




Illus. No.	Part No.	DESCRIPTION
5	4452551	Support Rails Right Side
	4452552	Support Rails Left Side
6	4449809	Screw, 8-18 x3/8
11	4452548	Rear Channel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00
 (Black) (White) (Biscuit) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
9	4448937	Glass, Middle
10	8303556	Frame, Door
11	4450038	Screw
12	4449809	Screw, 8-18 x 3/8
13	4451040	Screw, 8-16 x 1/2
14	4449141	Bracket, Mounting Right Side
	4449142	Left Side


Illus. No.	Part No.	DESCRIPTION
15	4449083	Filler, Side Right Side
	4449086	Left Side
16	8302813	Handle, Door Black
	8302814	White
	8302815	Biscuit
	8303164	S.Steel

Illus. No.	Part No.	DESCRIPTION
17	8303265	Glass, Outer Black
	8303273	White
	8303279	Biscuit
	8303249	Stainless Steel
18	8303810	Nameplate
24	8303169	Bracket, Handle

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00
 (Black) (White) (Biscuit) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4450378	Cover, Top
2	4448935	Baffle, Blower
3	4450920	Blower
4	4451789	Plate, Mounting
5	6610122	Transformer, (Lights)
6	4455038	Transformer, Control
7	4450027	Bracket, Duct
8	4449964	Grommet
9	4454949	Holder, Fuse
	4449154	Screw

Illus. No.	Part No.	DESCRIPTION
10	4454976	Fuse
11	4449868	Block, Terminal
12	4452559	Side, Combo
13	4449809	Screw, 8-18 x 3/8
14		Side, Control Top
	4451597	Right
	4451598	Left
15	9759135	Back, Control
16	4450551	Cover, Top Rear
17	4448664	Clamp

Illus. No.	Part No.	DESCRIPTION
18	4452367	Cover, Top Front
19	4452247	Plate, Cover
20	4451934	Suppressor
21	4451634	Duct, Exhaust
22	4455191	Plate, Service
23	9752759	Relay, Double Line Break
24	4163291	Screw, 6-20 x 1/2
25	4449154	Screw, 8-32 x 7/16

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GSC308PRB00, GSC308PRQ00, GSC308PRT00, GSC308PRS00
 (Black) (White) (Biscuit) (Black Stainless)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	261869	Cord Brown
	72032	Black
<u>PAINT, SPRAY</u>		
	350930	White
	261900	Citrine White
	830864	Black
<u>ADHESIVE</u>		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
<u>SPLICING WIRES--25FT. LENGTH</u>		
	242828	Wire (12 Ga. 150 C Black)
	242820	Wire(14 Ga. 150 C Black)
	242821	Wire (14 Ga. 150 C Blue)
	242822	Wire (14 Ga. 150 C Brown)
	242830	Wire (14 Ga. 200 C Brown)
	242823	Wire (14 Ga. 150 C Green)
	242824	Wire (14 Ga. 150 C Orange)
	242829	Wire (12 Ga. 150 C Red)
	242825	Wire (14 Ga. 150 C Red)
	242831	Wire (14 Ga. 200 C Red)
	242826	Wire (14 Ga. 150 C White)
	242827	Wire (14 Ga. 150 C Yellow)
	242832	Wire (14 Ga. 200 C Yellow)

Illus. No.	Part No.	DESCRIPTION
<u>FOLLOWING PARTS NOT ILLUSTRATED</u>		
	4378944	Filler Kit (Bl)
	4378945	Filler Kit (Wh)
	4378946	Filler Kit (Al)
	814381	Kit, Pin Hinge
	4448950	Screw, Installation
<u>WIRING HARNESS PARTS</u>		
	8301909	Harness, Latch
	8301921	Harness, Main
	8303838	Harness, Main Filter
	4450831	Grown (M/W)
	4450800	Screw
	4449809	Screw
	4450950	Conduit, Combo
	313438	Clip, Harness
	4452222	Spacer, Harness
	4454835	Tie, Cable
	4452400	Ground Lead

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST