




CONTROL PANEL PARTS

For Models: MH3184XPQ3, MH3184XPB3, MH3184XPT3, MH3184XPS3
 (WHITE) (BLACK) (BISCUIT) (STAINLESS)

Microwave Oven
 1.8 Cu. Ft.




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1		Literature
	8205959	U & C Guide
	8205606	Tech Sheet
	8205621	Tech Sheet, Insert
	8205142	Instructn, Install
	8204931	Cook Guide Label
3		Panel Asy, Control Includes Lens and Membrane Switch
	8205374	White
	8205376	Black
	8205377	Biscuit
	8205375	Stainless
4	8205378	Bracket, Control
6	8205379	Microcomputer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: MH3184XPQ3, MH3184XPB3, MH3184XPT3, MH3184XPS3
 (WHITE) (BLACK) (BISCUIT) (STAINLESS)




Illus. No.	Part No.	DESCRIPTION
6	8184922	Pivot, Door
7		Handle, Door
	8205224	White
	8205226	Stainless
	8205225	Biscuit
	8205226	Black
8	8204678	Lower Hinge
9	8169479	Screw
11	8204690	Screw
12	8204691	Washer
13	8204679	Upper Hinge
14		Complete Door
	8205370	White
	8205371	Stainless
	8205373	Biscuit
	8205372	Black

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR AND VENTILATION PARTS

For Models: MH3184XPQ3, MH3184XPB3, MH3184XPT3, MH3184XPS3
(WHITE) (BLACK) (BISCUIT) (STAINLESS)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR AND VENTILATION PARTS


For Models: MH3184XPQ3, MH3184XPB3, MH3184XPT3, MH3184XPS3
(WHITE) (BLACK) (BISCUIT) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION
1	8205096	Reflector, Lamp
2	8183993	Lamp
4	8184001	Filter, Grease
5	8205366	Plate, Bottom
6	8184141	Glass, Lamp
7	8184889	Holder, Glass
8	4393697	Switch, Micro Primary/Secondary
10	4393599	Switch, Micro
11	8169438	Spring, Interlock
12	8205211	Plate, Cam
13	8185189	Support, Interlock
14	8205362	Fan, DC 12 Volt
15	8205364	Housing, Fan
17	8205357	Diffuser, Housing
19	8185190	Rod-Locking Link
20	8184093	Capacitor, 125 V
22	8205356	Plate, Side
24	4393598	Switch, Micro
25	8184202	Cover, Terminal
26	8184091	Motor, Capacitor
27	8184312	Holder, Fuse
28	4393308	Fuse
30	8184199	Screw
31	4393835	Screw
32	8184200	Screw
34	8169477	Screw
36	8169539	Holder, Lamp
38	8205358	Transformer, H.V.
39	8205359	Bracket, Capacitor
40	8205360	Capacitor, H.V.
41	8205361	Diode, H.V.
42	8205365	Chassis

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: MH3184XPQ3, MH3184XPB3, MH3184XPT3, MH3184XPS3
(WHITE) (BLACK) (BISCUIT) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	8205350	Deflector, Air
2	8205353	Cover, Lamp
3	8205368	Duct, Air
4	8204789	Bracket, Thermostat
5	8183703	Thermostat
6	8204676	Cover
7	8183993	Lamp
8	8205354	Air Guide, Back


Illus. No.	Part No.	DESCRIPTION
9	8184825	Motor, Fan Assy
10	8205355	Shield
11	8204790	Shield
12	8205146	Filter, Charcoal
15	8169474	Screw
16	8205367	Left Air Guide
	8205352	Right Air Guide

Illus. No.	Part No.	DESCRIPTION
17	4393808	Humidity, Sensor
18	8169561	Filter
19	8169539	Holder, Lamp
20	8205351	Base Plate, Air Guide
24	8185097	Socket, Motor Wire

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MAGNETRON AND TURNTABLE PARTS

For Models: MH3184XPQ3, MH3184XPB3, MH3184XPT3, MH3184XPS3
(WHITE) (BLACK) (BISCUIT) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	8205044	Motor, Stirrer
2	8205202	Stirrer
		Shaft/Blade
3	8205369	Shield, Nomex
4	8184585	Thermostat/Bracket
5	8184604	Cover, Inlet
		Includes Nails and Bushings
6	8204662	Hook, Rack (4)


Illus. No.	Part No.	DESCRIPTION
7	8184549	Nails/Bushings (4 of each)
8	4393799	Turntable
9	8205778	Ring, Turntable
10	8184109	Spacer, Waterproof
11	8205779	Driver, Turntable
12	8183953	Motor, Turntable
13	4393756	Cover, Terminal

Illus. No.	Part No.	DESCRIPTION
14	8205363	Magnetron
15	8184951	Thermostat
16	8205380	Rack
18	4393838	Screw
21	4393832	Screw
23	8184586	Thermostat/Bracket
24	8184669	Bracket, Plug
25	8205039	Spacer (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND INSTALLATION PARTS

For Models: MH3184XPQ3, MH3184XPB3, MH3184XPT3, MH3184XPS3
(WHITE) (BLACK) (BISCUIT) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	8206172	Plate, Mounting
3	4393713	Door, Damper
4	8184897	Lid, Power Cord
5	8205558	Damper Assembly
6	8205808	Cord, Power
7		Case, Outer
	8205347	White
	8205348	Black
	8205349	Biscuit

Illus. No.	Part No.	DESCRIPTION
8		Grille, Vent
	8205214	White
	8205215	Black
	8205216	Biscuit
9	8184190	Clip, Grille
10	4393836	Screw
11	8169475	Screw
12	4393472	Screw
18	8206192	Plate, Damper

Illus. No.	Part No.	DESCRIPTION
Miscellaneous		
	8205948	Installation, Hardware
	8184731	Template, Upper
	8169704	Screw, Top Mountng
	8205695	Main Harness
	8205696	Ground Wire Assy
	8205693	H.V. Wire Assy

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST