




# DOOR PARTS

MICROWAVE OVEN  
1.5 CUBIC FOOT


For Models: MT4155SPQ3, MT4155SPB3, MT4155SPT3, MT4155SPS3  
(White) (Black) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10158719	Use & Care Guide
	W10178208	Tech Sheet
	8204843	Installation Instructions
	8205086	Cook Guide Label
2	8184263	Latch
3	8171918	Spring, Latch
4	8184265	Cap
5		Door Assembly
	8205446	Black
	8205445	White
	8205447	Biscuit
	8205569	Stainless Steel

# CONTROL PANEL PARTS


For Models: MT4155SPQ3, MT4155SPB3, MT4155SPT3, MT4155SPS3  
 (White) (Black) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Button
	8184427	Black
	8184336	White
	8184441	Biscuit
	8205571	Stainless Steel
2		Switch, Membrane
	8205449	Black
	8205448	White
	8205450	Biscuit
3		Lever, Release
4		Control Panel
	8184541	Black
	8184533	White
	8184543	Biscuit
	8205570	Stainless Steel (Includes #3)
5	W10178210	Microcomputer
6	8184272	Spring
7	4358381	Screw

# OVEN CAVITY PARTS

For Models: MT4155SPQ3, MT4155SPB3, MT4155SPT3, MT4155SPS3  
 (White) (Black) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	8184278	Canopy
2	8205457	Guide, Sensor
3	4358192	Screw
4		Outer Case
	W10178211	Black
	W10178212	White
	W10178213	Biscuit

Illus. No.	Part No.	DESCRIPTION
5	8183514	Sensor, Humidity
6	W10143945	Tray, Glass
7	W10143947	Shaft, Turntable
8	W10143946	Ring, Turntable
9	4358376	Screw

Illus. No.	Part No.	DESCRIPTION
10	W10169273	Motor, Synchronous
11	4358188	Screw
12		Screw
	4358829	Black
	4358362	White
13	8171862	Screw

# LATCH BOARD PARTS


For Models: MT4155SPQ3, MT4155SPB3, MT4155SPT3, MT4155SPS3  
 (White) (Black) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Latch Board Assembly (Non-Serviceable)
2	8185271	Latch Board
3	8183561	Switch Micro Primary/Secondary
4	8183562	Switch, Micro Monitor
5	4358271	Screw

# OVEN INTERIOR PARTS

For Models: MT4155SPQ3, MT4155SPB3, MT4155SPT3, MT4155SPS3  
(White) (Black) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	8205458	Blade, Fan
2	W10169274	Guide, Suction
3	8205462	Motor, Fan
4	8184813	H.V. Capacitor
5	8184288	H.V.C Bracket
6	8206282	Leadwire Assembly
7	8184290	Bracket, Support
8	8184295	H.V. Diode Cable

Illus. No.	Part No.	DESCRIPTION
9	8206281	Power Cord
10	8184383	Thermostat
11	8171810	Lamp, Baseless
12	8204900	Duct, Air
13	8205460	Magnetron
14	4359794	Holder
15	8206270	Filter, Noise

Illus. No.	Part No.	DESCRIPTION
16	8183507	Fuse
17	8204902	Screw, Ground
18	W10160553	Screw
19	4358190	Screw
20	4358489	Screw
21	4358381	Screw
22	8205509	Bracket, Support

# BASE PLATE PARTS

For Models: MT4155SPQ3, MT4155SPB3, MT4155SPT3, MT4155SPS3  
 (White) (Black) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8205464	Base Plate
2	8184385	Leg
3	W10169275	Transformer
4	4358489	Screw

## Following Parts Not Illustrated

Trim Kits	
MK1154XPB	24" Black
MK1154XPQ	24" White
MK1154XPT	24" Biscuit
MK1154XPS	24" S. Steel
MK1157XPB	27" Black
MK1157XPQ	27" White
MK1157XPT	27" Biscuit
MK1157XPS	27" S. Steel
MK1150XPB	30" Black
MK1150XPQ	30" White
MK1150XPT	30" Biscuit
MK1150XPS	30" S. Steel