iHome FastTrack laser mouse

Model # IH-M125LO IH-M126LR

Product Knowledge Base



Frequently asked Questions (FAQs)

- 1. What is included in the box?
- FastTrack laser mouse
- Quick start guide

- 2. What are the system requirements?
- Windows® 2000, XP or Windows Vista®
- Mac® OS X v10.4 or later
- USB port
- 3. How to Setup the Mouse?
- Verify package contents
- Connect USB cable
- Start using your mouse!

Note: The drivers for your mouse load automatically.

4. Where can I find warranty information?

Visit www.life-works.com/warranty

Troubleshooting:

1. My mouse does not work

- Ensure the USB cable is connected. If it is, try connecting it to a different USB port.
- Ensure the laser sensor on the bottom of the mouse is clean.
- Restart your computer.

Product Operating tips:

• The scroll wheel is also a button. Press the scroll wheel (without rolling it) to automatically scroll a document or web page, then move your mouse up or down to set the automatic scroll speed.

 Your mouse has two sensitivity settings, standard mode and highperformance mode. High-performance mode allows the cursor to move very quickly, and is useful for activities such as gaming. Press the DPI button (behind the scroll wheel) to switch from standard mode to highperformance mode and back.

When switching to high-performance mode, the scroll wheel blinks rapidly for 2 seconds. When switching to standard mode, the scroll wheel blinks slowly for 2 seconds.

For questions regarding your iHome computer accessory, please visit our website at www.life-works.com or call 1-877-Life-540.

2009 © LifeWorks Technology Group LLC.

iHome[™] is a trademark of SDI Technologies Inc. used under license.

Windows Vista® is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

Mac® is a trademark of Apple Inc., registered in the U.S. and other countries. All other brands and logos are trademarks of their respective companies.