

# RF-RCMBO2 2.4GHz Wireless Combo

## Package contents

- Keyboard
- 2.4G Receiver
- Installation CD including *User Guide*
- Laser mouse
- AA batteries (4)
- *Quick Setup Guide*

## Features

### Keyboard

- 104-key design
- Connect button
- LED showing pairing and battery status
- 18 hot-keys
- Power switch
- Soft palm rest

### Mouse


- Three mouse buttons (left, right, and middle)
- Tilt/scroll wheel
- Two hot-key buttons
- Power saving mode
- Excellent performance
- Working range up to 32.8 feet (10 meters)
- Dual-color status LED indicator
- Connect button
- Power switch

## System requirements

- One available USB port (USB 2.0 or 1.1)
- Operating system: Microsoft® Windows® 7, Windows® Vista, or Windows® XP with Service Pack 3 or higher

**NOTE:** For optimal performance, we recommend you place the dongle on the front of the computer.

## Keyboard top




#	Description
1	Calculator button
2	Application switch button
3	Play/Pause button
4	Stop button
5	Previous track button
6	Next track button
7	Volume + button
8	Volume - button
9	Mute button
10	Help button
11	Spelling button


#	Description
12	Slide show button
13	Status LED
14	E-mail button
15	Sleep button
16	Home button
17	Search button
18	My Favorite button
19	Back web page button
20	Forward web page button
21	Refresh web page button
22	Stop web page button

## Keyboard bottom

#	Description
1	Connect button
2	Power switch



## Mouse top




#	Description
1	Left button
2	Forward button
3	Back button
4	Right button
5	Tilt/scroll button
6	LED indicator

## Setting up


### Installing the batteries

#### To install the keyboard batteries:

- 1 Remove the battery cover on the bottom of the keyboard.




## Mouse bottom




#	Description
7	Laser sensor
8	Connect button
9	Power button
10	Battery cover

- 2 Install two AA batteries (included). Make sure that the + and - symbols on the batteries match the symbols in the battery compartment.



- 3 Replace the battery cover.

## To install the mouse batteries:



- 1 Press the tab to release the battery cover on the bottom of the mouse.
- 2 Install two AA batteries (included). Make sure that the + and - symbols on the batteries match the symbols in the battery compartment.
- 3 Replace the battery cover.

## Setting up the keyboard and mouse

- 1 Plug the 2.4 GHz receiver into an available USB port on your computer.
- 2 Slide the power switch of the mouse to **ON**, to turn the mouse on.
- 3 Slide the power switch of the keyboard to **ON**, to turn the keyboard on. The computer recognizes the keyboard and mouse automatically. The keyboard and mouse are ready to use.

## Installing the combo driver

To use advanced functions, such as tilt wheel driver, dynamic search and magnifier, you need to install the mouse driver and software.

- 1 Insert the installation CD (provided) in the CD drive on your computer. The installation program should start automatically. If it does not start automatically, open Windows Explorer, browse to the CD, then double-click autorun.exe. The Rocketfish wireless combo screen opens.
- 2 Click **Install Combo Driver**. The Welcome screen opens.
- 3 Click **Next**. The Start installation screen opens.
- 4 Click **Next**. An installation progress bar appears. When the installation is complete, the Setup Complete screen opens.
- 5 Click **Finish**.

## One-year limited warranty

Visit [www.rocketfishproducts.com](http://www.rocketfishproducts.com) for details.

## Contact Rocketfish:

For customer service please call 1-800-620-2790  
[www.rocketfishproducts.com](http://www.rocketfishproducts.com)

© 2010 BBY Solutions, Inc., All Rights Reserved  
Distributed by Best Buy Purchasing, LLC  
7601 Penn Avenue South, Richfield, MN USA 55423-3645